

[Manuals.plus](#) /

> [Sony](#) /

> Sony UBP-X800M2 4K UHD Blu-Ray Disc Player User Manual

Sony UBPX800M2

Sony UBP-X800M2 4K UHD Blu-Ray Disc Player User Manual

Model: UBPX800M2

INTRODUCTION

This manual provides essential information for the setup, operation, and maintenance of your Sony UBP-X800M2 4K UHD Blu-Ray Disc Player. Please read this manual thoroughly before using the product to ensure proper and safe operation.



Figure 1: Front view of the Sony UBP-X800M2 Blu-Ray Disc Player, showcasing its sleek black design and minimal controls.

WHAT'S IN THE BOX

Verify that all items are present in the packaging:

- Sony UBP-X800M2 4K UHD Blu-Ray Disc Player
- Remote Control (RMT-VB310U)
- AAA Batteries (x2)
- Instructions Manual (this document)
- Customer Registration Card

SETUP

1. Placement

Place the player on a stable, level surface with adequate ventilation. Avoid placing it near heat sources or in direct

sunlight.



Figure 2: Proper placement of the Blu-Ray player within a home entertainment system.

2. Connecting to a TV

Use a high-speed HDMI cable (not included) to connect the player to your TV. For optimal 4K UHD and HDR performance, ensure your TV's HDMI input supports HDCP 2.2.

1. Connect one end of the HDMI cable to the HDMI OUT (VIDEO/AUDIO) port on the back of the player.
2. Connect the other end of the HDMI cable to an HDMI input on your TV.



Figure 3: Rear panel connections of the Blu-Ray player, highlighting the HDMI output.

3. Connecting to the Internet

The player supports both wired (Ethernet) and wireless (Wi-Fi) connections for streaming services and firmware updates.

Wired Connection:

- Connect an Ethernet cable from your router to the LAN (100) port on the back of the player.

Wireless Connection:

- Turn on the player and navigate to the Network Settings menu to configure your Wi-Fi connection.

OPERATING INSTRUCTIONS

1. Basic Playback

1. Insert a Blu-Ray disc, DVD, or CD into the disc tray.
2. The player will automatically load the disc. If it does not, select the disc icon from the home menu.
3. Use the remote control to navigate menus and start playback.

2. 4K UHD and HDR Playback

The UBP-X800M2 supports 4K UHD Blu-ray discs with HDR10 and Dolby Vision. Ensure your TV is compatible and configured for these formats.

- For Dolby Vision content, you may need to manually enable Dolby Vision in the player's settings menu. Refer to your TV's manual for specific HDR/Dolby Vision input settings.

3. Streaming Services

Access various streaming applications such as Netflix, YouTube, and Amazon Prime Video via the player's smart functionality.

- Ensure the player is connected to the internet.
- Navigate to the "Network" or "Home" menu to find available streaming apps.

4. USB Playback

The player supports playback of media files from a USB storage device.

1. Insert a USB device into the USB port on the front of the player.
2. Select the USB icon from the home menu to browse and play content.



Figure 4: USB port on the front panel for media playback.

MAINTENANCE

Cleaning the Unit:

- Wipe the exterior of the player with a soft, dry cloth.
- Do not use abrasive pads, scouring powders, or solvents such as alcohol or benzene.

Disc Handling:

- Handle discs by their edges to avoid fingerprints and scratches.
- Clean discs with a soft, lint-free cloth, wiping from the center outwards.

TROUBLESHOOTING

Problem	Solution
No power	Ensure the power cord is securely connected to both the player and a working electrical outlet.

Problem	Solution
No picture or sound	Check HDMI cable connections. Verify correct input selection on your TV. Ensure your TV supports the output resolution of the player.
Disc playback issues (freezing, skipping)	Clean the disc for smudges or scratches. Try a different disc to determine if the issue is with the disc or the player. Ensure the player's firmware is up to date.
Cannot connect to Wi-Fi	Check your router and internet connection. Re-enter your Wi-Fi password in the network settings. Move the player closer to the Wi-Fi router or use a wired connection.

SPECIFICATIONS

Model: UBP-X800M2

Dimensions (W x H x D): Approximately 19 x 3.75 x 14.13 inches

Weight: Approximately 8.4 pounds

Supported Disc Formats: 4K UHD Blu-ray, Blu-ray Disc, DVD, CD

Video Features: 4K High Dynamic Range (HDR10, Dolby Vision), HDR to SDR Conversion, 4K Upscaling (up to 60p)

Audio Features: High-Resolution Audio Playback, Dolby Atmos, DTS:X, DSEE HX

Connectivity: HDMI Output (x2), Coaxial Digital Audio Output, USB Input (front), Ethernet (LAN), Wi-Fi (Built-in)

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the customer registration card included in the box or visit the official Sony support website. The user guide PDF is also available for download:

[Download Official User Guide \(PDF\)](#)

