

DigiTech B07PFTTT7S

DigiTech Portable Wireless UHF Lapel Microphone System User Manual

Model: B07PFTTT7S

INTRODUCTION

Thank you for purchasing the DigiTech Portable Wireless UHF Lapel Microphone System. This system is designed to provide clear, reliable audio transmission for various applications, including presentations, public speaking, and recording. Its compact and portable design ensures ease of use and mobility.

PACKAGE CONTENTS

Please check the package carefully to ensure all items are present and in good condition.

- 1 x UHF Wireless Receiver/Speaker Unit
- 1 x UHF Wireless Transmitter with Lapel Microphone
- 1 x USB Charging Cable
- 1 x Power Adapter
- 1 x Shoulder Strap
- 1 x User Manual (this document)



Image: All components included in the package, showing the receiver/speaker, transmitter with lapel microphone, charging cable, power adapter, and shoulder strap.

PRODUCT FEATURES

- Portable and lightweight design for easy transport.
- UHF wireless technology for stable and clear audio transmission.
- Includes a sensitive lapel microphone for hands-free operation.
- Built-in rechargeable batteries for extended use.
- Auxiliary input for connecting external audio sources.
- Single channel operation.
- Signal-to-noise ratio of 75 dB for clear sound.
- USB connectivity for charging.
- Compatible with amplifiers and speakers.
- Up to 7 selectable frequencies (as per product packaging).

SETUP GUIDE

1. Charging the Devices

Before first use, fully charge both the receiver/speaker unit and the transmitter unit. Use the provided USB charging cable and power adapter.

1. Connect the USB charging cable to the charging port on each device.

2. Plug the other end of the USB cable into the power adapter, then plug the adapter into a standard wall outlet.
3. The charging indicator light (usually red) will turn off or change color (e.g., blue) once fully charged.

2. Pairing the Transmitter and Receiver

The transmitter and receiver are typically pre-paired from the factory. If they do not connect automatically, follow these steps:

1. Ensure both the receiver and transmitter are powered off.
2. Turn on the receiver unit.
3. Press and hold the "Pair" button on the transmitter unit while simultaneously turning it on.
4. Hold the "Pair" button until the indicator light on both units shows a stable connection (e.g., solid blue light).
5. If pairing fails, repeat the process. Ensure no other wireless devices are interfering.



Image: The main components of the system, the receiver/speaker unit and the transmitter with its attached lapel microphone.

3. Connecting to an External Device (Optional)

If you wish to use the system with an external amplifier or speaker, use the appropriate audio cable (not included) to connect the receiver's audio output to the input of your external device.

OPERATING INSTRUCTIONS

1. Power On/Off

- To power on, slide the power switch on both the receiver and transmitter to the "ON" position.
- To power off, slide the power switch on both units to the "OFF" position.

2. Volume Adjustment

Adjust the volume using the volume control knob or buttons on the receiver/speaker unit. Start with a low volume and gradually increase it to a comfortable level.

3. Using the Lapel Microphone

Clip the lapel microphone to your clothing, approximately 6-12 inches (15-30 cm) from your mouth, for optimal sound pickup. Ensure the microphone is not covered by clothing.

4. Frequency Selection (if applicable)

If your system supports multiple frequencies, refer to the specific instructions on the transmitter for changing channels. This is useful in environments with wireless interference.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the units. Do not use liquid cleaners or solvents.
- **Battery Care:** To prolong battery life, avoid fully discharging the batteries frequently. Charge them regularly, even if the device is not in use for extended periods (e.g., once every 3 months).
- **Storage:** Store the system in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity.
- **Handling:** Handle the units with care. Avoid dropping them or exposing them to strong impacts.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No sound from receiver/speaker.	Units not powered on.	Ensure both units are powered on.
	Low battery.	Charge both units fully.
	Units not paired.	Follow pairing instructions in the Setup Guide.
	Volume too low.	Increase volume on the receiver.
	Microphone not connected or faulty.	Check microphone connection to transmitter.
Poor sound quality (static, dropouts).	Interference from other wireless devices.	Change operating frequency (if available).
	Units too far apart.	Reduce distance between transmitter and receiver.
	Low battery.	Charge both units.
	Obstructions between units.	Ensure clear line of sight.
Transmitter not pairing.	Incorrect pairing procedure.	Repeat pairing steps carefully.
	Low battery.	Charge both units fully.

SPECIFICATIONS

Brand	DigiTech
Model	B07PFTTT7S
Power Source	Corded Electric, Battery Powered
Connector Type	Aux
Number of Channels	1
Audio Input	Wireless Microphone, Auxiliary

Special Features	Wireless
Microphone Format	Microphone System
Signal-to-Noise Ratio (SNR)	75 dB
Item Weight	480 g
Package Dimensions	18.8 x 16.1 x 7.9 cm
Connectivity Technology	USB (for charging)
Colour	Black
Compatible Devices	Amplifier, Speaker
Mounting Type	Portable

WARRANTY AND SUPPORT



This DigiTech product comes with a standard manufacturer's warranty. For specific warranty terms and conditions, please refer to the warranty card included in your package or visit the official DigiTech website. For technical support, troubleshooting assistance, or to inquire about repairs, please contact DigiTech customer service through their official channels.






Please retain your proof of purchase for warranty claims.



© 2024 DigiTech. All rights reserved.
This manual is subject to change without notice.

Related Documents

	<p>Digitech AM4051 UHF Headset Microphone Kit Instruction Manual</p> <p>Instruction manual for the Digitech AM4051 UHF Headset Microphone Kit, covering box contents, features, product diagram, operation instructions, troubleshooting, specifications, and warranty information.</p>
	<p>Digitech Slimline Indoor UHF/VHF Antenna with Signal Meter User Manual LT-3158</p> <p>User manual for the Digitech Slimline Indoor UHF/VHF Antenna (LT-3158) with signal meter. Includes setup, operation, troubleshooting, safety, and specifications for optimal TV reception.</p>

<div data-bbox="116 91 312 365"><div></div><div>Portable Bluetooth® Wireless Speaker with RGB</div><div></div><div>Model CS2648</div><div> R-NZ</div><div>Instruction Manual</div></div>	<p>Digitech CS2648 Portable Bluetooth Wireless Speaker with RGB - Instruction Manual</p> <p>User manual for the Digitech CS2648 Portable Bluetooth Wireless Speaker with RGB. Includes features, usage instructions, button functions, and warranty information provided by Electus Distribution.</p>
<div data-bbox="116 405 312 678"><div></div><div>Portable Boom Box Speaker with Bluetooth® TWS</div><div></div><div>Model CS2602</div><div>Instruction Manual</div></div>	<p>Digitech CS2602 Portable Boom Box Speaker with Bluetooth TWS - Instruction Manual</p> <p>User manual for the Digitech CS2602 Portable Boom Box Speaker. Learn about features, specifications, operation instructions for Bluetooth, TWS, FM radio, USB, and AUX modes, charging, and safety guidelines.</p>