

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [BAYBEE](#) /

> [Baybee Electric Baby Swing Cradle Instruction Manual B07PFX2V5F](#)

BAYBEE Electric Baby Swing Cradle B07PFX2V5F

Baybee Electric Baby Swing Cradle Instruction Manual

Model: B07PFX2V5F

1. IMPORTANT SAFETY INFORMATION

Read all instructions before assembly and use of the Baybee Electric Baby Swing Cradle. Keep this manual for future reference.

- This product is EN Certified, meeting stringent European safety standards for babies and toddlers.
- Suitable for newborns and infants.
- **Maximum weight capacity: 15 Kilograms.** Do not exceed this weight limit.
- Always ensure the cradle is placed on a flat, stable, and non-slip surface to prevent tipping.
- Never leave your child unattended in the swing.
- Ensure all components are securely assembled before placing a child in the cradle.
- Keep small parts away from children during assembly.

2. PRODUCT COMPONENTS AND STRUCTURE

The Baybee Electric Baby Swing Cradle is designed with durable and comfortable materials for your baby's safety and comfort.



Cotton Fabric and ABS Plastic: The cradle features skin-friendly, breathable, and soft cotton fabric for comfort, combined with stable and strong environmental protection ABS plastic for safety.



Thick Steel Pipe and Sturdy Base: Constructed with thick steel pipes for enhanced durability and safety. The cradle's four corners are designed to be sturdy and stable, providing a secure grip.

3. SETUP AND ASSEMBLY

Follow these steps to assemble your Baybee Electric Baby Swing Cradle.

1. Unpack all components from the packaging. Verify all parts are present according to the packing list (not provided in this manual).
2. Assemble the main frame using the thick steel pipes, ensuring all connections are secure.
3. Attach the cradle basket to the assembled frame, making sure it is firmly connected and balanced.
4. Install the mosquito net over the cradle basket.
5. The cradle features a folding bracket for easy transport and storage. Ensure it is fully extended and locked into place for use.


For a visual guide, an assembly video is available online: <https://www.youtube.com/watch?v=nhtNjmcNWpw>

4. OPERATING INSTRUCTIONS


4.1 Powering the Cradle

The cradle can be powered via a low voltage power adapter or batteries (not included). Connect the power adapter to the designated port or insert the required batteries according to the polarity markings.

4.2 Control Panel and Remote Functions



Cradle Control Panel: Features an ON/OFF button, swing gear indication, timing button, lullaby selection, timing indicator, and volume/next controls.



Remote Control: Provides convenient access to functions including ON/OFF, volume up/down, music/TF button, fast forward, next, music button, timer button, speed control (1-6), and stop button.

4.3 Swing Speed Adjustment

The cradle offers six adjustable swing speeds, corresponding to swing angles from 10 to 30 degrees. Use the swing speed selector buttons on the control panel or remote to choose the desired speed. Six LED lights indicate the current speed setting (1-6).

Six Speed Adjustment

Baby sleep gently like on mother's arm



Six Speed Adjustment: Adjust the swing speed from Level 1 to Level 6 for gentle motion.

4.4 Music and Nature Sounds

The cradle includes built-in nature sounds and music. Press the TOGGLE button on the control panel or the Music button on the remote to cycle through three nature sounds and seven musical tunes. These will play automatically for two cycles.


Extra Music (TF Card): To play additional music, insert a TF card with music files before powering on the device. Only music files on the TF card will play. Press the TOGGLE button to advance to the next track.

4.5 Timing Function

Press the TIMING button on the control panel or the Timer button on the remote to set the operating time to 15, 30, or 45 minutes. After the selected time, all functions will stop automatically. If no timing is set, the module will automatically stop after one hour of continuous operation.

5. MAINTENANCE

- **Cleaning:** The fabric components of the cradle are washable. Follow the product care instructions for hand washing only.
- Regularly inspect all parts for wear and tear, especially the frame, fabric, and electronic components.
- Ensure the mosquito net is clean and free from damage.
- Keep the control panel and remote clean and dry.



Washable Fabric: The cradle features washable fabric for easy cleaning and hygiene.

6. TROUBLESHOOTING

If you encounter issues with your Baybee Electric Baby Swing Cradle, consider the following:

- **Cradle Not Swinging:**
 - Check if the power adapter is securely connected or if batteries are correctly inserted and not depleted.
 - Ensure the ON/OFF button has been pressed.
 - Verify that the swing speed is set to a level above 0.
- **Remote Control Not Working:**
 - Replace the remote control batteries.
 - Ensure there are no obstructions between the remote and the cradle's receiver.
- **No Sound/Music:**
 - Check the volume level.
 - If using a TF card, ensure it is inserted correctly and contains valid music files.

If problems persist, please contact customer support.

7. SPECIFICATIONS

Brand	BAYBEE
Model Number	B07PFX2V5F

Color	Brown
Material	ABS, Cotton
Maximum Weight Recommendation	15 Kilograms
Minimum Age Recommendation	0 months and up
Item Weight	8 kg 200 g
Package Dimensions	93 x 46.6 x 12.8 cm
Product Dimensions (Approx.)	100 cm (Length) x 63 cm (Width) x 85 cm (Height)
Batteries Required	No (for main unit, remote may require batteries)
Form Factor	Folding
Furniture Finish	Matte finish

8. WARRANTY AND SUPPORT

Warranty information for this product is not explicitly provided in the available product details. For any warranty claims, technical support, or service inquiries, please contact the manufacturer directly.

Manufacturer: BAYBEE