

Sharp SJX-640-BK3

Sharp Side by Side Refrigerator SJX-640-BK3 User Manual

Model: **SJX-640-BK3** | Brand: **Sharp**

1. IMPORTANT SAFETY INFORMATION

Please read all safety instructions carefully before operating your new Sharp refrigerator. Keep this manual for future reference.

- Ensure the refrigerator is placed on a firm, level surface.
- Do not block ventilation openings in the appliance enclosure or in the built-in structure.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- Do not damage the refrigerant circuit.
- Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.
- Unplug the appliance before cleaning or performing maintenance.

2. SETUP AND INSTALLATION

2.1 Unpacking

Carefully remove all packaging materials, including tape and protective films. Retain packaging for potential future transport.

2.2 Placement

Place the refrigerator in a location with adequate air circulation. Avoid direct sunlight or proximity to heat sources. Ensure sufficient clearance around the appliance for proper ventilation (e.g., 10cm at the back and sides, 30cm at the top).



Figure 2.1: Angled view of the Sharp SJX-640-BK3 refrigerator, showing its sleek black glass finish and side profile, important for understanding placement requirements.

2.3 Leveling

Adjust the leveling feet at the bottom of the refrigerator to ensure it is stable and level. This prevents vibrations and ensures proper door sealing.

2.4 Electrical Connection

Connect the refrigerator to a dedicated, grounded electrical outlet. Do not use extension cords or adapters. Allow the refrigerator to stand upright for at least 2-4 hours before plugging it in to allow refrigerants to settle.

3. OPERATING INSTRUCTIONS

3.1 Control Panel Overview

The Sharp SJX-640-BK3 features a Digital Smart Control panel located on the exterior of the freezer door. This panel allows you to adjust temperatures and access various functions.



Figure 3.1: Front view of the Sharp SJX-640-BK3 refrigerator, highlighting the external Digital Smart Control panel on the left door.

3.2 Temperature Settings

Use the control panel to set the desired temperature for both the refrigerator and freezer compartments. The Digital Smart Control senses when warm food is stored and adjusts cooling accordingly.

3.3 Magic Cool Zone

The Magic Cool Zone compartment offers flexible temperature control for specific items. Select from the following modes:

- **Fresh:** Ideal for general produce and dairy.
- **Vegetable:** Optimized for keeping vegetables crisp and fresh.
- **Fish:** Maintains a lower temperature suitable for fresh fish.
- **Meat:** Provides optimal conditions for storing fresh meat.

3.4 Special Features

- **Xpress Can Chiller:** A dedicated compartment designed to rapidly chill beverages.
- **Spill-Proof Shelves:** Tempered glass shelves with raised edges to contain accidental spills and prevent liquids from dripping to lower shelves.
- **Temperature Alarm:** Alerts you if the internal temperature fluctuates significantly, helping to preserve food

freshness.

- **Door Alarm:** Sounds an alert if a refrigerator door is left open for an extended period.



Figure 3.2: Interior view of the Sharp SJX-640-BK3 refrigerator, showcasing the spacious compartments, spill-proof glass shelves, and storage bins.

4. MAINTENANCE AND CLEANING

4.1 Interior Cleaning

Regularly clean the interior with a mild detergent and warm water. Wipe dry with a soft cloth. Remove shelves and drawers for thorough cleaning as needed. Do not use abrasive cleaners or solvents.

4.2 Exterior Cleaning

Wipe the exterior surfaces, including the black glass finish, with a soft, damp cloth. For stubborn marks, use a mild glass cleaner. Avoid harsh chemicals that may damage the finish.

4.3 Door Seals

Clean the door seals regularly to ensure a tight seal. A dirty or damaged seal can lead to inefficient cooling.

4.4 Automatic Defrost

This refrigerator features an automatic defrost system, eliminating the need for manual defrosting of the freezer compartment.

5. TROUBLESHOOTING

Before contacting service, please check the following common issues and solutions:

Problem	Possible Cause	Solution
Refrigerator not cooling	Power supply issue, temperature setting too high, door not closed properly.	Check power plug, adjust temperature, ensure doors are fully closed.
Unusual noises	Refrigerator not level, items vibrating inside, normal compressor sounds.	Level the appliance, rearrange items, normal operation sounds are expected.

Problem	Possible Cause	Solution
Door alarm sounds frequently	Door not fully closed, obstruction, faulty sensor.	Ensure nothing blocks the door, check door seals, close door firmly.
Water on floor	Drain tube clogged, excessive humidity.	Clear drain tube (refer to service manual if needed), ensure proper ventilation.

6. SPECIFICATIONS

Technical specifications for the Sharp SJX-640-BK3 Side by Side Refrigerator:

Feature	Detail
Brand Name	Sharp
Model Info	SJX-640-BK3
Product Dimensions	70 x 90 x 178 cm
Capacity	24 Cubic Feet (640 Liters)
Freezer Capacity	24 Cubic Feet (shared total capacity)
Installation Type	Freestanding
Form Factor	Side By Side
Special Features	Compact, Digital Smart Control, Magic Cool Zone, Xpress Can Chiller, Spill-Proof Shelves, Temperature Alarm, Door Alarm
Color	Black
Defrost	Automatic
Door Hinges	Side by Side
Door Material Type	Glass
Shelf Type	Glass
Material Type	Metal
Shipping Weight	110 kg
Date First Available	10 March 2019

7. WARRANTY AND SUPPORT

For detailed warranty information, please refer to the warranty card included with your product or visit the official Sharp website. For technical support or service inquiries, please contact Sharp customer service through their official channels.

You can visit the official Sharp store on Amazon for more products and information:[Sharp Store](#)