

[Manuals.plus](#) /

› [Hilltop Products](#) /

› Hilltop Products 2-Pack White Toilet Paper Holder Spring Loaded Roller Replacement Rod Instruction Manual

Hilltop Products ABS ROUND COLOUR SHOWER HILLTOP PRODUCT

Hilltop Products 2-Pack White Toilet Paper Holder Spring Loaded Roller Replacement Rod Instruction Manual

Model: ABS ROUND COLOUR SHOWER HILLTOP PRODUCT

1. INTRODUCTION

This manual provides instructions for the installation and use of the Hilltop Products 2-Pack White Toilet Paper Holder Spring Loaded Roller Replacement Rod. This product is designed to replace old, damaged, or missing toilet paper holder rollers, offering a universal fit for most standard holders.

2. PRODUCT OVERVIEW

The Hilltop Products replacement rollers are crafted from durable plastic and feature a robust spring-loaded mechanism for secure fit and easy operation. Each roller includes tamper tips with three steps to ensure correct installation.



Figure 1: Two white spring-loaded toilet paper roller replacement rods.

Key Features:

- **Quantity:** 2 pieces per pack.
- **Material:** Durable plastic with a high-quality steel spring.
- **Design:** Spring-loaded for easy installation and secure hold.
- **Compatibility:** Universal fit for most toilet paper holders.
- **Installation Aid:** Tamper tips with 3 steps for proper alignment.




Figure 2: Internal structure showing the durable plastic and steel spring.

3. SPECIFICATIONS

Attribute	Detail
Brand	Hilltop Products
Material	Plastic
Finish Type	Matte
Color	White
Product Dimensions (Extended)	6.5 inches (Length) x 1 inch (Diameter)
Product Dimensions (Compressed)	4.25 inches (Length)
Shape	Cylindrical
Number of Items	2
Item Weight	1.13 ounces
UPC	706098736530
Model Number	ABS ROUND COLOUR SHOWER HILLTOP PRODUCT

SIZE




Figure 3: Detailed dimensions of the toilet paper roller.

4. INSTALLATION

The spring-loaded design allows for quick and easy installation into most standard toilet paper holders. No tools are required.

1. **Remove Old Roller:** If replacing an existing roller, remove it from the toilet paper holder.
2. **Prepare New Roller:** Take one of the Hilltop Products replacement rollers.
3. **Compress and Insert:** Apply pressure to one end of the roller, compressing the internal spring.
4. **Position:** Insert the compressed end into one side of the toilet paper holder.
5. **Release:** Align the other end with the opposite side of the holder and release the pressure, allowing the spring to expand and secure the roller in place.

Hilltop Products®



Figure 4: Example of a roller installed in a toilet paper holder.

Installation Demonstration Videos:

Toilet Paper Holder Installation

Your browser does not support the video tag.

Video 1: A demonstration of how to install the spring-loaded toilet paper roller into a holder. This video shows the compression and placement process.

Spring Loaded Roller Rod Demonstration

Your browser does not support the video tag.

Video 2: This video illustrates the spring-loaded action of the toilet paper roller, demonstrating its flexibility for installation.

White Toilet Paper Holder Roller Overview

Your browser does not support the video tag.

Video 3: A brief overview of the white toilet paper holder roller, highlighting its features and ease of use.

Toilet Paper Roller Functionality

Your browser does not support the video tag.

Video 4: This video demonstrates the practical application of the toilet paper roller, showing how it holds a roll securely.

Plastic Toilet Paper Roller Features

Your browser does not support the video tag.

Video 5: A short video showcasing the white plastic toilet paper roller and its spring mechanism.

5. OPERATING INSTRUCTIONS

To replace a toilet paper roll:

1. Remove the empty toilet paper roll from the roller.
2. Compress one end of the spring-loaded roller.
3. Slide the roller out of the toilet paper holder.
4. Place a new toilet paper roll onto the roller.
5. Compress one end of the roller again and insert it back into the toilet paper holder, ensuring both ends are securely seated.

6. MAINTENANCE

To maintain the cleanliness and functionality of your toilet paper roller:

- Wipe the roller with a damp cloth and mild soap as needed.
- Avoid using abrasive cleaners or harsh chemicals, as these may damage the plastic finish.
- Ensure the spring mechanism remains free of debris to allow for smooth operation.

7. TROUBLESHOOTING

Issue: Roller does not fit in the holder.

- **Solution:** Verify the dimensions of your toilet paper holder. The roller is designed to fit most standard holders with an extended length of 6.5 inches and a compressed length of 4.25 inches. If your holder is significantly outside these dimensions, the roller may not be compatible.

Issue: Roller feels loose or falls out.

- **Solution:** Ensure the roller is fully extended and properly seated in both sides of the holder. The spring should provide sufficient tension to keep it in place. Check for any obstructions in the holder's slots.

8. WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your Hilltop Products toilet paper roller, please refer to the seller's contact information on the product packaging or the platform where it was purchased. Specific warranty details are typically provided at the point of sale.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07PK6VWS8>

More documents and user manuals: <https://manuals.plus/>