

Daewoo DJE-5659

Daewoo DJE-5659 400 Watts Centrifugal Juice Extractor User Manual

INTRODUCTION

Thank you for purchasing the Daewoo DJE-5659 400 Watts Centrifugal Juice Extractor. This appliance is designed to efficiently extract juice from various fruits and vegetables, providing fresh and nutritious beverages. Please read this manual thoroughly before operating the appliance to ensure safe and optimal performance. Keep this manual for future reference.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons. Read all instructions carefully.

- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- Do not immerse the motor unit in water or any other liquid. Clean with a damp cloth only.
- Always unplug the appliance from the power outlet before assembling, disassembling, or cleaning.
- Keep hands and utensils out of the feed chute during operation to prevent injury and damage to the juicer.
- Never use your fingers to push food down the feed chute. Always use the food pusher provided.
- Do not operate the appliance if the power cord or plug is damaged, or if the appliance malfunctions or has been dropped or damaged in any manner.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Place the appliance on a stable, level, and dry surface during operation.
- Do not use attachments not recommended or sold by the manufacturer.

PRODUCT COMPONENTS

Familiarize yourself with the parts of your Daewoo DJE-5659 Juice Extractor before use.

1. Food Pusher
2. Transparent Lid with Feed Chute
3. Filter Basket (Stainless Steel)
4. Juice Collector/Spout
5. Pulp Container
6. Motor Unit with Control Dial
7. Safety Locking Bar
8. Juice Jug (1.5 Liter Capacity)



Image 1: Fully assembled Daewoo DJE-5659 Juice Extractor, showing the main unit, juice jug, and pulp container.

SETUP AND ASSEMBLY

Follow these steps to correctly assemble your juice extractor before first use.

1. Place the motor unit on a dry, stable, and flat surface.
2. Insert the juice collector/spout onto the motor unit, ensuring it is securely seated.
3. Place the stainless steel filter basket firmly into the juice collector. Ensure it clicks into place.
4. Position the transparent lid with the feed chute over the filter basket and juice collector. Align the lid with the motor unit and press down until it is securely in place.
5. Lift the safety locking bar and hook it over the lid on both sides. Push the locking bar down until it locks into position. The appliance will not operate if the locking bar is not correctly engaged.
6. Place the pulp container under the pulp outlet on the side of the motor unit.
7. Place the juice jug under the juice spout.
8. Insert the food pusher into the feed chute.



Image 2: Daewoo DJE-5659 Juice Extractor assembled, demonstrating the placement of the juice jug and the main unit components before attaching the pulp container.

OPERATING INSTRUCTIONS

Before juicing, ensure all components are correctly assembled and the safety locking bar is engaged.

1. Wash fruits and vegetables thoroughly. For larger items, cut them into smaller pieces that fit into the feed

chute. Remove hard pits from fruits like peaches or plums. Peeling is generally not necessary for most fruits and vegetables, but you may peel citrus fruits to avoid a bitter taste.

2. Plug the appliance into a suitable power outlet.
3. Turn the control dial to the desired speed setting: **I** (low speed) for softer fruits and vegetables (e.g., berries, tomatoes) or **II** (high speed) for harder fruits and vegetables (e.g., carrots, apples).
4. Gradually feed the prepared fruits and vegetables into the feed chute using the food pusher. Do not force the food down, as this can affect the juicer's performance and potentially damage the motor.
5. The fresh juice will flow into the juice jug, and the pulp will collect in the pulp container.
6. Once juicing is complete, turn the control dial to the '0' (off) position and unplug the appliance from the power outlet.

Tips for Best Results:

- Process softer ingredients before harder ones to prevent clogging.
- Do not overload the juicer. Feed ingredients at a steady pace.
- For maximum juice extraction, ensure the filter basket is clean before each use.

CLEANING AND MAINTENANCE

Regular cleaning ensures the longevity and hygienic operation of your juice extractor. Always unplug the appliance before cleaning.

1. Turn the control dial to '0' and unplug the appliance.
2. Remove the food pusher.
3. Unlatch the safety locking bar and remove the transparent lid.
4. Carefully remove the filter basket and the juice collector/spout.
5. Empty the pulp container and the juice jug.
6. Rinse all detachable parts (food pusher, lid, filter basket, juice collector, pulp container, juice jug) under running water immediately after use to prevent pulp from drying and sticking.
7. Use a cleaning brush (if provided) to thoroughly clean the mesh of the filter basket. Dried pulp can be difficult to remove.
8. Most detachable parts are dishwasher safe. Refer to the product care instructions for specific details.
9. Wipe the motor unit with a damp cloth. Never immerse the motor unit in water or any other liquid.
10. Dry all parts thoroughly before reassembling or storing.

TROUBLESHOOTING

If you encounter issues with your juice extractor, refer to the following common problems and solutions.

- **Appliance does not start:**
 - Check if the power cord is securely plugged into the outlet.
 - Ensure the safety locking bar is correctly engaged over the lid. The juicer has a safety interlock system.
- **Low juice yield or excessive pulp:**
 - Ensure the filter basket is clean and free from blockages.

- Use the appropriate speed setting for the type of fruit or vegetable.
- Feed ingredients slowly and steadily, do not overload.

• **Motor stops during operation:**

- The juicer may have overheated due to continuous use or overloading. Turn off the appliance, unplug it, and let it cool down for at least 15-20 minutes before resuming.
- Check for blockages in the filter basket or feed chute.

• **Vibration or excessive noise:**

- Ensure all parts are correctly assembled and securely locked.
- Check if the appliance is placed on a stable, level surface.

SPECIFICATIONS

Feature	Detail
Brand	Daewoo
Model Number	DJE-5659
Type	Centrifugal Juice Extractor
Power / Wattage	400 Watts
Capacity (Juice Jug)	1.5 Liters
Material	Stainless Steel
Color	Multi-color (Stainless Steel and Black)
Speed Settings	2 (Low 'I', High 'II')
Special Features	Portable
Product Care Instructions	Dishwasher Safe (detachable parts)
Power Source	Corded Electric

WARRANTY AND SUPPORT

This Daewoo DJE-5659 Juice Extractor comes with a standard manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including the warranty period and coverage details.

For technical support, service, or to inquire about replacement parts, please contact Daewoo customer service through the contact information provided on your warranty card or the official Daewoo website. When contacting support, please have your model number (DJE-5659) and purchase date available.

