Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- > Sony /
- > Sony HT-S350 2.1ch Soundbar System with Wireless Subwoofer Instruction Manual

Sony HTS350

Sony HT-S350 2.1ch Soundbar System with Wireless Subwoofer Instruction Manual

Model: HTS350

NTRODUCTION

This manual provides essential information for the safe and efficient use of your Sony HT-S350 2.1ch Soundbar System. Please read it thoroughly before operating the product and retain it for future reference.

The Sony HT-S350 system enhances your audio experience with a 2.1 channel soundbar and a powerful wireless subwoofer, delivering 320W total output. It features HDMI ARC for simplified connectivity and S-Force Pro Front Surround technology for an immersive soundstage.

WHAT'S IN THE BOX

- Soundbar Unit
- Wireless Subwoofer
- Remote Commander (RMT-AH500U)
- Batteries for Remote Commander (2 AAA)
- Optical Cable
- · Wall Mount Template

SETUP

1. Placement

Place the soundbar centrally below your TV. The wireless subwoofer can be placed anywhere in the room where a power outlet is available, ideally near the soundbar for optimal bass integration.




Image: Sony HT-S350 Soundbar and Wireless Subwoofer positioned in a living room setup.

2. Connections

Connect the soundbar to your TV using one of the following methods:

HDMI ARC (Recommended)

For optimal audio and control, connect an HDMI cable (not included) from the HDMI OUT (TV (ARC)) port on the soundbar to the HDMI ARC port on your TV. This allows for one-cable audio and control synchronization.



Image: Close-up of the soundbar's rear panel, highlighting the HDMI OUT (TV (ARC)) and TV IN (OPTICAL) ports.

Optical Cable

If your TV does not support HDMI ARC, connect the supplied optical cable from the TV IN (OPTICAL) port on the soundbar to the optical digital output port on your TV.

3. Power On

Plug the soundbar and wireless subwoofer into separate AC outlets. The subwoofer will automatically pair with the soundbar upon powering on.

OPERATING INSTRUCTIONS

Remote Control Functions

Use the supplied Remote Commander (RMT-AH500U) to control various settings:

- Power (TV/Soundbar): Turns the TV and soundbar on/off.
- Bluetooth: Activates Bluetooth pairing mode.
- Cinema: Optimizes sound for movies.
- Auto Sound: Automatically adjusts sound settings based on content.
- Music: Enhances audio for music playback.

- Voice: Isolates and amplifies voices for clearer dialogue.
- Night: Adjusts sound for late-night listening.
- SW +/-: Adjusts subwoofer volume level.
- Audio: Selects audio input.
- Game: Optimizes sound for gaming.
- News: Enhances dialogue clarity for news programs.
- Sports: Optimizes sound for sports broadcasts.
- Standard: Provides a balanced sound profile.
- Secure Link Indicators: Displays connection status.

Bluetooth Streaming

To stream audio from your smartphone or tablet:

- 1. Press the Bluetooth button on the remote or soundbar to enter pairing mode.
- 2. On your mobile device, search for and select "HT-S350" from the list of available Bluetooth devices.
- 3. Once paired, audio from your device will play through the soundbar system.

Your browser does not support the video tag.

Video: Official Sony Electronics overview of the HT-S350 Soundbar with Wireless Subwoofer, demonstrating its features and connectivity options.

MAINTENANCE

To ensure the longevity and optimal performance of your soundbar system:

- · Keep the units clean by wiping them with a soft, dry cloth. Avoid using abrasive cleaners or solvents.
- Ensure proper ventilation around both the soundbar and subwoofer to prevent overheating.
- Protect the units from direct sunlight, extreme temperatures, and moisture.

TROUBLESHOOTING

No Sound

- Check that both the soundbar and TV are powered on.
- Verify that the correct input source is selected on the soundbar (e.g., TV, Bluetooth).
- Ensure all cables (HDMI, Optical) are securely connected.
- If using HDMI ARC, confirm that ARC is enabled in your TV's audio settings.

Subwoofer Not Connecting

- Ensure the subwoofer is plugged into a working power outlet.
- The subwoofer should automatically pair. If not, refer to the full user manual for manual pairing instructions.
- Check for any obstructions or interference between the soundbar and subwoofer.

Poor Bluetooth Connection

- Ensure your Bluetooth device is within range (typically 10 meters) of the soundbar.
- Avoid placing the soundbar near other wireless devices that may cause interference.
- · Try unpairing and re-pairing your device.

SPECIFICATIONS

Feature	Detail
Model Name	HTS350
Speaker Type	Soundbar
Surround Sound Channel Configuration	2.1
Speaker Maximum Output Power	320 Watts
Subwoofer Diameter	6.3 Inches
Wireless Communication Technology	Bluetooth
Connectivity Technology	Wired, Wireless (HDMI ARC, Optical, Bluetooth)
Product Dimensions	3.5"D x 35.5"W x 2.62"H
Item Weight	22.5 Pounds (Total System)
Included Components	Remote Commander, Batteries, Optical Cable, Wall Mount Template

WARRANTY AND SUPPORT

This product comes with a limited warranty. For detailed warranty information, please refer to the warranty card included in the product packaging or visit the official Sony support website.

For further assistance, troubleshooting, or product inquiries, please visit the Sony Store on Amazon or contact Sony customer support.

© 2025 Sony Corporation. All rights reserved.

Related Documents - HTS350



Sony HT-S350 Sound Bar: Operating Instructions and User Guide

Get the most out of your Sony HT-S350 Sound Bar with this official operating manual. Learn about setup, connecting devices via HDMI and Bluetooth, adjusting sound settings, troubleshooting common problems, and important safety information.



Sony HT-ZF9 Soundbar Startup Guide and Connection Instructions

Get started with your Sony HT-ZF9 soundbar. This guide covers unboxing, connecting to your TV and other devices via HDMI or optical, initial setup, listening to audio, and basic troubleshooting.



Sony HT-S350 Sound Bar Operating Instructions

Comprehensive operating instructions for the Sony HT-S350 Sound Bar, covering setup, connections, features, and troubleshooting. Learn how to enhance your audio experience with this 2.1 channel soundbar and wireless subwoofer.



Sony HT-SD40 Sound Bar Setup Guide

Quick start guide for setting up your Sony HT-SD40 sound bar. Learn how to connect to your TV via HDMI ARC or optical cable, connect power, and adjust audio settings for an enhanced home theater experience.



Sony HT-S350 Sound Bar: Operating Instructions and User Guide

Comprehensive operating instructions and user guide for the Sony HT-S350 Sound Bar, covering setup, connectivity (Bluetooth, HDMI), remote control functions, sound modes, wall mounting, troubleshooting, and technical specifications.



Sony BRAVIA Theatre Bar 6 Soundbar Help Guide

Comprehensive help guide for the Sony BRAVIA Theatre Bar 6 soundbar, covering setup, operation, connectivity, and troubleshooting. Learn how to use the BRAVIA Connect app for enhanced control and features.