

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Sig Sauer](#) /

› [Sig Sauer Lens Cleaning Kit SOLCK1 User Manual](#)

Sig Sauer SOLCK1

Sig Sauer Lens Cleaning Kit

MODEL: SOLCK1

Brand: Sig Sauer

Introduction

The Sig Sauer Lens Cleaning Kit is an essential accessory designed to maintain the clarity and performance of your electro-optics, including scopes and binoculars. This compact and lightweight tool provides a reliable solution for keeping your lenses free from dust, debris, and stubborn grime, ensuring optimal visual quality.

Product Components

- **Retractable Lens Brush:** For gently sweeping away loose dust and debris.
- **Carbon Cleaning Tip:** For removing fingerprints, smudges, and more stubborn marks.
- **Protective Caps:** To keep both the brush and cleaning tip clean when not in use.



Figure 1: Sig Sauer Lens Cleaning Kit with the retractable brush extended.

Operating Instructions

Step 1: Remove Loose Debris with the Retractable Brush

1. Gently slide the orange button on the side of the pen to extend the soft, retractable brush.
2. Hold your optic with the lens facing downwards to allow gravity to assist in debris removal.
3. Lightly brush the lens surface in a circular motion, starting from the center and moving outwards. This action removes loose dust, dirt, and other particles without scratching the lens.
4. Retract the brush by sliding the orange button back into its original position to protect the bristles.



Figure 2: The cleaning kit with the retractable brush safely stored.

Step 2: Clean Stubborn Marks with the Carbon Cleaning Tip

1. Remove the protective cap from the carbon cleaning tip located at the opposite end of the pen.
2. Gently rub the carbon cleaning tip onto the lens surface using small, overlapping circular motions. The unique carbon compound is designed to absorb fingerprints, smudges, and oil without the need for liquid cleaning solutions.
3. Continue rubbing until the smudges are completely removed and the lens is clear.
4. Replace the protective cap on the carbon cleaning tip after use to prevent contamination and ensure its longevity.

Maintenance

- **Brush Care:** The retractable brush is self-cleaning when retracted. Avoid touching the bristles with your fingers to prevent transferring oils.
- **Carbon Tip Care:** The carbon cleaning tip recharges itself when the cap is replaced. Twist the cap on and off a few times to refresh the cleaning compound. Do not use any liquids on the carbon tip.
- **Storage:** Store the cleaning kit in its original storage case or a clean, dry place to protect it from dust and damage.

Troubleshooting

- **Smudges persist after using carbon tip:** Ensure the carbon tip is clean and dry. Re-cap and twist to refresh the tip. Apply gentle, consistent pressure.
- **Brush not removing all debris:** For larger or sticky debris, use a can of compressed air (specifically for optics) before using the brush to avoid scratching.

Specifications

Feature	Detail
Brand	Sig Sauer
Model Name	Lens Cleaning Kit w/ Retractable Lens Brush and Cleaning Tip for Electro-Optics
Model Number	SOLCK1
Color	Black
Material	Nylon
Item Dimensions (LxWxH)	1.6 x 3.5 x 1 inches
Package Weight	0.03 Kilograms
UPC	798681597253



Figure 3: Product packaging for the Sig Sauer Lens Cleaning Kit.

Warranty and Support

For warranty information or technical support, please refer to the official Sig Sauer website or contact their customer service directly. Keep your purchase receipt for any warranty claims.

