

Time2 Oscar 2

Time2 Oscar 2 Twin Pack Outdoor Security Camera Instruction Manual

Model: Oscar 2 | Brand: Time2

[Introduction](#) [What's in the Box](#) [Product Features](#) [Setup](#) [Operating](#) [Maintenance](#)
[Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your Time2 Oscar 2 Twin Pack Outdoor Security Cameras. The Oscar 2 cameras are designed for outdoor surveillance, offering 1080p Full HD video, night vision, motion and sound detection, and two-way audio communication. Please read this manual thoroughly before using the product to ensure proper setup and functionality.

2. WHAT'S IN THE BOX

Upon unpacking, please verify that all the following items are included:

- 2 x Time2 Oscar WiFi Camera
- 2 x Power Adapter
- 2 x Wall Mounting Kit (screws and wall plugs)
- 1 x Quick Start Guide



Image: The Time2 Oscar 2 camera shown with its retail packaging, indicating the contents of the box.

3. PRODUCT FEATURES

The Time2 Oscar 2 cameras are equipped with advanced features for comprehensive outdoor security:

- **1080p Full HD Video:** Captures clear and detailed footage day and night.
- **Superior Night Vision:** Automatic infrared night vision with IR cut for clear images in low light or darkness.
- **100° Field of View:** Provides a wide coverage area for monitoring your property.
- **Motion and Audio Detection:** Advanced sensors detect unusual movement or sounds, sending instant alerts.
- **Two-Way Audio:** Built-in microphone and speaker allow for real-time communication.
- **Local & Cloud Storage:** Supports local storage via MicroSD card (up to 128GB, not included) and optional cloud storage via CLAN CLOUD subscription.
- **Weatherproof Design:** IP65 rated for outdoor use, resistant to rain and dust.
- **Mains Powered:** Ensures continuous operation without battery recharging.
- **Activity Zones:** Customize detection areas to reduce false alerts.
- **Alexa Integration:** Compatible with Amazon Alexa for voice control.

Product **Features**



1080 HD Video Footage



Superior Night Vision



100° Field of View



Motion/Audio Detection



2-Way Audio



Local & Cloud Storage

Image: An illustration highlighting the main features of the Oscar 2 camera, including 1080p HD video, night vision, 100° field of view, motion/audio detection, two-way audio, and storage options.

4. SETUP

4.1 App Download and Account Creation

1. Download the "CLAN" app from your smartphone's app store (iOS or Android).
2. Open the app and follow the on-screen instructions to create a new account or log in if you already have one.

4.2 MicroSD Card Installation (Optional)

For local video storage, you can install a MicroSD card (up to 128GB, not included) into the camera.

1. Locate the MicroSD card slot on the camera (refer to the Quick Start Guide for exact location).
2. Carefully insert the MicroSD card into the slot until it clicks into place.
3. Ensure the camera is powered off before inserting or removing the MicroSD card.

4.3 Camera Installation and Power Connection

The Oscar 2 cameras are designed for wall mounting and require a mains power connection.

1. **Choose a Location:** Select an outdoor location that provides the desired viewing angle and is within reach of a power outlet. Consider the 100° field of view.
2. **Mount the Camera:** Use the provided wall mounting kit (screws and wall plugs) to securely attach the camera to a wall or suitable surface. The camera housing allows for rotation to adjust the lens angle.
3. **Connect Power:** Plug the power adapter into the camera and then into a mains power outlet. The camera will power on automatically.

4.4 Pairing with the CLAN App


1. Ensure your smartphone is connected to a 2.4GHz Wi-Fi network (5GHz networks are not supported).
2. Open the CLAN app and tap the "+" icon to add a new device.
3. Select "Oscar 2" from the list of devices.
4. Follow the in-app instructions, which typically involve scanning a QR code displayed on your phone with the camera lens or listening for a sound prompt.
5. Once paired, you can name your camera and begin configuring settings.

5. OPERATING YOUR OSCAR 2 CAMERA

5.1 Live View and Monitoring

From the CLAN app home screen, tap on your camera's name to access the live video feed. You can view multiple cameras simultaneously if you have more than one Oscar 2 device.

Never Miss A Moment



Secure Cloud & Local Storage

Save and playback recorded footage with Time2 Cloud Storage or by using a MicroSD card (up to 128GB).

Image: A smartphone displaying the CLAN app interface, showing a live view from the Oscar 2 camera and various control options.

5.2 Motion and Sound Detection

The Oscar 2 camera can detect movement and sound, sending instant alerts to your smartphone or tablet.

- **Enable Alerts:** Navigate to the camera settings in the CLAN app and enable motion and sound detection alerts.
- **Adjust Sensitivity:** You can adjust the sensitivity level of both motion and sound detection to minimize false alarms.
- **Set Activity Zones:** Define specific areas within the camera's field of view where you want motion detection to be active. This helps focus on critical areas and ignore irrelevant movements.

5.3 Two-Way Audio

Utilize the built-in microphone and speaker for two-way communication.

1. While in live view, tap the microphone icon in the app to speak through the camera's speaker.
2. Tap the speaker icon to listen to audio from the camera's microphone.
3. This feature is useful for interacting with visitors or deterring intruders.



Motion Detection & 2-Way Audio Built-in Speaker & Microphone




Image: An illustration demonstrating the two-way audio feature, showing a user communicating with a delivery person via the Oscar 2 camera and smartphone app.

5.4 Recording and Playback

The Oscar 2 cameras offer flexible recording options:

- **Continuous Recording:** If a MicroSD card is installed, the camera can record continuously for up to 21 days (with a 128GB card).
- **Motion-Activated Recording:** The camera can be set to record only when motion or sound is detected. Recordings include 5 seconds of pre-event footage.
- **Local Storage (MicroSD):** Access recorded footage directly from the MicroSD card via the CLAN app.
- **Cloud Storage (CLAN CLOUD):** Subscribe to CLAN CLOUD for secure off-site storage of your recordings, accessible from anywhere.
- **Playback:** Use the playback feature in the CLAN app to review recorded events.

5.5 Night Vision

The camera automatically switches to infrared night vision in low-light conditions, providing clear black and white images. The integrated IR cut filter ensures accurate color representation during the day.

24/7 Home Security

The outdoor security camera captures both **continuous recordings** and **motion-activated recordings** - it's your choice




Image: A visual representation of the camera's 24/7 monitoring capability, showing how the view changes from morning (color) to afternoon (color) to night (infrared night vision).

5.6 Alexa Integration

The Oscar 2 cameras are compatible with Amazon Alexa. To enable this feature, link your CLAN account within the Alexa app. You can then use voice commands to view your camera feed on compatible Alexa-enabled devices.

6. MAINTENANCE

- **Cleaning:** Periodically clean the camera lens with a soft, damp cloth to ensure optimal image clarity. Do not use harsh chemicals or abrasive materials.
- **Firmware Updates:** Ensure your camera's firmware is up to date. The CLAN app will typically notify you of available updates. Follow the in-app instructions to perform updates, which can improve performance and add new features.
- **Power Cycle:** If the camera experiences issues, try power cycling it by unplugging it from the power source for a few seconds and then plugging it back in.

7. TROUBLESHOOTING

- **Camera Not Connecting to Wi-Fi:**
 - Ensure your Wi-Fi network is 2.4GHz. The camera does not support 5GHz networks.

- Check that the camera is within range of your Wi-Fi router.
- Verify your Wi-Fi password is entered correctly in the app.
- Restart your router and the camera.

- **Frequent Motion Detection Alerts:**

- Adjust the motion detection sensitivity settings in the CLAN app to a lower level.
- Define specific activity zones to exclude areas with frequent irrelevant movement (e.g., trees swaying, busy roads).
- Environmental factors like heavy rain or snow can sometimes trigger alerts; consider adjusting sensitivity during adverse weather.

- **Poor Image Quality:**

- Clean the camera lens to remove any dirt or smudges.
- Ensure there are no obstructions in the camera's field of view.
- Check your internet connection speed; a slow connection can affect live stream quality.

- **Two-Way Audio Issues:**

- Ensure your phone's volume is up and the app has microphone permissions.
- Check the camera's speaker and microphone settings in the app.
- Minimize background noise for clearer communication.

- **Recordings Not Saving:**

- If using a MicroSD card, ensure it is correctly inserted and formatted within the app. Check if the card is full.
- If using cloud storage, verify your CLAN CLOUD subscription is active.

8. SPECIFICATIONS

Feature	Detail
Model Name	Oscar 2
Product Dimensions	8.9 x 17.8 x 19.1 cm
Weight	720 grams
Manufacturer	Time2
Connectivity Technology	Wireless (Wi-Fi)
Special Feature	Motion and Sound Alerts
Indoor/Outdoor Use	Outdoor
Compatible Devices	Computer, Smartphone, Tablet
Power Source	Electric Cable (Mains Powered)
Controller Type	Amazon Alexa
Mounting Type	Wall Mount
Color	White
Form Factor	Bullet
Water Resistance Level	Waterproof (IP65)
Voltage	12 Volts
Wattage	5 Watts
Video Capture Format	MP4
Effective Video Resolution	1080 Pixels (1080p)
Viewing Angle	100 Degrees
Number of Items	2 (Twin Pack)
UPC	045912296356

9. WARRANTY AND SUPPORT

9.1 Warranty Information

Your Time2 Oscar 2 cameras come with a manufacturer's warranty. Please refer to the warranty card included in your product packaging or visit the official Time2 website for detailed warranty terms and conditions.

9.2 Customer Support

If you encounter any issues or have questions not covered in this manual, please contact Time2 customer support. Contact details can typically be found on the Time2 website or in the Quick Start Guide provided with your product. For the latest information, FAQs, and support resources, please visit the official Time2 website.

