

[Manuals.plus](#) /

› [Hot Octopuss](#) /

› Hot Octopuss JETT Hands-Free Male Masturbator Instruction Manual

Hot Octopuss HO14

Hot Octopuss JETT Hands-Free Male Masturbator

INSTRUCTION MANUAL

Introduction

The Hot Octopuss JETT is an innovative hands-free male masturbator designed to provide intense sensations. It features dual bullet vibrators with Treble & Bass technology, offering multiple intensity combinations and pulse patterns. This manual will guide you through the proper setup, operation, maintenance, and troubleshooting of your JETT device.

Key Features:

- 100% Hands-Free Operation: Designed to be worn against the frenulum for continuous stimulation.
- Dual Bullet Vibrators: Incorporates Treble (high-frequency) and Bass (deep, rumble) sensations.
- Multiple Settings: Offers 5 Treble levels, 5 Bass settings, and 5 pulse patterns for customizable pleasure.
- Premium Silicone Sleeve: Flexible and body-safe, designed to fit comfortably.
- Battery-Powered: Cordless design for portable and discreet use.

Package Contents

Upon opening your Hot Octopuss JETT package, please ensure all components are present and undamaged. The package should contain:

- 1 x JETT Remote Control Unit
- 1 x Flexible Silicone Sleeve
- 2 x Dual Bullet Vibrators (connected to the remote)
- Instruction Manual

SATISFACTION GUARANTEED



Easy to use



Flexible and comfortable



5 powerful vibration settings

Image: Hot Octopuss JETT components, showing the remote, dual bullet vibrators, and the silicone sleeve.

Setup

1. Battery Installation

The JETT remote control requires 1 Lithium Ion battery. To install:

1. Locate the battery compartment on the back of the remote control.
2. Gently slide open the battery cover.
3. Insert the Lithium Ion battery, ensuring correct polarity (+/-).
4. Close the battery cover securely.

2. Assembly of Vibrators and Sleeve

The JETT is designed for easy assembly:

1. Take the flexible silicone sleeve.

2. Carefully insert each bullet vibrator into the designated openings in the silicone sleeve. Ensure they are seated firmly.
3. Connect the vibrator cables to the corresponding ports on the JETT remote control.

6 INTENSE SPEEDS



Image: Assembly process of the JETT, illustrating how the bullet vibrators fit into the silicone sleeve.

Operating Instructions

1. Power On/Off

To power on the JETT, press and hold the central power button on the remote control until the device activates. To power off, press and hold the same button until the vibrations cease.

2. Understanding the Controls

The JETT remote control features intuitive buttons for adjusting your experience:

- **'+' / '-' Buttons (Top):** Control the intensity of the Treble vibrations.

- **'+' / '-' Buttons (Bottom):** Control the intensity of the Bass vibrations.
- **Central Button:** Cycles through the 5 distinct pulse patterns.

HANDS-FREE PLEASURE



Experience pleasure without manual
intervention, enhancing overall
satisfaction and immersion



Image: Close-up of the JETT remote control, highlighting the various control buttons for intensity and patterns.

3. Usage and Application

The JETT is designed for hands-free use. Position the silicone sleeve with the bullet vibrators against the frenulum area. The flexible design allows for comfortable wear whether flaccid or erect. Experiment with the Treble and Bass settings, individually or combined, and cycle through the pulse patterns to find your preferred sensation.

AS SEEN IN

VOGUE

VICE

GQ

BuzzFeed

WIRED

Men'sHealth

Red

The New York Times

GLAMOUR

Mashable

PLAYBOY

marie claire

Image: The Hot Octopuss JETT being worn, illustrating its hands-free application.

4. Official Product Videos

Your browser does not support the video tag.

Video: Official product video demonstrating the Hot Octopuss JETT's hands-free operation and features.

Your browser does not support the video tag.

Video: An introductory video to the Hot Octopuss JETT, explaining its unique Treble and Bass technology.

Maintenance

1. Cleaning

To ensure hygiene and longevity of your JETT, clean it after each use:

- Remove the silicone sleeve from the bullet vibrators.

- Wash the silicone sleeve with warm water and a mild, toy-safe soap. Rinse thoroughly.
- Wipe the bullet vibrators and remote control with a damp cloth and a toy-safe cleaner. Do not submerge the remote or vibrators in water.
- Allow all components to air dry completely before reassembly or storage.

2. Storage

Store your JETT in a clean, dry place away from direct sunlight and extreme temperatures. Keep it separate from other toys made of different materials to prevent material degradation.

Troubleshooting

If you encounter any issues with your Hot Octopuss JETT, please refer to the following common solutions:

Problem	Possible Cause	Solution
Device does not turn on or stops working.	Low or depleted battery. Incorrect battery installation. Loose connection.	Replace the battery with a fresh Lithium Ion battery. Ensure the battery is inserted with correct polarity. Check that the vibrator cables are securely plugged into the remote.
Vibrations are weak or inconsistent.	Low battery. Loose connection.	Replace the battery. Ensure all connections are firm.
Remote control buttons are unresponsive.	Battery issue. Internal fault.	Check and replace the battery. If the issue persists, contact customer support.

If these steps do not resolve the issue, please contact Hot Octopuss customer support for further assistance.

Specifications

- **Model Number:** HO14
- **Product Dimensions:** 5.9 x 5.9 x 1.97 inches
- **Weight:** 6.24 ounces
- **Battery Type:** 1 Lithium Ion battery (required)
- **Material:** Premium body-safe silicone
- **Color:** Silver/Black
- **Manufacturer:** Hot Octopuss

Warranty and Support

The Hot Octopuss JETT typically comes with a 1-year warranty from the date of purchase. This warranty covers manufacturing defects and ensures product quality. For warranty claims, technical support, or any other inquiries, please contact Hot Octopuss customer service directly through their official website or the retailer where the product was purchased. Please retain your proof of purchase for warranty validation.

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07PM34WCM>

More documents and user manuals: <https://manuals.plus/>