Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Festive Lights /
- > Festive Lights BL110WW Outdoor Festoon Lights User Manual

Festive Lights BL110WW

Festive Lights BL110WW Outdoor Festoon Lights User Manual

Model: BL110WW | Brand: Festive Lights

INTRODUCTION

This manual provides detailed instructions for the safe and efficient use of your Festive Lights BL110WW Outdoor Festoon Lights. Please read this manual thoroughly before installation and operation, and retain it for future reference.

PRODUCT OVERVIEW

The Festive Lights BL110WW is a set of battery-operated LED festoon lights designed for decorative illumination. It features 10 frosted LED bulbs on a 4.5-meter black cable, suitable for both indoor and outdoor use with an IP44 rating.



Image: The complete Festive Lights BL110WW string, showing the 10 frosted LED bulbs and the integrated battery pack.

SETUP INSTRUCTIONS

1. Battery Installation

- 1. Locate the battery compartment on the string lights.
- 2. Unscrew the cap of the battery compartment.
- 3. Insert 3 x AA batteries (not included), ensuring correct polarity (+/-).
- 4. Securely screw the cap back onto the battery compartment to ensure water resistance.



Image: Close-up of the battery compartment, showing the slot for AA batteries and the timer switch.

2. Placement and Hanging

- The lights are designed for both indoor and outdoor use, with an IP44 rating for water and dirt resistance.
- Each bulb features a practical hook for easy hanging.
- Hang the lights along pergolas, fences, walls, or other desired structures. Ensure the battery pack is positioned in a location that allows for easy access and protection from extreme weather conditions.




Image: Festive Lights BL110WW installed outdoors, strung along a wooden pergola, illuminating the area.

OPERATING INSTRUCTIONS

Power On/Off and Timer Function

The battery compartment includes a switch for controlling the lights and activating the timer function.

- **OFF:** Slide the switch to the "OFF" position to turn the lights off.
- ON: Slide the switch to the "ON" position to turn the lights on continuously.
- **TIMER:** Slide the switch to the "TIMER" position to activate the built-in timer. When the timer is active, the lights will automatically turn on for 6 hours, then turn off for 18 hours, and repeat this cycle daily.

For optimal battery life, it is recommended to use the timer function.

MAINTENANCE

- Cleaning: The lights are resistant to water and dirt (IP44 rated). To clean, gently wipe the bulbs and cable with a damp cloth. Do not immerse the battery compartment in water.
- Battery Replacement: When the lights dim or stop working, replace all 3 AA batteries with new ones, following the battery installation steps.
- **Storage:** If storing the lights for an extended period, remove the batteries to prevent leakage and corrosion. Store in a cool, dry place.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Lights do not turn on.	 Batteries are dead or incorrectly inserted. Switch is in "OFF" position. Timer is active and lights are in off cycle. 	 Replace batteries with new ones, ensuring correct polarity. Slide switch to "ON" or "TIMER". Wait for the timer cycle to turn lights on, or switch to "ON".
Lights are dim.	Batteries are low.	Replace batteries with new ones.
Lights turn off unexpectedly.	Timer function is active.	This is normal operation for the timer function (6 hours on, 18 hours off). If continuous light is desired, switch to "ON".

SPECIFICATIONS

Feature	Detail
Model Number	BL110WW
Brand	Festive Lights
Light Type	LED
Number of Lights	10
Bulb Diameter	5 cm
Total Length	4.5 m
Bulb Spacing	50 cm
Cable Color	Black
Power Source	3 x AA Batteries (not included)
Timer Function	6 hours ON / 18 hours OFF
IP Rating	IP44 (Water and dirt resistant)
Material	Plastic
Color Temperature	3000 Kelvin (Warm White)
Wattage	5 watts

Feature	Detail
Item Weight	340 g

WARRANTY AND SUPPORT

Your Festive Lights BL110WW Outdoor Festoon Lights come with a **12-month warranty** from the date of purchase. This warranty covers manufacturing defects under normal use.

For warranty claims, technical support, or any inquiries, please contact Festive Lights customer service through your retailer or visit the official Festive Lights website for contact information.



Related Documents - BL110WW

BOMECET 4	Festive Lights ConnectSelect Colour Select Rope Light User Manual User guide and instructions for Festive Lights ConnectSelect Colour Select Rope Lights, detailing setup, operation, safety warnings, and technical specifications for outdoor lighting.
Control Carlos Control Carlos	Festive Lights LED Battery Lights User Manual Instructions for safe and proper use of Festive Lights LED Battery Lights, including operation, timer function, safety precautions, and warranty information.
US LOUIS (AND LOUIS CONTROL OF THE C	Festive Lights HL133 LED Battery Lights - User Manual & Instructions Official user manual for Festive Lights HL133 LED Battery Lights. Get detailed instructions on safe operation, battery installation, timer function, warranty, and technical support for your indoor decorative lights.
US DE MENO (ANT)	Festive Lights LED Battery Lights User Manual and Safety Instructions Comprehensive guide to using Festive Lights LED Battery Lights, including safety precautions, operation instructions, warranty information, and care tips. Suitable for indoor and outdoor decorative use.
The control of the co	Festive Lights Solar Powered Lights - User Guide and Specifications Comprehensive user guide for Festive Lights Solar Powered Lights, covering setup, operation, warranty, safety, and technical specifications. Learn how to maximize your outdoor lighting experience.
LEG Marris (April LEG Marris (A	Festive Lights LED Battery Lights User Manual Comprehensive user manual for Festive Lights LED Battery Lights, covering safe usage, operation, maintenance, and warranty information. Includes instructions for indoor decorative use.