

[Manuals.plus](#) /

› [TCL](#) /

› TCL 32A325 Android Smart TV User Manual

TCL 32A325

TCL 32A325 Android Smart TV User Manual

Model: 32A325

INTRODUCTION

This manual provides detailed instructions for setting up, operating, and maintaining your TCL 32A325 Android Smart TV. Please read this manual thoroughly before using your TV to ensure proper and safe operation.

PRODUCT OVERVIEW

The TCL 32A325 is a 32-inch HD Smart LED TV powered by Android TV, offering a comprehensive entertainment experience. It features integrated Google Assistant and Chromecast, allowing for voice control and seamless content casting.



Figure 1: Front view of the TCL 32A325 Android Smart TV. This image shows the full display with the TCL logo at the bottom center and "32" HD androidtv" branding.

Key Features:

- **Voice Remote Control:** Navigate and control your TV using voice commands.
- **Integrated Google Assistant:** Access information, control smart home devices, and more with your voice.
- **Integrated Google Chromecast:** Easily cast your favorite movies, shows, apps, and games from your mobile device directly to your TV.
- **HDR10 Support:** Experience enhanced contrast and color detail.
- **Bluetooth Connectivity:** Connect wireless headphones, speakers, and other Bluetooth-enabled devices.
- **Android TV Operating System:** Access a wide range of apps and content from the Google Play Store.
- **AI TCL System:** An artificial intelligence system designed to make your TV the center of your home entertainment.

SETUP

1. Unboxing and Initial Inspection

Carefully remove the TV and all accessories from the packaging. Inspect for any signs of damage. Keep the packaging materials for future transport or service needs.

2. Attaching the Stand

Place the TV face down on a soft, flat surface to prevent screen damage. Align the TV stands with the screw holes on the bottom of the TV and secure them with the provided screws.



Figure 2: Angled front view of the TCL 32A325 TV, illustrating the TV with its two support stands attached.

3. Wall Mounting (Optional)

If you plan to wall mount your TV, refer to the wall mount bracket's instructions. Ensure proper ventilation and cable management. The TV dimensions are 73.19 cm (width) x 48.11 cm (height) x 17.25 cm (depth with stand).



Figure 3: The TCL 32A325 TV displayed mounted on a wall in a modern living room setting, showcasing its aesthetic integration.

4. Connecting Peripherals

Connect your devices (cable box, gaming console, Blu-ray player, etc.) to the appropriate ports on the back of the TV. The TV includes:

- 1 x USB Port
- 1 x Ethernet Port
- 3 x HDMI Ports (one with ARC support)
- 1 x Cable/Antenna Input
- 1 x AV In (adapter required, not included)
- 1 x Audio Out (3.5mm jack)
- 1 x Optical Audio Out






Figure 4: Detailed view of the TCL 32A325 TV's rear connectivity panel, showing ports for USB, Ethernet, HDMI (1 ARC), Cable/Antenna,

5. Power On and Initial Setup

Plug the power cord into an electrical outlet. Press the power button on the TV or remote control. Follow the on-screen instructions to complete the initial setup, including network connection, Google account login, and channel scanning.

OPERATING YOUR TV

Remote Control

The included remote control features voice command capabilities and is designed for intuitive navigation of the Android TV interface. Insert 2 AAA batteries (included) into the remote.

Android TV Interface

The Android TV home screen provides quick access to your favorite apps, live TV, and connected devices. Use the directional pad on your remote to navigate and the OK button to select.

Voice Control and Google Assistant

Press the Google Assistant button on your remote and speak into the microphone to search for content, get answers, control smart home devices, and more.

Casting Content with Chromecast

Ensure your mobile device and TV are connected to the same Wi-Fi network. Open a Chromecast-enabled app on your mobile device and tap the Cast icon (usually a rectangle with a Wi-Fi symbol) to send content to your TV.

Bluetooth Connectivity

To pair Bluetooth devices, go to *Settings > Remote & Accessories > Add accessory* on your TV. Select your device from the list and follow the pairing instructions.

MAINTENANCE

Cleaning the TV

- Always unplug the TV before cleaning.
- Use a soft, dry cloth to wipe the screen and cabinet.
- For stubborn marks, lightly dampen the cloth with water or a mild, non-abrasive screen cleaner. Do not spray cleaner directly onto the screen.
- Avoid using alcohol, benzene, thinners, or other volatile substances.

Software Updates

Your Android TV may receive automatic software updates. Ensure your TV is connected to the internet to receive these updates, which can improve performance and add new features. You can also check for updates manually in *Settings > Device Preferences > About > System update*.

TROUBLESHOOTING

If you encounter issues with your TV, refer to the following common solutions:

Problem	Possible Solution
---------	-------------------

Problem	Possible Solution
No power	Ensure the power cord is securely plugged into the TV and a working electrical outlet. Try a different outlet.
No picture, but sound is present	Check the input source. Ensure all cables are securely connected. Try restarting the TV.
No sound, but picture is present	Check the volume level and mute settings. Ensure audio cables are connected correctly. If using external speakers, check their power and connections.
Remote control not working	Check and replace batteries. Ensure there are no obstructions between the remote and the TV. Re-pair the Bluetooth remote if necessary.
Wi-Fi connection issues	Restart your router and modem. Check Wi-Fi settings on the TV. Ensure the TV is within range of your Wi-Fi router.
Apps are slow or crashing	Close unused apps. Clear app cache (<i>Settings > Apps > See all apps > [App Name] > Clear cache</i>). Restart the TV. Consider a factory reset as a last resort (<i>Settings > Device Preferences > Reset</i>).

SPECIFICATIONS

Feature	Detail
Brand	TCL
Model	32A325
Model Year	2019
Screen Size	32 Inches (82 cm visible diagonal)
Display Technology	LED
Resolution	720p (1280 x 720 pixels)
Refresh Rate	60 Hz
Operating System	Android TV
Connectivity	Built-in Wi-Fi, Bluetooth, 3x HDMI, 1x USB, Ethernet
Audio Output	Surround Sound, 2.1 Channel, 60 Watts Max Output
Image Aspect Ratio	16:9
Brightness	220 Nits
Contrast Ratio	3000:1
Viewing Angle	178 Degrees
Dimensions (with stand)	73.19 x 17.25 x 48.11 cm (W x D x H)
Weight	3.9 kg
Remote Control	Included, with Google Assistant and Bluetooth technology

Feature	Detail
Batteries	2 AAA (included)
Compatible Internet Services	Browser, Google TV, Netflix, YouTube

SUPPORT AND WARRANTY

For personalized assistance or any questions regarding your TCL TV, please contact TCL customer support:

- **Phone:** 01800-112-4656
- **WhatsApp:** 55-2317-7847
- **Email:** serviciomx@tcl.com

Please refer to the warranty card included with your product for specific warranty terms and conditions.

© 2024 TCL. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question