

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Casio](#) /

› [Casio Replacement Watch Band Model 10408444 Instruction Manual](#)

Casio 10408444

Casio Replacement Watch Band Model 10408444 Instruction Manual

For Models: WVA-M640, WVA-M650, WVQ-M410 Series

INTRODUCTION

This instruction manual provides detailed guidance for the proper installation and care of your Genuine Casio Replacement Watch Band, Model 10408444. This band is designed for specific Casio watch models, including the WVA-M640, WVA-M650, and WVQ-M410 series. Following these instructions will help ensure a secure fit and extend the lifespan of your watch band.

SETUP AND INSTALLATION

Replacing a watch band requires careful handling to avoid scratching your watch case or damaging the new band. It is recommended to use appropriate watch repair tools, such as a spring bar tool.

Tools Required:

- Spring Bar Tool (recommended)
- Small Flathead Screwdriver (alternative for spring bar tool)
- Soft Cloth (to protect watch surface)

Step-by-Step Installation:

1. **Prepare Your Workspace:** Place your watch face down on a soft cloth to prevent scratches. Ensure good lighting.

2. **Remove the Old Watch Band:**

Locate the spring bars that secure the current watch band to the watch lugs. Using a spring bar tool, gently compress one end of the spring bar and pull the band away from the watch case. Repeat for the other end of the band and for the second strap piece.



Image: The two components of the replacement watch band, showing the buckle and the strap with adjustment holes.

3. **Inspect Spring Bars:** The replacement band typically does not include new spring bars. Carefully remove the spring bars from your old band. Inspect them for bends or damage. If damaged, new spring bars of the correct size will be required.
4. **Attach Spring Bars to New Band:** Insert one end of a spring bar into the small hole on one side of the new watch band. Align the other end of the spring bar with the corresponding hole on the opposite side of the band and gently push it in until it clicks into place. Repeat for the second spring bar and the other band piece.



Image: Detail of the watch band's lug ends, indicating where the spring bars are inserted.

5. Install New Watch Band:

Take one piece of the new band with the spring bar inserted. Insert one end of the spring bar into a lug hole on the watch case. Using the spring bar tool, compress the other end of the spring bar and guide it into the opposite lug hole. Release the tool and gently tug on the band to ensure the spring bar is securely seated in both holes. Repeat this process for the second piece of the watch band.



Image: The complete replacement watch band, ready for installation onto the watch case.

6. **Final Check:** Once both band pieces are installed, gently pull on each side of the band to confirm that the spring bars are fully engaged and the band is securely attached to the watch.

MAINTENANCE

Proper care will help maintain the appearance and longevity of your Casio watch band.

- **Cleaning:** For resin or rubber bands, wipe regularly with a soft, damp cloth. For stubborn dirt, a mild soap solution can be used, followed by rinsing with clean water and thorough drying. Avoid harsh chemicals or abrasive cleaners.
- **Avoid Extreme Conditions:** Prolonged exposure to direct sunlight, high temperatures, or harsh chemicals (e.g., solvents, strong detergents) can cause the band material to degrade, discolor, or crack.
- **Storage:** When not in use, store your watch in a cool, dry place away from direct sunlight.

TROUBLESHOOTING

If you encounter issues during or after installation, consider the following:

- **Band Not Fitting:** Ensure you have the correct replacement band for your specific Casio watch model. Refer to the compatibility list in the introduction.
- **Spring Bar Not Securing:** Verify that the spring bar is correctly inserted into the band and that both ends are fully seated in the watch lug holes. Sometimes, a bent or damaged spring bar can prevent proper seating; replace if necessary.
- **Difficulty with Installation:** If you are having trouble, consider seeking assistance from a professional watch repair technician.

SPECIFICATIONS

Model Number	10408444
Compatible Watch Models	WVA-M640-1A, WVA-M640-7A, WVA-M640B-1A, WVA-M640B-1A2, WVA-M650-1A, WVA-M650-1A2, WVA-M650-2A, WVA-M650-7A, WVA-M650B-1A, WVQ-M410-1A, WVQ-M410B-1
Material	Resin / Rubber
Clasp Type	Tang Buckle (Stainless Steel)
Color	Black
Package Dimensions	5.51 x 0.78 x 0.78 inches; 0.32 ounces


WARRANTY AND SUPPORT

This product is a genuine Casio replacement part. For specific warranty information, please refer to the original warranty documentation provided with your Casio watch or contact the authorized Casio service center or the retailer from whom you purchased the band.

For further assistance or inquiries regarding this replacement band, please contact the seller or Casio customer support.

Related Documents - 10408444

	<p><u>Casio WVA-430/440/470/620 Watch User Manual (Modules 3353, 3354, 5053)</u> Comprehensive user manual for Casio watches with modules 3353, 3354, and 5053, covering models WVA-430, WVA-440, WVA-470, and WVA-620. Learn about features, operation, water resistance, and maintenance.</p>
	<p><u>Casio WVA-210/220/230 Watch User Manual</u> Comprehensive user manual for Casio WVA-210/220/230 watches (Module 4378 4379), covering battery, water resistance, care, world time, alarms, stopwatch, and technical specifications.</p>
	<p><u>Руководство пользователя часов Casio Модуль 3353, 3354, 5053</u> Подробное руководство пользователя для часов Casio с модулями 3353, 3354 и 5053, охватывающее функции, эксплуатацию и обслуживание.</p>

	<p><u>Casio Watch User Manual - Models 3353, 3354, 5053</u></p> <p>Comprehensive user manual for Casio watches with module numbers 3353, 3354, and 5053, covering general precautions, water resistance, operating modes (current time, world time, alarm, stopwatch, analog time), power source and charging, power saving mode, and technical specifications.</p>
	<p><u>Casio Watch Module 2734/2758/3748/3749/4773 User Manual</u></p> <p>Comprehensive user manual for Casio watches with modules 2734, 2758, 3748, 3749, and 4773, covering features, operation, care, and specifications. This guide provides detailed instructions for setting time, using world time, alarms, stopwatch, and other functions.</p>
	<p><u>Casio WVA-300/310 Watch User Manual - Module 2367/2739</u></p> <p>Comprehensive user manual for the Casio WVA-300/310 watch (Module 2367/2739), covering features, operation, water resistance, care, and technical specifications.</p>