

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [PREXTEX](#) /

› PREXTEX 6 ft Fully Decorated Collapsible Christmas Tree Instruction Manual

PREXTEX DS-T-200L/4FE

PREXTEX 6 ft Fully Decorated Collapsible Christmas Tree Instruction Manual

Model: DS-T-200L/4FE

INTRODUCTION

Thank you for choosing the PREXTEX 6 ft Fully Decorated Collapsible Christmas Tree. This manual provides essential information for the safe and efficient setup, operation, maintenance, and storage of your new Christmas tree. Please read these instructions carefully before assembly and retain for future reference.





Image: The PREXTEX 6 ft Fully Decorated Collapsible Christmas Tree, showcasing its pre-attached gold and red ornaments, bows, and warm lights.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly:

- 1 x Collapsible Christmas Tree (pre-decorated with lights, bows, ornaments, holly leaves, poinsettias)
- 1 x Center Pole (multiple sections)
- 1 x Tree Stand Base
- 1 x Power Adapter for Lights

Fully-decorated Christmas Tree



Bows



350 Warm Lights



Ribbons



Holly Leaves



Ornaments



Poinsettias



Image: An illustration detailing the components of the fully decorated Christmas tree, including bows, 350 warm lights, ribbons, holly leaves, ornaments, and poinsettias.

SETUP INSTRUCTIONS

1. Assemble the Base and Pole:

Carefully unfold the tree stand base and insert the pole sections, ensuring they are securely connected. The pole should be firmly seated in the base.

2. Position the Tree:

Place the assembled pole and base in your desired location. Ensure there is enough space around the tree for its full 6 ft height and 30-inch diameter.

3. Raise the Collapsible Tree:

Take the collapsed tree section. Carefully lift it and slide it down over the center pole. Gently pull the tree upwards until it fully extends and locks into place, forming its conical shape. The pre-attached decorations and lights will expand as the tree is raised.

4. Connect Power:

Locate the power cord for the pre-lit lights. Plug it into a standard electrical outlet. Ensure all connections are secure.

5. Adjust Decorations:

Once the tree is fully extended and lit, gently adjust any bows, ribbons, or ornaments to achieve your desired aesthetic. Some minor fluffing of branches may be necessary.



Image: A three-step visual guide showing how to assemble the tree: 1) Set up the pole and base, 2) Pull up the collapsed tree over the pole, and 3) Place the tree on top of the pole.

OPERATING INSTRUCTIONS

The PRETEX Collapsible Christmas Tree features integrated warm white LED lights. To operate the lights, simply plug the power adapter into a working electrical outlet. There are no additional controls for the lights; they will illuminate when powered.

This tree is designed for ease of use, providing instant holiday decor without the need for separate light stringing or extensive ornament placement.

MAINTENANCE AND STORAGE

Cleaning:

To clean the tree, gently wipe any dust or debris with a soft, dry cloth. Do not use liquid cleaners or

abrasive materials, as these may damage the decorations or lights.

Disassembly and Storage:

1. **Unplug the Lights:** Always unplug the tree from the power outlet before disassembling.
2. **Collapse the Tree:** Gently push down on the top of the tree while holding the base steady. The tree will collapse downwards, compacting the branches and decorations.
3. **Remove from Pole:** Once fully collapsed, lift the tree off the center pole.
4. **Disassemble Pole and Base:** Separate the pole sections and fold the tree stand base.
5. **Store:** Store all components in their original packaging or a suitable storage container in a cool, dry place, away from direct sunlight and extreme temperatures. The collapsible design allows for minimal storage space.

Easy Storage

Folds down for minimal storage space



Image: The PREXTEX Christmas tree shown in its collapsed, compact form, suitable for easy storage in its original box.

SAFETY INFORMATION

- This product is equipped with UL-certified lights for safety.

- Ensure the tree is placed on a stable, level surface to prevent tipping.
- Keep away from open flames, heat sources, and flammable materials.
- Do not overload electrical outlets.
- While the tree is shown in outdoor settings in some promotional images, it is primarily designed for indoor use. If used outdoors, ensure it is protected from moisture and harsh weather conditions, as prolonged exposure can damage the product and electrical components.
- Keep out of reach of small children and pets to prevent accidental damage or injury.
- Do not modify the tree or its electrical components.

Use Indoors or Outdoors



UL-certified lights

Image: The PREXTEX Christmas tree illuminated outdoors in a winter scene, highlighting its UL-certified lights. Note: For outdoor use, ensure protection from moisture.

TROUBLESHOOTING

- **Lights Not Working:**
 - Check if the power adapter is securely plugged into both the tree and the electrical outlet.
 - Verify that the electrical outlet is functional by testing it with another device.
 - Inspect the light string for any loose bulbs or damaged wires.

- **Tree Appears Unstable:**

- Ensure the tree stand base is fully unfolded and locked.
- Confirm that the center pole sections are securely connected and properly seated in the base.
- Place the tree on a flat, level surface.
- If additional stability is desired, especially in high-traffic areas or homes with pets/children, consider placing weights on the base (e.g., sandbags covered by a tree skirt) or securing the pole to a sturdy object.

- **Decorations Appear Sparse:**

- Gently adjust and fluff the branches and ribbons after setup to achieve a fuller appearance.
- The tree is designed to be fully decorated, but personal preference may lead to adding additional ornaments if desired.

SPECIFICATIONS

Feature	Detail
Brand	PREXTEX
Model Number	DS-T-200L/4FE
Product Dimensions	30"D x 30"W x 72"H (6 ft tall)
Color	Red and Green (decorations), Green (tree)
Material	Plastic
Item Weight	11.48 pounds
Special Feature	Pop Up, Prelit, Collapsible
Built-in Light	Yes (350 Warm White Lights)
Included Components	Stunning bow topper, opulent ribbons, shatterproof ornaments
UPC	850001836807

WARRANTY INFORMATION

Specific warranty details for this product are not provided in the available information. Please refer to the product packaging or contact PREXTEX customer support for warranty inquiries.

CUSTOMER SUPPORT

For further assistance, questions, or to report any issues with your PREXTEX 6 ft Fully Decorated Collapsible Christmas Tree, please contact PREXTEX customer support. Contact information can typically be found on the product packaging or the official PREXTEX website.

You may also visit the [PREXTEX Store on Amazon](#) for more information.

