

ULTREAN HF-9001TS

ULTREAN 8.5 Quart Air Fryer Model HF-9001TS Instruction Manual

Your guide to safe and efficient operation

1. IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons. Read all instructions carefully before operating the ULTREAN Air Fryer.

- Ensure the appliance is connected to a 120V AC power outlet. Do not use with voltage converters.
- Do not immerse the cord, plug, or the appliance housing in water or other liquid to prevent electric shock.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Do not place the appliance against a wall or against other appliances. Leave at least 10 cm (4 inches) free space on the back and sides and 10 cm (4 inches) free space above the appliance.
- Do not place anything on top of the appliance.
- During hot air frying, hot steam is released through the air outlet openings. Keep your hands and face at a safe distance from the steam and from the air outlet openings.
- Always ensure the basket is properly inserted before operating.
- This air fryer is for household use only.

2. PRODUCT OVERVIEW

The ULTREAN 8.5 Quart Air Fryer (Model HF-9001TS) utilizes 360-degree rapid air circulation technology to cook food with significantly less oil. It features a digital touch screen with 7 preset cooking functions and a large 8.5-quart capacity suitable for 6-8 persons.



Image 2.1: Front view of the ULTREAN 8.5 Quart Air Fryer, showcasing its sleek black design and digital control panel.

Key Features:

- **Rapid Air Frying Technology:** Ensures even cooking and crispy results with up to 80% less fat.
- **Multifunctional:** Capable of frying, roasting, grilling, and baking.
- **Large Capacity:** 8.5 quarts / 8 liters, ideal for family meals.
- **Digital Touch Screen:** Intuitive LCD display with soft-touch buttons for easy operation.
- **7 Cooking Presets:** Dedicated settings for Chips, Meat, Shrimp, Cake, Chicken, Steak, and Fish.
- **Safety Features:** Equipped with auto shut-off and overheat protection.
- **Easy to Clean:** Detachable, nonstick basket and accessories are dishwasher safe.

360° Rapid Heat Circulation

Save your time and oil. Cook food evenly for golden-brown and delicious results with the high-effective air circulation system.



Image 2.2: Diagram illustrating the 360-degree rapid heat circulation system within the air fryer, ensuring even cooking.

3. SETUP

3.1 Unpacking

1. Remove all packaging materials from the air fryer.
2. Check that all parts are present and in good condition.
3. Remove any stickers or labels from the appliance.

3.2 Initial Cleaning

1. Wash the basket and pan thoroughly with hot water, dish soap, and a non-abrasive sponge.
2. Wipe the inside and outside of the appliance with a damp cloth.
3. To reduce initial odors, preheat slices of lemon at 400°F (200°C) for 10-15 minutes before first use. Then, wash the basket and pan again.

3.3 Placement

1. Place the air fryer on a stable, horizontal, and level surface.
2. Ensure there is adequate space (at least 10 cm or 4 inches) around the appliance for proper ventilation.
3. Do not place the appliance on non-heat-resistant surfaces.

4. OPERATING INSTRUCTIONS

4.1 Control Panel



Image 4.1: Detailed view of the digital touch screen control panel, highlighting Time/Temp adjustment, Power, and Mode buttons.

- **Power Button:** Turns the appliance on/off.
- **Mode Button:** Cycles through the 7 preset cooking functions.
- **Temperature Adjustment Buttons (+/-):** Adjusts temperature from 180°F (80°C) to 400°F (200°C).
- **Time Adjustment Buttons (+/-):** Adjusts cooking time from 0 to 30 minutes.

7 in 1 Versatile Cooking Presets

Including: Chips, Meat, Shrimp, Cake, Chicken, Steak, Fish



Image 4.2: Visual representation of the 7 versatile cooking presets: Chips, Meat, Shrimp, Cake, Chicken, Steak, and Fish.

4.2 General Operation

1. Plug the power cord into a grounded wall outlet.
2. Carefully pull the basket out of the air fryer.
3. Place the ingredients into the basket. Do not exceed the MAX fill line.
4. Slide the basket back into the air fryer.
5. Press the Power button to turn on the appliance.
6. Select a preset function using the Mode button, or manually set the desired temperature and time using the +/- buttons.
7. Press the Power button again to start cooking.
8. Some ingredients require shaking halfway through the preparation time. To shake the ingredients, pull the basket out of the appliance by the handle and gently shake it. Then slide the basket back into the air fryer.
9. When the cooking time has elapsed, the appliance will automatically shut off. Carefully pull out the basket and transfer the food to a plate.

A Perfect Size for Your Big Family



Image 4.3: Step-by-step guide on how to safely pull out the basket, slide the button guard forward, and press the button to separate the basket from the pan.

Note: Cooking times and temperatures may vary depending on the size, thickness, quantity, and type of food. Always check food doneness and adjust settings as needed.

5. MAINTENANCE AND CLEANING

Clean the appliance after every use.

5.1 Cleaning the Basket and Pan

1. Allow the air fryer to cool down completely before cleaning.
2. Remove the basket from the pan by sliding the button guard forward and pressing the release button.
3. The nonstick basket and pan are dishwasher safe. Alternatively, wash them with hot water, dish soap, and a non-abrasive sponge.
4. For stubborn food residue, soak the basket and pan in warm, soapy water for approximately 30 minutes.

5.2 Cleaning the Appliance Exterior and Interior

1. Wipe the exterior of the air fryer with a damp cloth. Do not use harsh abrasive cleaners.
2. Clean the inside of the appliance with hot water and a non-abrasive sponge.
3. Clean the heating element with a cleaning brush to remove any food residue.

6. TROUBLESHOOTING

If you encounter issues with your ULTREAN Air Fryer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance is not plugged in. Power outlet is not working.	Ensure the power plug is properly inserted into a grounded wall outlet. Check if the outlet is functional by plugging in another appliance.
Food is not cooked thoroughly.	Too much food in the basket. Temperature or time setting is incorrect.	Reduce the amount of food in the basket. Increase the temperature or cooking time. Shake or flip food halfway through cooking.
White smoke comes from the appliance.	Fat residue from previous use. Excess oil on ingredients.	Clean the pan and basket thoroughly after each use. Pat dry oily ingredients before air frying.
Food is not crispy.	Ingredients not suitable for air frying. Not enough oil (for some foods).	Ensure ingredients are dry before adding to the air fryer. Lightly brush or spray some oil on foods that typically require it for crispiness.

7. SPECIFICATIONS

Specification	Detail
Brand	ULTREAN
Model Number	HF-9001TS
Color	Black
Product Dimensions	40.39 x 40.39 x 44.96 cm (15.9 x 15.9 x 17.7 inches)
Capacity	8.5 Quarts / 8 Liters
Power/Wattage	1700 Watts
Voltage	120 Volts (AC)
Material	Aluminum
Auto Shut-off	Yes
Special Features	Temperature Control

Specification	Detail
Item Weight	7.8 kg (17.2 lbs)

User Firendly Design



Nonstick Baskets are FDA-approved & PFOA-free (Kitchen gloves are included)



Pull the basket out and set them on a flat surface



Slide the button guard forward



Press the button to separate the basket







Image 7.1: Diagram showing the dimensions of the ULTREAN 8.5 Quart Air Fryer and its basket.

8. WARRANTY AND SUPPORT

The ULTREAN 8.5 Quart Air Fryer comes with a **1-Year Warranty** from the date of purchase. Additionally, ULTREAN provides **Lifetime Support** for its products.

For any product concerns, technical assistance, or warranty claims, please contact ULTREAN customer support. Customer satisfaction is a priority.

Please refer to the contact information provided in your product packaging or visit the official ULTREAN website for support details.

<p>ULTREAN Air Fryer</p>  <p>Email: support@ultrean.com</p>	<p>Ultrean Air Fryer User Manual</p> <p>Comprehensive user manual for the Ultrean Air Fryer, detailing setup, operation, safety precautions, cleaning, and troubleshooting for optimal use.</p>
<p>ULTREAN Air Fryer</p>  <p>Email: support@ultrean.com</p>	<p>Ultrean Air Fryer User Manual: Operation, Settings, and Troubleshooting</p> <p>Comprehensive user manual for the Ultrean Air Fryer, covering important safety instructions, general description, operating procedures, cooking settings, cleaning, storage, troubleshooting, and environmental guidelines.</p>
<p>ULTREAN Air Fryer</p>  <p>Email: support@ultrean.com</p>	<p>Ultrean AF0302 Air Fryer User Manual and Operating Guide</p> <p>Comprehensive user manual for the Ultrean AF0302 Air Fryer, covering essential safety precautions, detailed operating instructions for the touchscreen interface, time and temperature adjustments, and preparation tips for various cooking tasks. Learn how to use preset menus and ensure optimal results.</p>
<p>PowerXL VORTEX AIR FRYER</p>  <p>Owner's Manual</p>	<p>PowerXL Vortex Air Fryer Owner's Manual: Safety, Operation, and Cooking Guide</p> <p>Comprehensive owner's manual for the PowerXL Vortex Air Fryer, covering safety precautions, parts, operation, troubleshooting, and cooking guidelines for models HF-2096TS, HF-5096TS, HF-8096TS, and HF-1096TS.</p>
<p>PowerXL CLASSIC AIR FRYER</p>  <p>Owner's Manual</p>	<p>PowerXL Classic Air Fryer Owner's Manual & Operating Guide</p> <p>Comprehensive owner's manual for the PowerXL Classic Air Fryer, covering safety instructions, operating procedures, cooking guidelines, troubleshooting, and warranty information for models HF-509DT, HF-8959DT, and HF-196DT.</p>
<p>PowerXL VORTEX AIR FRYER</p>  <p>Owner's Manual</p>	<p>PowerXL Vortex Air Fryer Owner's Manual & Instructions</p> <p>Comprehensive owner's manual for the PowerXL Vortex Air Fryer, covering safety precautions, specifications, usage instructions, cooking guidelines, troubleshooting, and warranty information for models HF-2096DT-P, HF-5096DT-P, HF-8096DT-P, and HF-1096DT-P.</p>

