

## Frigidaire EFR372-PINK

# Frigidaire EFR372-PINK Retro Compact Refrigerator User Manual

Model: EFR372-PINK

## 1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your Frigidaire EFR372-PINK Retro Compact Refrigerator. Please read these instructions thoroughly before installation and use, and retain them for future reference.

The Frigidaire EFR372-PINK is a 3.2 cubic foot compact refrigerator featuring a retro design, internal chiller compartment, and a built-in bottle opener. It is designed for convenient food and beverage storage in various settings such as offices, bedrooms, dorm rooms, and cabins.

## 2. SAFETY INFORMATION

**WARNING: To reduce the risk of fire, electric shock, or injury when using your appliance, follow these basic precautions:**

- Read all instructions before using the refrigerator.
- Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.
- Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- Do not damage the refrigerant circuit.
- Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- **Proposition 65 Warning:** This product can expose you to chemicals which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to

### 3. PRODUCT OVERVIEW

The Frigidaire EFR372-PINK compact refrigerator offers efficient cooling and convenient storage in a stylish retro design. Key features include:

- 3.2 cubic feet storage capacity
- Internal chiller compartment
- Adjustable thermostat control
- Two removable glass shelves
- Door storage for 2-liter bottles and cans
- Built-in bottle opener
- Reversible door hinge for flexible placement
- Space-saving flush back design





*Figure 1: Front view of the Frigidaire EFR372-PINK Retro Compact Refrigerator.*

# Compact Yet Spacious

3.2 CU. FT. STORAGE CAPACITY



*Figure 2: Interior view displaying the chiller compartment, adjustable glass shelves, and door storage.*

## 4. SETUP AND INSTALLATION

### 4.1 Unpacking

1. Remove all packaging materials, including the foam base and adhesive tape holding accessories.
2. Inspect the refrigerator for any shipping damage. Report any damage immediately to the retailer.
3. Clean the interior and exterior surfaces with a soft cloth and mild detergent before use.

### 4.2 Placement

- Place the refrigerator on a firm, level surface to prevent vibrations and ensure proper operation.
- Allow at least 5 inches (12.7 cm) of space between the back and sides of the refrigerator and any adjacent walls to ensure proper air circulation.
- Avoid placing the unit in direct sunlight or near heat sources (e.g., stoves, heaters).
- This appliance is designed for freestanding installation only and should not be recessed or built-in.

### 4.3 Electrical Connection

- Ensure the voltage and frequency of your power supply match the ratings on the appliance's rating label (110 Volts).
- Plug the refrigerator into a dedicated, properly grounded wall outlet. Do not use extension cords or adapter plugs.

### 4.4 Door Reversal (Optional)

The door hinge is reversible, allowing you to change the door swing direction to suit your space. Refer to the detailed diagrams in the full manual for specific steps. This process typically involves:

1. Unplugging the unit.
2. Removing the top hinge cover and screws.
3. Lifting the door off the bottom hinge.
4. Removing the bottom hinge and transferring it to the opposite side.
5. Reattaching the door and top hinge on the new side.

## 5. OPERATING INSTRUCTIONS

### 5.1 Initial Start-up

After plugging in the refrigerator, allow it to operate for 2-3 hours before placing food inside. This allows the interior to reach the desired temperature.

### 5.2 Temperature Control

The refrigerator features an adjustable thermostat control knob located inside the unit, typically near the chiller compartment. Settings range from 'Min' (warmest) to 'Max' (coldest). Adjust the knob to your desired cooling level. A setting of 'Mid' is often suitable for general use.

# Efficient Organization

This small fridge provides organized storage for your drinks and snacks



Figure 3: Interior organization with adjustable temperature control dial visible.

## 5.3 Food Storage

- Utilize the two adjustable glass shelves for flexible storage of various items.
- The door basket is designed to hold 2-liter bottles and canned beverages.
- The chiller compartment is suitable for items requiring colder temperatures, such as ice trays or small frozen goods.

## 6. MAINTENANCE

### 6.1 Defrosting

This refrigerator features manual defrost. Frost will accumulate on the chiller compartment walls. When the frost layer becomes about 1/4 inch (6 mm) thick, defrost the unit:

1. Turn the thermostat to the 'OFF' position and unplug the refrigerator.
2. Remove all food items and place them in another cooler.

3. Leave the door open to allow frost to melt. Place a towel at the bottom to absorb water.
4. Do not use sharp objects or heating devices to remove frost, as this can damage the cooling system.
5. Once defrosted, clean and dry the interior thoroughly before plugging the unit back in and returning food.

## 6.2 Cleaning

- Always unplug the refrigerator before cleaning.
- Wash the interior with a mild detergent and warm water solution. Rinse and dry thoroughly.
- Clean the exterior with a soft cloth and mild detergent. Avoid abrasive cleaners or solvents.
- The removable glass shelves can be washed with soap and water.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Refrigerator does not operate.	Not plugged in; circuit breaker tripped; temperature control set to 'OFF'.	Ensure plug is secure; reset circuit breaker; set temperature control to a desired setting.
Temperature is too warm.	Door opened too frequently; large amount of warm food added; poor ventilation; thermostat setting too high.	Minimize door openings; allow warm food to cool before storing; ensure adequate clearance around unit; adjust thermostat to a colder setting.
Temperature is too cold.	Thermostat setting too low.	Adjust thermostat to a warmer setting.
Excessive frost buildup.	Door not sealed properly; high humidity; frequent door openings.	Check door gasket for proper seal; avoid opening door unnecessarily; defrost as per instructions.
Unusual noises.	Unit not level; objects vibrating against the unit; normal compressor operation.	Ensure unit is level; move objects away from the unit; some operational sounds are normal.

## 8. SPECIFICATIONS



Frigidaire is a pending or registered trademark of Electrolux Home Products and used under license from Electrolux Home Products, Inc.

Figure 4: Product dimensions for planning placement.

Feature	Detail
Model Number	EFR372-PINK
Capacity	3.2 Cubic Feet (Fresh Food: 3.2 cu ft, Freezer: 0.2 cu ft)
Dimensions (D x W x H)	18.5" x 21" x 31.5" (47 cm x 53.3 cm x 80 cm)
Item Weight	49 Pounds (22.2 kg)
Voltage	110 Volts
Annual Energy Consumption	222 Kilowatt Hours Per Year
Defrost System	Manual
Door Hinges	Reversible

Feature	Detail
Shelf Type	Glass (2 shelves)
Material Type	Metal, Plastic

## 9. WARRANTY AND SUPPORT

Frigidaire products are manufactured to high-quality standards and are backed by a limited warranty. For specific warranty details, including coverage period and terms, please refer to the warranty card included with your product or visit the official Frigidaire website.

For technical assistance, troubleshooting beyond this manual, or to inquire about replacement parts, please contact Frigidaire customer support. Contact information can typically be found on the manufacturer's website or on the product's packaging.

Please have your model number (EFR372-PINK) and serial number ready when contacting support.