Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

B Bubos B07PPVKBQV

Bubos Baby Food Processor Steamer

Model: B07PPVKBQV

Important Safety Instructions

Please read all instructions carefully before using the Bubos Baby Food Processor Steamer. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always ensure the appliance is unplugged before assembly, disassembly, or cleaning.
- Do not immerse the motor unit in water or any other liquid. Clean with a damp cloth only.
- Keep hands and utensils away from the moving blade during operation to prevent injury.
- Do not operate the appliance if the cord or plug is damaged, or if the appliance malfunctions or has been dropped or damaged in any manner.
- Use only manufacturer-recommended attachments.
- This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Close supervision is necessary when any appliance is used by or near children.
- Always operate the appliance on a flat, stable surface.
- Exercise caution when handling sharp blades and hot steam.
- The appliance features an auto shut-off function when the water tank is empty to prevent overheating.
- This product is BPA-free.

Product Overview

The Bubos Baby Food Processor Steamer is a versatile 6-in-1 appliance designed to simplify baby food preparation. It combines steaming, blending, warming, sterilizing, chopping, and pureeing functions into one compact unit.

Key Features:

- **6-in-1 Functionality:** Steam, Warm, Blend, Puree, Chop, Sterilize.
- **Open Water Reservoir:** Designed for easy cleaning and to prevent mold or rust buildup.
- **Built-in Timer:** Allows for precise cooking and automatic shut-off.
- **BPA-Free Materials:** Ensures safe food preparation for your baby.
- **Compact Design:** Saves counter space.

Components:

Familiarize yourself with the parts of your Bubos Baby Food Processor Steamer:



Image: Exploded view showing the main unit, blending jar, steaming basket, lid, and blade assembly.

- **Main Unit:** Contains the motor, water reservoir, and control panel.

- **Blending Jar:** Transparent container for blending and pureeing. Features measurement markings.
- **Steaming Basket:** Inserted into the blending jar for steaming food.
- **Lid:** Secures the blending jar and steaming basket during operation. Includes a lid strainer.
- **Blade Assembly:** Detachable blade for chopping and blending.
- **Control Knob:** Used to select functions and set the timer.

Included Accessories:



Image: The Bubos Baby Food Processor shown with a spatula, cleaning brush, and tongs.

- **Spatula:** For transferring food.
- **Measuring Cup:** For precise liquid measurements.
- **Cleaning Brush:** For thorough cleaning of components.
- **Tongs:** For safe handling of hot items.

Setup

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Initial Cleaning:** Before first use, wash all detachable parts (blending jar, lid, steaming basket, blade assembly, spatula, measuring cup, tongs) in warm soapy water. Rinse thoroughly and dry. Wipe the main unit with a damp cloth.
3. **Assemble Blade:** Carefully attach the blade assembly to the bottom of the blending jar. Ensure it is securely fastened.
4. **Place Blending Jar:** Position the blending jar onto the main unit, ensuring it clicks into place.

5. **Fill Water Reservoir:** Open the water reservoir cover on the side of the main unit and fill with distilled or filtered water up to the MAX line. Close the cover securely.

Operating Instructions

1. Steaming Food

1. Ensure the water reservoir is filled (refer to Setup).
2. Chop food into small, uniform pieces (approximately 1 cm cubes) to ensure even cooking.
3. Place the chopped food into the steaming basket. Do not overfill.
4. Insert the steaming basket into the blending jar, then place the lid on top and secure it.
5. Turn the control knob to the 'Steam' setting and set the desired steaming time. Recommended steaming times are often indicated near the knob or in a separate guide. For example, soft vegetables may require 10-15 minutes, while harder vegetables or meat may need 20-25 minutes.
6. The appliance will automatically shut off when the steaming cycle is complete or the water reservoir is empty.
7. Carefully remove the lid using the tongs, as steam will be hot. Use the spatula to transfer the steamed food if desired.

2. Blending / Pureeing Food



Image: The Bubos Baby Food Processor illustrating various puree consistencies from smooth to lumpy.

1. After steaming, carefully transfer the cooked food from the steaming basket into the blending jar.
2. Add a small amount of breast milk, formula, or cooking water to achieve the desired consistency.
3. Securely place the lid on the blending jar.
4. Turn the control knob to the 'Blend' setting. Pulse in short bursts until the desired texture is achieved (smooth, mixed, or lumpy). Do not blend continuously for more than 30 seconds to prevent overheating.
5. Once blended, turn the knob to 'Off' and unplug the appliance.
6. Carefully remove the lid and serve the baby food.

3. Warming / Reheating

1. Ensure the water reservoir is filled.
2. Place the bottle or container of food into the steaming basket.
3. Insert the steaming basket into the blending jar, then place the lid on top and secure it.

4. Turn the control knob to the 'Warm' setting and set the desired warming time.
5. The appliance will heat the contents using steam. Always check the temperature of the food or milk before feeding your baby.

4. Sterilizing

1. Ensure the water reservoir is filled.
2. Place clean bottles, pacifiers, or small accessories into the steaming basket.
3. Insert the steaming basket into the blending jar, then place the lid on top and secure it.
4. Turn the control knob to the 'Sterilize' setting and set the desired time (e.g., 10-15 minutes).
5. The hot steam will sterilize the items. Use tongs to carefully remove items after the cycle is complete and they have cooled.

Cleaning and Maintenance

Regular cleaning ensures optimal performance and hygiene of your Bubos Baby Food Processor Steamer.

1. **Unplug:** Always unplug the appliance from the power outlet before cleaning.
2. **Disassemble:** Carefully remove the blending jar, lid, steaming basket, and blade assembly from the main unit.
3. **Wash Detachable Parts:** The blending jar, lid, steaming basket, and blade assembly are dishwasher-safe. Alternatively, wash them by hand in warm soapy water using the provided cleaning brush for thorough cleaning. Rinse all parts thoroughly and allow them to air dry completely before reassembly or storage.
4. **Clean Water Reservoir:** The open design of the water reservoir allows for easy access. After each use, empty any remaining water. Wipe the inside with a damp cloth to prevent mineral buildup. For stubborn mineral deposits, a descaling solution (e.g., white vinegar diluted with water) can be used. Run a steam cycle with the descaling solution, then rinse thoroughly by running several cycles with clean water.
5. **Clean Main Unit:** Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water.
6. **Storage:** Store the clean and dry appliance in a cool, dry place.

Troubleshooting

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outage; control knob not set correctly.	Ensure the appliance is securely plugged into a working outlet. Check household circuit breaker. Turn the control knob to the desired function and set the timer.

Problem	Possible Cause	Solution
Steaming takes too long or food is not cooked.	Insufficient water in reservoir; food pieces too large; steaming time too short.	Refill water reservoir to MAX line. Cut food into smaller, uniform pieces. Increase steaming time.
Blending is ineffective or food is chunky.	Too much food in jar; not enough liquid; blade not properly installed.	Reduce the amount of food. Add more liquid (breast milk, formula, or cooking water). Ensure the blade assembly is securely attached.
Strong plastic/chemical smell during steaming.	New appliance odor; residue from manufacturing.	Perform several steaming cycles with only water before first use to dissipate any manufacturing odors. Ensure all parts were thoroughly cleaned initially. If the smell persists and affects food taste, contact customer service.
Blade leaks.	Blade assembly not properly sealed or damaged.	Ensure the blade assembly is correctly and tightly screwed onto the blending jar. Check the rubber seal for damage. If damaged, contact customer service for a replacement.
Appliance automatically shuts off prematurely.	Water reservoir is empty.	This is a safety feature. Refill the water reservoir and restart the cycle if needed.

Specifications

Feature	Detail
Brand	B Bubos
Model	B07PPVKBQV
Functions	Steam, Warm, Blend, Puree, Chop, Sterilize
Material	Stainless Steel (blade), BPA-Free Plastic
Color	White, Silver
Item Weight	2.56 Kilograms
Power Source	Manual (referring to knob operation, not battery)
Manufacturer	Bubos
UPC	718930071839

Warranty and Support

The Bubos Baby Food Processor Steamer comes with a **1-year manufacturer's warranty**. We also offer a **30-day money-back guarantee** from the date of purchase. Our commitment to customer satisfaction includes lifetime support for our products.

For any suggestions, concerns, or warranty claims, please contact Bubos Customer Service. Your feedback is valuable and helps us improve our products and services.

Manufacturer Contact Information: Wanchai, HK 999077, HK

© 2024 B Bubos. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07PPVKBQV

More documents and user manuals: **https://manuals.plus/**