

Stauer 20409

Stauer Centurion Hybrid Watch Instruction Manual

Model: 20409

[Overview](#)

[Setup](#)

[Operating](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty & Support](#)

1. OVERVIEW

The Stauer Centurion Hybrid watch (Model 20409) is a timepiece designed for functionality and durability, featuring both analog and digital displays. This watch is equipped with a chrome alloy case, a black stitched leather band, and a rotating bezel. It offers multiple functions including timekeeping, a stopwatch, and displays for day, date, and month. Luminous hands ensure visibility in various lighting conditions.



Image: Front view of the Stauer Centurion Hybrid watch, highlighting its dual analog and digital displays.

2. SETUP

2.1 Initial Time Setting

Upon first use or after a battery replacement, you will need to set both the analog and digital times.

Setting Analog Time:

1. Pull the crown (the knob on the side of the watch case) out to the first or second position (refer to specific model instructions if available for exact crown positions).
2. Turn the crown clockwise or counter-clockwise to adjust the hour and minute hands to the correct time.
3. Once set, push the crown back into its original position to start the analog movement.

Setting Digital Time and Date:

The digital display typically has multiple modes and is adjusted using the push-buttons on the side of the watch case. Consult the full PDF manual for detailed button functions.

- Press the mode button (usually bottom left) to cycle through modes such as time, date, stopwatch, and alarm.
- In the time setting mode, use the adjust button (usually top left) to select the digit to be changed (hours, minutes, seconds).
- Use the set/advance button (usually top right or bottom right) to change the value of the selected digit.
- Repeat for date (month, day, year) and other digital functions.
- Press the mode button again to exit the setting mode.



Image: Side view of the watch, illustrating the crown and push-buttons used for adjustments.

2.2 Band Adjustment

The watch features a genuine leather strap with a tang buckle. Adjust the strap by inserting the tang into the desired hole on

the strap for a comfortable and secure fit.

3. OPERATING THE WATCH

3.1 Analog Display

The analog display continuously shows the current time (hours, minutes, seconds) using traditional watch hands.

3.2 Digital Display Functions

The digital display offers several functions:

- **Time:** Displays hours, minutes, and seconds, often with 12/24-hour format options.
- **Date:** Shows the current day, date, and month.
- **Stopwatch:** A chronographic function to measure elapsed time. Typically started, paused, and reset using the push-buttons.
- **Alarm:** An audible alert that can be set for a specific time.



Image: Angled view of the watch, demonstrating the active digital display.

3.3 Rotating Bezel

The rotating bezel can be used to track elapsed time or for simple calculations. Align the zero mark on the bezel with the minute hand at the start of an event to measure duration, or use the markings for other timing purposes.

3.4 Luminous Hands

The hour and minute hands are treated with a luminous material, allowing them to glow in low-light conditions after exposure to light, improving readability in the dark.

4. MAINTENANCE

4.1 Cleaning

Wipe the watch case and crystal with a soft, dry cloth. For the leather strap, use a slightly damp cloth and allow it to air dry. Avoid using harsh chemicals or abrasive materials.

4.2 Water Resistance

This watch has a water resistance rating of 30 meters (3 ATM). This means it is suitable for everyday use and can withstand splashes or brief immersion in water. It is **not** suitable for swimming, showering, or diving. Avoid operating the push-buttons or crown when the watch is wet.

4.3 Battery Replacement

The watch is powered by batteries. When the timekeeping becomes erratic or the display fades, it may be time for a battery replacement. It is recommended to have battery replacement performed by a qualified watch technician to ensure proper sealing and maintain water resistance.



Image: Back view of the watch, showing the case back and leather strap.

4.4 Leather Strap Care

To prolong the life of your leather strap, avoid prolonged exposure to direct sunlight, extreme temperatures, and excessive moisture. Clean gently as described above.

5. TROUBLESHOOTING

If you encounter issues with your Stauer Centurion Hybrid watch, refer to the following common problems and solutions:

- **Analog or Digital Time is Incorrect:**

Ensure the crown is fully pushed in after setting the analog time. For digital time, re-enter the setting mode and adjust as per Section 2.1. If the issue persists, the battery may be low.

- **Digital Display is Faint or Blank:**

This typically indicates a low or depleted battery. Battery replacement is recommended.

- **Buttons are Unresponsive:**

Check if the watch is in a specific mode that locks buttons (e.g., a sleep mode or a mode that requires a specific button sequence to unlock). If not, a battery issue or internal malfunction may be present.

- **Watch Stops Running:**

For both analog and digital functions, a stopped watch usually points to a depleted battery.

For persistent issues not resolved by these steps, please refer to the official Stauer manual or contact customer support.

6. SPECIFICATIONS

Model Number	20409
Display Type	Analog-Digital
Movement Type	Quartz
Case Material	Chrome Alloy
Band Material	Leather
Case Diameter	42 Millimeters
Band Width	24 Millimeters
Water Resistance Depth	30 Meters (3 ATM)
Additional Features	Day and Date Function, Solid Back
Power Source	Battery Powered
Clasp Type	Tang Buckle
Crystal Material	Mineral Glass

7. WARRANTY & SUPPORT

7.1 Manufacturer's Warranty

The Stauer Centurion Hybrid watch comes with a **1-year manufacturer's warranty**. This warranty covers defects in materials and workmanship under normal use. It does not cover damage resulting from improper handling, accidents, unauthorized repairs, or normal wear and tear.

7.2 Further Support

For more detailed instructions, specific model information, or to contact customer service, please refer to the official Stauer website or the comprehensive manual available at: [Stauer Model 20409 PDF Manual](#).