

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [ghd](#) /

> [ghd Glide Hot Air Brush User Manual](#)

ghd 99350076468

ghd Glide Hot Air Brush User Manual

Professional Smoothing Blow Dryer Brush, Ceramic Hair Straightener, and Styler

1. PRODUCT OVERVIEW

The ghd Glide Hot Air Brush is designed to quickly tame frizz and smooth dry hair, providing a sleek, salon-quality finish. It features a ceramic heater and ionizer for effective frizz control and maintains an optimal styling temperature of 365°F to ensure healthy hair styling.



Figure 1.1: The ghd Glide Hot Air Brush, showcasing its sleek black design and brush head with bristles.



Figure 1.2: Key features of the ghd Glide: 365°F optimum styling temperature, ceramic technology with ionizer, and a rapid 25-second heat-up time.

2. SAFETY INFORMATION

Please read all safety instructions before using the ghd Glide Hot Air Brush to prevent injury or damage to the appliance.

- Always ensure your hands are dry before plugging in or unplugging the appliance.
- Do not use this appliance near water, in a bathroom, or near a basin or other vessel containing water.
- Keep the appliance out of reach of children.
- Do not leave the appliance unattended when plugged in.
- Allow the appliance to cool completely before storing.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons in order to avoid a hazard.
- The appliance is designed for use on dry hair only.

3. SETUP

Follow these steps for initial setup of your ghd Glide Hot Air Brush:

1. Unpack the ghd Glide Hot Air Brush and remove all packaging materials.
2. Inspect the appliance for any signs of damage. If damaged, do not use and contact customer support.
3. Plug the appliance into a suitable electrical outlet. The ghd Glide is designed for universal voltage, but ensure the plug type is compatible with your region's outlets.
4. Press the power button located on the handle. The indicator light will illuminate, and the brush will begin to heat up.
5. Wait approximately 25 seconds for the brush to reach its optimal styling temperature of 365°F. The indicator light will stop flashing when ready.



Figure 3.1: The power button and temperature indicator on the ghd Glide, highlighting the preset optimal temperature.

4. OPERATING INSTRUCTIONS

The ghd Glide Hot Air Brush is intended for use on dry hair. For best results, ensure your hair is completely dry before styling.

1. Ensure the brush has reached its optimal temperature (indicator light solid).
2. For optimal results, prep your hair with ghd Heat Protect Spray before styling.
3. Section your dry hair into manageable portions.

4. Take a section of hair and glide the ghd Glide Hot Air Brush from roots to ends in a slow, continuous stroke. Ensure the bristles pass through the hair evenly.
5. Repeat on all sections of hair until desired smoothness is achieved.
6. The brush is designed to smooth hair without flattening it, maintaining natural volume.
7. After use, press and hold the power button to turn off the appliance. The ghd Glide also features an automatic sleep mode that activates after 60 minutes of inactivity.



Figure 4.1: Visual representation of the ghd Glide's ability to transform hair from frizzy to smooth and sleek.

WINNER OF OVER 400 BEAUTY AWARDS GLOBALLY



For over 20 years ghd has championed a good hair day every day through Innovation, Performance, and Design

Figure 4.2: Demonstrates the ghd Glide in action, smoothing a section of hair from root to tip.

5. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your ghd Glide Hot Air Brush.

- **Cleaning:** Ensure the appliance is unplugged and completely cool before cleaning. Use a soft, damp cloth to wipe down the handle and brush head. Remove any trapped hair from the bristles using a fine-tooth comb or a brush cleaning tool. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the ghd Glide in a cool, dry place, away from direct sunlight and moisture. Ensure the cord is not tightly wrapped around the appliance, as this can cause damage over time.

6. TROUBLESHOOTING

If you encounter any issues with your ghd Glide Hot Air Brush, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Appliance not turning on.	Not plugged in; power outlet issue; internal fault.	Ensure it is securely plugged into a working outlet. Try a different outlet. If problem persists, contact customer support.
Appliance not heating up.	Not turned on; internal heating element issue.	Press the power button firmly. Allow 25 seconds for heat-up. If no heat, contact customer support.
Hair not smoothing effectively.	Hair is wet; sections too large; improper technique.	Ensure hair is completely dry. Work with smaller sections. Glide slowly from roots to ends.
Frizz persists after styling.	Hair not fully dry; environmental humidity; product buildup.	Ensure hair is completely dry. Consider using anti-frizz products. Clean the brush regularly.

If the issue is not resolved by these steps, please contact ghd customer support for further assistance.

7. SPECIFICATIONS

Detailed specifications for the ghd Glide Hot Air Brush:

- **Model Number:** 99350076468
- **Product Dimensions:** 12.6 x 3.7 x 3.85 inches
- **Weight:** 1.23 Pounds
- **Color:** Black
- **Bristle Material:** Ceramic
- **Handle Material:** Ceramic
- **Optimal Styling Temperature:** 365°F
- **Heat-up Time:** 25 seconds
- **Features:** Ceramic heater, Ionizer, Automatic sleep mode (after 60 minutes)
- **Manufacturer:** ghd
- **UPC:** 855254007608, 850041485164

8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official ghd website or contact their customer service directly. Keep your proof of purchase for any warranty claims.

- **Online Support:** Visit the official ghd website for FAQs, product registration, and support resources.
- **Contact Information:** Refer to the contact section on the ghd website for phone numbers or email support.
- **Documents:** Additional instructions for use may be available as PDF documents on the ghd website or through your retailer.

