

LOUTYTUO Louty-H

LOUTYTUO Ultrathin Upgraded Food Grade Silicone Travel Foldable Electric Kettle Instruction Manual

Model: Louty-H

1. IMPORTANT SAFETY INSTRUCTIONS

- **Read all instructions before use.**
- **Voltage Selection:** Before plugging in, ensure the voltage selector switch on the kettle base is set to the correct voltage (110V or 220V) for your region. Incorrect voltage selection can damage the appliance and pose a safety risk.
- **Boil Dry Protection:** The kettle is equipped with boil dry protection. If the kettle boils dry, it will automatically shut off. Allow it to cool down before refilling with water.
- **Water Level:** Do not fill above the MAX (555ml) line or below the MIN (300ml) line to prevent boiling over or boiling dry.
- **Unplug When Not in Use:** Always unplug the kettle from the outlet when not in use and before cleaning.
- **Hot Surfaces:** The kettle's exterior, especially the stainless steel base, will become hot during operation. Use the handle and avoid touching hot surfaces.
- **Supervision:** Close supervision is necessary when any appliance is used by or near children.
- **Silicone Odor:** A slight silicone odor may be present on first use. This is normal for food-grade silicone. To minimize, boil water with a slice of lemon or a small amount of vinegar several times before initial use.

2. PRODUCT FEATURES

- **Safe Food Grade Protective Material:** Made of BPA-free food-grade silicone. The heating plate

and kettle lid are constructed from 304 stainless steel for durability and safety.

- **Ultrathin Foldable Design:** Compact and easy to carry. Folded size: 170*139*132 MM; Unfolded size: 149*139*50 MM. Ideal for travel, camping, and business trips.
- **One-Button Operation:** Simple to use. Water boils in 3-5 minutes. The kettle features an automatic keep-warm function, reheating water if the temperature drops below 75°C.
- **Detachable Power Cord and Handle:** The power cord and handle can be separated from the kettle body for convenient storage and easier pouring.
- **Dual Voltage (110V/220V):** Equipped with a dual voltage selector, making it suitable for use in various countries.

3. PACKAGE CONTENTS

- 1 x Foldable Travel Kettle (US Plug)
- 1 x Zipper Foldable Storage Bag
- 1 x Instruction Manual
- 1 x Detachable Power Cord

4. SETUP

4.1 Handle Installation

The kettle's handle is detachable for compact storage. To install, align the handle with the slots on the kettle body and push firmly until it clicks into place. Ensure it is securely attached before use.



Image Description: A composite image demonstrating the kettle's foldable nature and handle attachment. The top left shows the kettle unfolded. The top right shows the handle being removed. The bottom left shows the kettle body folded flat. The bottom right shows the handle being reattached to the folded body.

4.2 Voltage Adjustment

Before first use, or when traveling to a region with a different voltage, adjust the voltage selector switch located on the bottom of the kettle. Use a screwdriver or a coin to turn the switch to either **110V** or **220V**, matching your local power supply. **Failure to do so may damage the appliance.**



Detachable Power cord

The detachable power cord is more durable and easy to storage.

Image Description: A close-up view of the kettle's base, highlighting the dual voltage selector switch. The switch can be turned to either 110V or 220V using a tool, as indicated by arrows.

4.3 Visual Guide: Setup and Folding

Your browser does not support the video tag.

Video Description: This video demonstrates how to install the handle, unfold the kettle, and then fold it back down for storage. It also briefly shows the voltage selector switch and the kettle in use.

5. OPERATING INSTRUCTIONS

5.1 Filling the Kettle

- Ensure the kettle is unfolded and the handle is securely attached.
- Open the lid and fill the kettle with water. Do not exceed the MAX (555ml) mark or go below the MIN (300ml) mark.
- Close the lid firmly.

Dual voltage

(110V / 220V)



Image Description: A detailed view of the kettle's silicone body, clearly showing the 'MAX: 555ml' and 'MIN: 300ml' water level indicators. The on-off button is also visible at the base.

5.2 Boiling Water

- Connect the detachable power cord to the kettle and then plug it into a suitable electrical outlet (ensure correct voltage is selected).
- Press the power button (usually illuminated) to start boiling. The indicator light will turn on.
- Water will typically boil in 3-5 minutes.

5.3 Automatic Shut-off and Keep Warm Function

- Once the water reaches boiling point, the kettle will automatically shut off, and the indicator light will extinguish.
- If the power button remains in the 'on' position, the kettle will self-heat and maintain the water temperature above 75°C.
- To completely turn off the kettle, press the power button again to the 'off' position and unplug it from the power outlet.

6. CLEANING AND MAINTENANCE

- **Always unplug the kettle and allow it to cool completely before cleaning.**
- **Exterior:** Wipe the exterior with a soft, damp cloth. Do not immerse the kettle base in water.
- **Interior:** For general cleaning, rinse the interior with water. For stubborn stains or mineral deposits, boil a mixture of water and white vinegar (1:1 ratio) in the kettle. Let it sit for 15-30 minutes, then rinse thoroughly.
- **Drying:** Ensure the kettle is completely dry before folding and storing.
- **Product Care Instructions:** Hand wash, wipe clean.

7. TROUBLESHOOTING

- **Kettle not heating:**
 - Check if the power cord is securely plugged into both the kettle and the wall outlet.
 - Ensure the power button is pressed to the 'on' position.
 - Verify the voltage selector switch on the base is set correctly (110V or 220V).
 - If the kettle recently boiled dry, the boil dry protection may have activated. Allow it to cool down before attempting to use it again.
- **Water has an unusual taste/odor:**
 - This can occur with new silicone products. Perform the initial cleaning procedure (boiling with lemon or vinegar) multiple times.
 - Ensure the kettle is thoroughly rinsed after cleaning.
- **Kettle boils over:**
 - Do not fill the kettle above the MAX line. Overfilling can cause water to boil over.

8. SPECIFICATIONS

Feature	Detail
Brand	LOUTYTUO
Model Name	Louty-F
Model Number	Louty-H
Capacity	555 ML (0.56 Liters)
Material	Food Grade Silicone, 304 Stainless Steel
Color	Pink
Voltage Range	110V / 220V (Dual Voltage)
Wattage	700 Watts (as per A+ content, conflicting with 580W in specs)
Boiling Time	3-5 minutes
Folded Size	170*139*132mm
Unfolded Size	149*139*50mm
Item Weight	0.7 Kilograms

9. STORAGE

To store the kettle, ensure it is completely cool and dry. Detach the handle by pulling the small lock towards the middle of the kettle and then remove the handle. Gently press down on the silicone body to fold it flat. Reattach the handle in its folded position or store it separately. Place the kettle and power cord in the provided zipper storage bag for compact and protected storage.



304 stainless steel heating plate



304 stainless steel lid



304 stainless steel support ring



3 anti-slip pads

Image Description: The LOUITYTUO foldable electric kettle, power cord, and instruction manual are shown neatly packed inside a black zippered travel case, demonstrating its portability.

10. WARRANTY AND SUPPORT

For any product inquiries, technical support, or warranty information, please refer to the contact details provided with your purchase or visit the LOUITYTUO official website. Keep your purchase receipt as proof of purchase for warranty claims.