

Sauder 420475

Sauder Harbor View Computer Desk Instruction Manual

MODEL: 420475

Product Overview

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your Sauder Harbor View Computer Desk. Designed to offer a cozy seaside aesthetic, this desk features a Curado Cherry finish, a storage hutch, louvered door panels, weathered bin pulls, and arched molding. It includes a slide-out keyboard shelf, storage behind doors, and three easy-to-access drawers for filing. The integrated hutch provides additional cubbyhole and vertical storage compartments.



Note: The image above is a placeholder indicating that a specific product image is not available.

Assembly Instructions

Assembly is required for this product. Please follow these general guidelines and refer to the specific assembly diagrams included with your product packaging for detailed, step-by-step instructions.

- 1. Unpack All Components:** Carefully remove all parts from the packaging. Verify that all components listed in the parts list are present and undamaged.
- 2. Identify Hardware:** Separate and identify all screws, dowels, cams, and other hardware. It is helpful to lay them out according to their type.
- 3. Follow Step-by-Step Diagrams:** Assemble the desk by following the numerical sequence of the diagrams. Ensure all fasteners are tightened securely but do not overtighten.
- 4. Attach Accessories:** Install the keyboard shelf, drawers, and hutch components as indicated in the instructions.
- 5. Final Inspection:** Once assembled, ensure the desk is stable and all parts are correctly aligned.

For best results, assemble on a soft, clean surface to prevent scratching. Two people are recommended for assembly.

Operating Your Desk

Your Sauder Harbor View Computer Desk is designed for functional use in a home office environment.

Familiarize yourself with its features:

- **Slide-Out Keyboard Shelf:** Located beneath the main desktop, this shelf provides convenient access for your keyboard and mouse, sliding in when not in use to save space.
- **Storage Drawers:** The three easy-to-access drawers are suitable for organizing files, office supplies, and personal items. Ensure drawers slide smoothly on their glides.
- **Behind-Door Storage:** Utilize the enclosed storage areas behind the louvered door panels for items you wish to keep out of sight.
- **Hutch Storage:** The integrated hutch offers cubbyhole compartments for smaller items and vertical storage for books or binders, helping to keep your workspace tidy.

Care and Maintenance

Proper care will extend the life and appearance of your computer desk.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the finish.
- **Spills:** Immediately blot any spills with a clean, dry cloth to prevent staining or damage to the finish.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they remain tight. Retighten as necessary to maintain stability.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration of the finish.
- **Heat and Moisture:** Do not place hot items directly on the surface. Use coasters or protective pads under beverages.

Troubleshooting Guide

This section addresses common issues you might encounter with your desk.

Problem	Possible Cause	Solution
Desk is wobbly or unstable.	Loose fasteners; uneven floor.	Ensure all screws and bolts are tightened. Adjust leg levelers if present, or place shims under legs on uneven surfaces.
Drawers do not slide smoothly.	Misaligned glides; obstruction; dirty glides.	Check that drawer glides are properly aligned and free of debris. Apply a silicone-based lubricant if necessary. Ensure drawers are not overloaded.
Missing or damaged parts.	Packaging error; shipping damage.	Refer to the contact information in the Warranty and Support section to request replacement parts. Do not attempt to assemble with missing parts.
Keyboard shelf is sticking.	Dust or debris in tracks; misaligned.	Clean the tracks of the keyboard shelf. Check for proper alignment and re-adjust if needed.

Product Specifications

Feature	Detail
Brand	Sauder
Model Name	Harbor View
Model Number	420475
ASIN	B07PRLZSXM
Finish Type	Cherry (Curado Cherry)
Shape	Rectangular
Number of Drawers	3
Assembly Required	Yes
Manufacturer	Sauder Woodworking
Age Range Description	Adult

Warranty and Customer Support

Sauder products are manufactured with quality and care. For specific warranty information regarding your Harbor View Computer Desk, please refer to the warranty card included with your product packaging or visit the official Sauder website.

If you require assistance with assembly, have questions about parts, or need to report a defect, please contact Sauder customer support directly. Contact information can typically be found on the manufacturer's website or within the product's packaging materials.

Please have your model number (420475) and purchase information ready when contacting support.

© 2023 Sauder Woodworking. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.

Related Documents - 420475

 <p>Computer Desk with Hutch Harbor View Collection Model 420475</p>	<p>Sauder Computer Desk with Hutch Assembly Instructions</p> <p>Step-by-step assembly guide for the Sauder Harbor View Collection Computer Desk with Hutch, Model 420475. Includes part identification, hardware identification, and assembly steps.</p>
 <p>Computer Desk with Hutch Harbor View Collection Model 420475</p>	<p>Sauder Computer Desk with Hutch Assembly Instructions</p> <p>Comprehensive assembly instructions for the Sauder Computer Desk with Hutch, Harbor View Collection, Model 420475. Includes part identification, hardware identification, and step-by-step assembly guidance.</p>

Documents - Sauder – 420475



[Sauder Computer Desk with Hutch Assembly Instructions](#)

Step-by-step assembly guide for the Sauder Harbor View Collection Computer Desk with Hutch, Model 420475. Includes part identification, hardware identification, and assembly steps.

lang:en score:32 filesize: 1.57 M page_count: 48 document date: 2016-12-21



[Sauder Computer Desk with Hutch Assembly Instructions](#)

Comprehensive assembly instructions for the Sauder Computer Desk with Hutch, Harbor View Collection, Model 420475. Includes part identification, hardware identification, and step-by-step assembly guidance.

lang:en score:26 filesize: 1.58 M page_count: 48 document date: 2018-05-21