

[Manuals.plus](#) /

› [PHILIPS](#) /

› PHILIPS Stellar Bright 16W LED Bulb User Manual

PHILIPS StellarBright 929001818814

PHILIPS Stellar Bright 16W LED Bulb User Manual

Model: StellarBright 929001818814

1. INTRODUCTION

Thank you for choosing the PHILIPS Stellar Bright 16W LED Bulb. This manual provides essential information for the safe and efficient use of your new LED bulbs. These bulbs are designed for indoor use, offering cool daylight illumination with energy-efficient LED technology.



The image displays the PHILIPS Stellar Bright 16W LED Bulb alongside its retail packaging. The packaging highlights key features such as 82% energy saving and EyeComfort Technology. The bulb itself is a standard A-shape with a B22 base.

2. SAFETY INFORMATION

- Always turn off the power supply before installing, removing, or cleaning the bulb.
- Do not use if the bulb or its packaging appears damaged.
- This bulb is designed for indoor use only.
- Do not attempt to disassemble or modify the bulb. There are no user-serviceable parts inside.
- Ensure the bulb is securely screwed into the fixture to prevent accidental detachment.
- This bulb is non-dimmable. Do not use with dimmer switches, as this may cause damage or malfunction.
- Operating voltage is 220-240 volts. Ensure your fixture's voltage matches this requirement.

3. SETUP AND INSTALLATION

3.1 Unpacking

Carefully remove the LED bulbs from their packaging. Inspect each bulb for any visible damage before installation.

3.2 Installation Steps

1. **Turn off Power:** Locate the light switch or circuit breaker controlling the fixture where the bulb will be installed and turn it off.
2. **Prepare Fixture:** If replacing an old bulb, allow it to cool completely before carefully unscrewing it from the fixture.
3. **Install New Bulb:** Gently screw the PHILIPS Stellar Bright 16W LED Bulb into the B22D base socket. Turn clockwise until it is snug, but do not overtighten.
4. **Restore Power:** Turn the power supply back on at the switch or circuit breaker.



A close-up view of the PHILIPS Stellar Bright 16W LED Bulb, highlighting its standard A-shape and B22D bayonet cap base, ready for installation.

4. OPERATING INSTRUCTIONS

Operating the PHILIPS Stellar Bright 16W LED Bulb is straightforward:

- **Power On/Off:** Use your standard wall switch to turn the light on or off.
- **Non-Dimmable:** This LED bulb is designed to operate at full brightness only and is not compatible with dimmer switches. Using it with a dimmer may lead to flickering, reduced lifespan, or damage to the bulb.



This graphic illustrates the main benefits of the PHILIPS Stellar Bright 16W LED Bulb, including up to 82% energy saving, 16W power consumption, LED technology, and EyeComfort Technology for reduced eye strain.

5. MAINTENANCE

The PHILIPS Stellar Bright 16W LED Bulb requires minimal maintenance:

- **Cleaning:** Ensure the power is off and the bulb is cool before cleaning. Use a soft, dry, lint-free cloth to wipe the bulb. Do not use liquid or abrasive cleaners.
- **Replacement:** When the bulb reaches the end of its operational life, replace it with a new PHILIPS Stellar Bright 16W LED Bulb or an equivalent LED bulb with a B22D base.

Eco-friendly lights



An image showing the PHILIPS Stellar Bright LED Bulb installed in a wall fixture, illuminating a modern living space with soft, eco-friendly light. The room features a sofa with cushions and a minimalist design.


6. TROUBLESHOOTING

If you encounter issues with your PHILIPS Stellar Bright 16W LED Bulb, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Bulb does not light up	No power to the fixture Bulb not screwed in properly Faulty bulb Faulty fixture	Check the light switch and circuit breaker. Ensure the bulb is securely tightened in the socket. Replace the bulb with a known working one. Have the fixture inspected by a qualified electrician.

Problem	Possible Cause	Solution
Bulb flickers	Used with a dimmer switch Loose connection Voltage fluctuations	Remove from dimmer circuit; this bulb is non-dimmable. Ensure the bulb is securely tightened. Consult an electrician if voltage issues persist.
Light output is low	Incorrect bulb wattage for desired brightness Dust or dirt on bulb/fixture	Ensure the 16W bulb meets your brightness requirements. Clean the bulb and fixture as per maintenance instructions.

LED lighting of the highest quality



The PHILIPS Stellar Bright LED Bulb is shown installed in an outdoor fixture, casting bright, high-quality light over the entrance of a building, demonstrating its suitability for various lighting needs.

7. SPECIFICATIONS

Detailed technical specifications for the PHILIPS Stellar Bright 16W LED Bulb:

Feature	Specification
Brand	PHILIPS
Model Name	StellarBright
Model Number	929001818814_6
Light Type	LED
Wattage	16 Watts
Bulb Base	B22D
Light Colour	Cool Daylight
Colour Temperature	6500 Kelvin
Operating Voltage	220-240 Volts
Light Output (Maximum)	1440 Lumens
Efficiency	90 lumens per watt, Energy Efficient
Light Source Operating Life	15,000 Hours
Special Feature	Energy Efficient, Non Dimmable
Material Type	Polycarbonate (PC)
Indoor Outdoor Usage	Indoor
Number of Items (in pack)	6 Count
Item Weight (for pack)	480 Grams

Light that's easy on your eyes



Reduces
glare



Minimises
flicker



Tailored for
well-being

This image depicts a family, including parents and children, comfortably relaxing in a bedroom illuminated by the PHILIPS Stellar Bright LED Bulb. The lighting is designed to be gentle on the eyes, promoting well-being.

8. WARRANTY AND SUPPORT

8.1 Warranty Information

This PHILIPS Stellar Bright 16W LED Bulb comes with a **2-year warranty** on the product from the date of invoice. Please retain your purchase receipt as proof of purchase for warranty claims.

8.2 Manufacturer and Importer Contact

For support, warranty claims, or further inquiries, please contact:

Manufacturer: Signify Innovations India Limited (formerly known as Philips Lighting India Limited)

PS ARCADIA CENTRAL, 3A, 3rd floor, 4A, Abanindranath Thakur Sarani (Camac Street), Kolkata – 700 017, India

Importer: Signify Innovations India Limited

PS Arcadia Central, 3A, 3rd Floor, 4A, Abanindranath Thakur Sarani (Camac Street), Kolkata-700017, West Bengal, India

