

[Manuals.plus](#) /

› [La Crosse Technology](#) /

› La Crosse Technology 404-4040 16-Inch Ironwood Wall Clock Instruction Manual

La Crosse Technology 404-4040

La Crosse Technology 404-4040 16-Inch Ironwood Wall Clock Instruction Manual

Model: 404-4040

1. PRODUCT OVERVIEW

The La Crosse Technology 404-4040 is a 16-inch Ironwood Wall Clock designed to provide accurate timekeeping with a distinctive aesthetic. It features a solid rust brown frame, a dual-toned wooden dial, and a reliable quartz movement. This clock is intended for indoor use and requires one AA alkaline battery for operation.



Image 1.1: Front view of the La Crosse Technology 404-4040 16-Inch Ironwood Wall Clock, showcasing its dual-toned wooden dial and metal frame.

2. FEATURES

- Dual-toned wood dial for a unique visual appeal.
- Durable metal framework with molded numbers at 12 and 6 o'clock positions.
- Accurate quartz movement for reliable timekeeping.
- Open face dial with metal hands for clear visibility.
- Designed for easy wall mounting.

3. SETUP INSTRUCTIONS

3.1. Battery Installation

1. Locate the battery compartment on the back of the clock.
2. Insert one fresh AA alkaline battery into the compartment, ensuring the correct polarity (+ and -).
3. Close the battery compartment cover securely.

3.2. Setting the Time

1. After installing the battery, allow the clock a few moments to initialize.
2. Locate the time setting wheel on the back of the clock mechanism.
3. Gently turn the wheel in either direction to move the clock hands to the correct time.
4. Avoid moving the hands directly, as this may damage the movement.

3.3. Mounting the Clock

The clock is designed for wall mounting. Choose a suitable location indoors, away from direct sunlight or extreme temperatures, which could affect accuracy or material integrity.

1. Select a sturdy wall location.
2. Install a suitable wall anchor or hook (not included) capable of supporting the clock's weight.
3. Hang the clock securely using the integrated hanging slot on the back.



Image 3.1: Side view of the clock, illustrating the frame and depth for mounting reference.

4. OPERATING THE CLOCK

Once the battery is installed and the time is set, the clock will begin operating automatically. The quartz movement ensures accurate timekeeping. No further user interaction is typically required for daily operation.

5. MAINTENANCE

5.1. Cleaning

To clean the clock, gently wipe the surface with a soft, dry cloth. Avoid using abrasive cleaners, solvents, or chemical sprays, as these can damage the finish or internal components.

5.2. Battery Replacement

Replace the AA alkaline battery annually or when the clock hands stop moving or begin to lose time. Follow the battery installation steps outlined in Section 3.1.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Clock is not running.	Battery is dead or incorrectly installed.	Replace with a fresh AA alkaline battery, ensuring correct polarity.
Clock is losing or gaining time.	Weak battery or faulty movement.	Replace the battery. If the problem persists, contact customer support.
Hands are stuck.	Hands may be bent or obstructed.	Carefully check if the hands are touching each other or the dial. Gently adjust if necessary.

7. SPECIFICATIONS

Attribute	Detail
Model Number	404-4040
Brand	La Crosse Technology
Display Type	Analog
Power Source	1 AA Alkaline Battery (not included)
Material	Metal, Wood
Product Dimensions	16"W x 16"H
Item Weight	3.89 pounds
Indoor/Outdoor Usage	Indoor
Mounting Type	Wall Mount




Image 7.1: Dimensions of the 16-inch Ironwood Wall Clock.

8. WARRANTY AND SUPPORT

La Crosse Technology is committed to providing quality products and customer satisfaction. For specific warranty information, please refer to the warranty card included with your product or visit the official La Crosse Technology website. For technical support, resources, or video tutorials, please visit the [La Crosse Technology Support Page](#) or contact their USA-based support team.

