

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [VTech](#) /

› [VTech KidiBuzz G2 Kids' Electronics Smart Device Instruction Manual](#)

VTech 80-186600

VTech KidiBuzz G2 Kids' Electronics Smart Device Instruction Manual

INTRODUCTION

The VTech KidiBuzz G2 is a Wi-Fi smart device designed for children aged 4-9 years. It offers a safe and engaging platform for kids to communicate, play, and learn. This device allows children to send texts, voice messages, and images to parent-approved contacts using the free KidiConnect app. It features a durable, kid-tough design with a shatter-safe screen, making it suitable for active play. The KidiBuzz G2 includes a variety of pre-loaded learning games, augmented reality experiences, and creative tools like the Wonder Masks app for photo filters.

Key Features

- Kids can send images, texts, and voice messages to parent-approved contacts with the free KidiConnect app.
- The sleek, kid-tough smart device looks just like an adult device and comes with a shatter-safe screen.
- Take photos with Wonder Masks' face filters that follow kids' movements and share with approved contacts.
- Play the AR game Creature Detective plus 40+ learning games on math, spelling, science, and more. Download even more from third-party app store.
- Intended for ages 4+ years. This device is not a cell phone. Rechargeable lithium-ion battery included. Only charge the device using the included micro USB cable with the included power adapter or a computer (not included).

SETUP

Unboxing

Carefully remove all components from the packaging. Ensure you have all items listed in the 'What's in the Box' section.





Image: The VTech KidiBuzz G2 device displaying a child's face with an interactive bunny filter from the Wonder Masks app.

Initial Charging

Before first use, fully charge your KidiBuzz G2 device. Use only the included micro USB cable and power adapter. Connect the micro USB cable to the device's charging port and the adapter to a standard wall outlet. A full charge ensures optimal performance.

Device Activation & KidiConnect App

Turn on the device by pressing the power button. Follow the on-screen prompts to set up your child's profile and connect to a Wi-Fi network. Download the free KidiConnect app on your smartphone or tablet to manage your child's contacts, send messages, and access parental controls. Refer to the included Parent's Guide for detailed instructions on pairing the device with the KidiConnect app.

OPERATING YOUR KIDIBUZZ G2

Messaging with KidiConnect

Once paired with the KidiConnect app, your child can send text messages, voice messages, and images to parent-approved contacts. The interface is designed to be intuitive for young users.

Using the Camera and Wonder Masks

The KidiBuzz G2 features a camera for taking photos and videos. Explore the Wonder Masks app to add fun, movement-responsive face filters to pictures, which can then be shared with approved contacts.





Image: The VTech KidiBuzz G2 device showing the 'Creature Detective' game, an augmented reality experience where a cartoon creature is overlaid on a real-world background.

Games and Learning Activities

The device comes pre-loaded with over 40 learning games covering subjects like math, spelling, and science. It also includes augmented reality games such as Creature Detective. Additional games can be downloaded from the third-party app store.






Image: The VTech KidiBuzz G2 device displaying a winter-themed game where a character is snowboarding down a snowy path, avoiding obstacles.

Video: An official VTech commercial showcasing the features and fun activities available on the KidiBuzz G2 device, including messaging, games, and creative filters.

Parental Controls

The KidiBuzz G2 includes passcode-protected parental controls. These controls allow parents to set time limits for device usage, approve contact lists for messaging, and add a list of specifically approved websites for safe browsing.

Maintenance

Charging Your Device

To maintain battery health, always use the included micro USB cable and power adapter for charging. Avoid using third-party chargers that may not be compatible. Do not attempt to charge the device with a damaged cable or adapter.

Cleaning

To clean the device, use a soft, dry cloth. Avoid using abrasive cleaners, solvents, or harsh chemicals, as these can damage the screen or casing. Do not immerse the device in water.

Troubleshooting

Common Issues

- **Charging Issues:** Ensure you are using the micro USB cable and power adapter that came with the device. Check that all connections are secure and the adapter is plugged into a working outlet.
- **Screen Glitches/Fading:** If the screen display appears glitchy or fades in and out, try restarting the device. If the issue persists, ensure the device software is up to date or contact VTech customer support.
- **KidiConnect App Not Working:** Verify that the KidiBuzz G2 is properly paired with the KidiConnect app on the parent's device and has a stable Wi-Fi connection. Check for app updates on both devices.
- **Screen Damage:** While the KidiBuzz G2 has a shatter-safe screen, it is not indestructible. Dropping the device from a height or onto a hard surface may cause damage. Consider using an additional protective case for enhanced durability.

SPECIFICATIONS

Feature	Detail
Product Dimensions	0.75 x 7.05 x 3.8 inches
Item Weight	13.4 ounces
Item Model Number	80-186600
Manufacturer Recommended Age	4 - 9 years
Batteries	1 Lithium Polymer batteries required (included)
Release Date	March 16, 2019
Manufacturer	VTech

WHAT'S IN THE BOX

- KidiBuzz™ G2 Device
- USB Cable
- AC Adapter
- Parent's Guide

WARRANTY AND SUPPORT

For detailed warranty information, product registration, and customer support, please refer to the VTech website or the contact details provided in the included Parent's Guide. Keep your proof of purchase for any warranty claims.