



[Manuals.plus](#) /

› [LEGO](#) /

› [LEGO City People Pack – Fun Fair 60234 Building Kit Instruction Manual](#)

LEGO 6251768

LEGO City People Pack – Fun Fair 60234 Building Kit Instruction Manual

Model: 6251768 | Brand: LEGO

INTRODUCTION

This manual provides detailed instructions for assembling and enjoying your LEGO City People Pack – Fun Fair 60234 Building Kit. This set is designed to enhance role-play adventures within your LEGO City, featuring a variety of minifigures and fun-fair themed elements. The set includes 14 minifigures, a duck pool ring toss game, a shooting gallery, a face painting table, a strength test, and an ice cream cargo bike.

SAFETY INFORMATION

Warning: Toy contains small parts. Not for children under 3 years.

Always ensure that small LEGO elements are kept away from young children to prevent choking hazards. Adult supervision is recommended during assembly and play for younger users.

WHAT'S IN THE BOX

Your LEGO City People Pack – Fun Fair 60234 Building Kit includes:

- All necessary LEGO Building Elements (183 pieces)
- Instruction booklet for assembly



Image: The retail box for the LEGO City People Pack Fun Fair 60234, showing the assembled set and various minifigures.



OPERATING THE FUN FAIR ELEMENTS

The LEGO City Fun Fair set includes several interactive elements designed for imaginative play:

- **Duck Pool Ring Toss Game:** Place the duck elements in the pool. Minifigures can attempt to toss rings over the ducks.



Image: A close-up of the duck pool ring toss game, showing the blue rings and yellow duck elements.

- **Shooting Gallery Game:** Utilize the stud shooter to knock down the targets. Position minifigures to aim and fire.



Image: A detailed view of the shooting gallery game with its red stud shooter and two target boards.

- **Strength Test:** Use the buildable mallet to hit the base of the strength test tower and see how high the indicator goes.



Image: The strength test attraction, featuring a yellow tower with a bell at the top and a red mallet for striking.

- **Ice Cream Cargo Bike:** The bike features an umbrella and space for an ice cream cone, allowing minifigures to role-play as vendors or customers.



Image: A close-up of the ice cream cargo bike with its yellow umbrella and detailed ice cream graphics.

- **Minifigures:** The set includes 14 diverse minifigures, such as a stilt walker, various fair-goers, and staff, enabling a wide range of role-playing scenarios.



Image: A stilt walker minifigure with a purple top hat and blue stilts, alongside a child minifigure.

MAINTENANCE

To ensure the longevity and cleanliness of your LEGO set, follow these simple maintenance guidelines:

- **Cleaning:** For general cleaning, wipe LEGO bricks with a damp cloth. For deeper cleaning, wash bricks by hand in water no warmer than 104°F (40°C) using a mild detergent. Rinse thoroughly with clear water.
- **Drying:** Air dry LEGO bricks at room temperature. Do not use a microwave, oven, or hairdryer, as high heat can damage the plastic.
- **Storage:** Store your LEGO set in a cool, dry place away from direct sunlight to prevent color fading and material degradation.
- **Avoid Harsh Chemicals:** Do not use alcohol, solvents, or abrasive cleaners on LEGO elements, as these can damage the plastic.

TROUBLESHOOTING

If you encounter any issues during assembly or play, consider the following common solutions:

- **Missing Pieces:** Double-check all packaging and sorting areas. Sometimes small pieces can be overlooked. If a piece is genuinely missing, contact LEGO Customer Service.
- **Difficulty Connecting Bricks:** Ensure bricks are aligned correctly and apply firm, even pressure. New bricks can sometimes be a bit stiff.
- **Incorrect Assembly:** Review the instruction booklet carefully, paying close attention to the orientation and placement of each brick. Disassemble and reassemble the problematic section if necessary.
- **Damaged Pieces:** If any pieces are damaged upon arrival, contact LEGO Customer Service for replacements.

SPECIFICATIONS

Feature	Detail
---------	--------

Product Dimensions	10.32 x 7.52 x 1.81 inches
Item Weight	3.52 ounces
ASIN	B07PVBZF11
Item Model Number	6251768
Manufacturer Recommended Age	5 years and up
Release Date	August 1, 2019
Manufacturer	LEGO
Number of Pieces	183

WARRANTY AND SUPPORT

LEGO products are known for their high quality and durability. For information regarding product warranty, missing parts, or any other support needs, please visit the official LEGO customer service website or contact their support team directly.

Official LEGO Website: www.lego.com

LEGO Customer Service: Refer to the contact information provided on the LEGO website for your region.