Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Passion-Electro XSARIUS Pure

Passion-Electro Replacement Remote Control for XSARIUS PURE User Manual

Introduction

This manual provides detailed instructions for the Passion-Electro replacement remote control, specifically designed for XSARIUS PURE devices. This remote offers full functionality comparable to your original remote control. It is a specialized replacement and does not require any programming. Simply insert the batteries, and it is ready for use.

Product Overview

The Passion-Electro replacement remote control is engineered for seamless compatibility with your XSARIUS PURE device. Its design ensures that all essential functions are easily accessible, providing a familiar user experience.



Figure 1: Front view of the remote control, displaying the button layout.



Figure 2: Angled view of the remote control, showing its profile and button details.



Figure 3: Rear view of the remote control, with the battery compartment visible.

Setup

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch and lift to open it.
3. Insert two (2) AAA 1.5V batteries (not included), ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.

The remote control is now ready for use. No additional programming is required.

Operating Instructions

This replacement remote control provides access to all standard functions of your XSARIUS PURE device. Point the remote control directly at your device's infrared receiver for optimal performance.

- **Power Button:** Turns the device on or off.
- **Number Buttons (0-9):** Directly select channels or input numerical values.
- **Channel Up/Down:** Navigates through channels.
- **Volume Up/Down:** Adjusts the audio volume.
- **Mute Button:** Toggles audio mute on or off.
- **Navigation Pad (Arrows and OK):** Used to navigate menus and confirm selections.
- **Menu/Home Button:** Accesses the main menu or home screen of your device.
- **Exit Button:** Exits current menus or functions.
- **Color Buttons (Red, Green, Yellow, Blue):** These buttons typically correspond to specific functions within menus or applications, as indicated on your device's screen.
- **Other Function Buttons:** Additional buttons (e.g., TV, DVD, AUX, INFO, SLEEP) provide access to specific device modes or features. Refer to your XSARIUS PURE device's manual for their exact functions.

Maintenance

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries simultaneously with new ones of the same type (AAA 1.5V).
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage. Store in a cool, dry place.
- **Avoid Exposure:** Do not expose the remote control to direct sunlight, extreme temperatures, high humidity, or water.

Troubleshooting

Problem	Possible Cause	Solution
Remote control is not working.	• Batteries are dead or inserted incorrectly. • Obstruction between remote and device. • Remote control is too far from the device.	• Replace batteries with new AAA 1.5V batteries, ensuring correct polarity. • Remove any objects blocking the line of sight between the remote and the device. • Move closer to the device (within 10 meters).
Buttons are unresponsive or delayed.	• Low battery power. • Infrared sensor on device is dirty or blocked.	• Replace batteries. • Clean the infrared sensor on your XSARIUS PURE device.

Specifications

- **Brand:** Passion-Electro

- **Model Name:** XSARIUS Pure
- **Color:** Black
- **Connectivity Technology:** Infrared
- **Compatible Devices:** XSARIUS PURE
- **Maximum Range:** 10 Meters
- **Battery Type:** 2 x AAA 1.5V (not included)

Warranty and Support

This product is typically covered by a 30-day return policy for refunds or replacements, as per standard retail terms. For any issues, questions, or support needs regarding your Passion-Electro replacement remote control, please contact the seller directly through your purchase platform. Provide your order details for efficient assistance.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07PVNY9ZN

More documents and user manuals: **https://manuals.plus/**