

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Vermont Castings](#) /

> [Vermont Castings Andiron 1306717A Instruction Manual for Intrepid and Dauntless Stoves](#)

## Vermont Castings 1306717A

# Vermont Castings Andiron 1306717A Instruction Manual

For Intrepid and Dauntless Wood Stoves

## 1. PRODUCT OVERVIEW

The Vermont Castings Andiron, model 1306717A, is a replacement component designed for specific Vermont Castings wood stoves. This andiron measures 6-1/4 inches long and is sold individually. Two (2) andirons are typically required for a full replacement within the stove's bottom grate area.



Figure 1: Vermont Castings Andiron 1306717A. This cast iron component is crucial for proper log placement and airflow within your wood stove.

## 2. COMPATIBILITY

This genuine OEM Vermont Castings part (1306717A or 130-6717) is compatible with the following Vermont Castings stove models:

- Dauntless Fireplace with Glass 1240
- Dauntless Tradition 2150
- Intrepid I 1302
- Intrepid II 1990, 2070, 1308, 1303

Always verify your stove's model number to ensure proper fitment before ordering replacement parts.

### 3. INSTALLATION AND REPLACEMENT

The andirons are designed for straightforward replacement. Over time, due to high temperatures and ash buildup, existing andirons may deteriorate or become difficult to remove. The replacement process typically involves removing the old andirons and inserting the new ones into the designated slots within the stove's firebox.

#### Installation Steps:

1. Ensure the wood stove is completely cool and free of any burning embers or hot ash.
2. Open the stove doors to access the firebox.
3. Carefully remove any existing, damaged andirons. They may simply lift out or require a gentle wiggle if ash has accumulated around them.
4. Clean any ash or debris from the area where the andirons sit to ensure a proper fit for the new parts.
5. Insert the new Vermont Castings Andiron 1306717A into the designated slots on the bottom grate. Ensure they are seated firmly.
6. Repeat for the second andiron if replacing both.
7. Close the stove doors.

Your browser does not support the video tag.

Video 1: Installation demonstration of a similar bolt-on andiron for Vermont Castings wood stoves. This video illustrates the general process of replacing andirons.

### 4. OPERATING CONSIDERATIONS

Proper placement of the andirons ensures optimal airflow and prevents logs from rolling against the stove's glass doors. Position logs securely between the andirons to maintain a stable fire and protect the stove components.

### 5. MAINTENANCE

Regularly inspect your andirons for signs of wear, cracking, or significant deterioration. While made from durable cast iron, prolonged exposure to high heat can cause them to degrade over time. Keep the area around the andirons free of excessive ash buildup, as this can restrict airflow and potentially accelerate wear.

### 6. TROUBLESHOOTING

- **Andirons do not fit:** Double-check your stove's model number against the compatibility list. Ensure all ash and debris are cleared from the installation area.
- **Andirons wear out quickly:** This can be a normal consequence of high-temperature use. Ensure you are not over-firing your stove, which can lead to premature wear of internal components.

### 7. SPECIFICATIONS

Feature	Specification
---------	---------------

Brand	Vermont Castings
Model Number	1306717A
Material	Cast Iron
Color	Black
Size	6-1/4 inches long
Item Weight	0.36 Kilograms (approx. 12.6 ounces)
Installation Type	Freestanding (within grate)

## 8. WARRANTY AND SUPPORT

This product typically comes with a limited warranty from Vermont Castings. For specific warranty details, claims, or further support, please refer to the official Vermont Castings website or contact their customer service directly. Always use genuine Vermont Castings replacement parts to maintain product integrity and warranty coverage.