

Manuals.plus /

- › UPS Battery Center /
- › UPSBatteryCenter Replacement Battery Instruction Manual for Rollplay 12V GMC Sierra Denali Black (Model TLV12120T)

UPS Battery Center TLV12120T

UPSBatteryCenter Replacement Battery Instruction Manual for Rollplay 12V GMC Sierra Denali Black

Model: TLV12120T

1. PRODUCT OVERVIEW

This document provides instructions for the UPSBatteryCenter 12V replacement battery, designed for use with specific Rollplay 12V GMC Sierra Denali Black ride-on toy models. This battery is a sealed, rechargeable unit intended to provide power for compatible children's vehicles.

Compatibility:

- Rollplay GMC Sierra Denali Black models: W461-G, W461-G01, W461-G02, W461-G03, W461-G04, W461-G05



Image 1.1: The UPSBatteryCenter 12V 12Ah replacement battery, featuring a blue top casing and black body with visible

2. INSTALLATION INSTRUCTIONS

Safety Precautions:

- Ensure the ride-on toy is turned off and disconnected from any power source before beginning installation.
- Always wear appropriate personal protective equipment, such as gloves and eye protection.
- Avoid short-circuiting the battery terminals.
- Keep children away from the installation area.

Installation Steps:

1. Locate the battery compartment on your Rollplay ride-on toy. Refer to your toy's original instruction manual for specific compartment access.
2. Carefully open the battery compartment cover.
3. Disconnect the existing battery by detaching the connectors. Note the polarity (positive and negative) to ensure correct re-connection.
4. Remove the old battery from the compartment.
5. Place the new UPSBatteryCenter replacement battery into the compartment, ensuring it fits securely.
6. Connect the battery terminals to the toy's wiring, matching positive to positive (red) and negative to negative (black). Ensure connections are firm.
7. Close the battery compartment cover securely.
8. The battery arrives fully charged and ready for use.

3. USAGE GUIDELINES

This replacement battery is designed for immediate use upon installation. For optimal performance and longevity, adhere to the following guidelines:

- **Initial Use:** The battery is shipped fully charged.
- **Charging:** Always use the charger provided with your Rollplay ride-on toy. Follow the toy's original manual for charging procedures and recommended charging times.
- **Discharge:** Avoid completely draining the battery. Recharge the battery after each use or when the toy's performance noticeably decreases.
- **Operating Temperature:** Use the battery within the recommended temperature range specified by the ride-on toy manufacturer.

4. MAINTENANCE AND STORAGE

Proper maintenance and storage will extend the life of your replacement battery:

- **Regular Charging:** If the toy is not used for extended periods, charge the battery at least once every 3 months to prevent deep discharge and maintain capacity.
- **Cleaning:** Keep battery terminals clean and free of corrosion. Use a dry cloth to wipe down the battery exterior.
- **Storage:** Store the battery in a cool, dry place away from direct sunlight and extreme temperatures. Ensure the battery is fully charged before long-term storage.
- **Disposal:** Do not dispose of batteries in household waste. Recycle spent batteries according to local

regulations.

5. TROUBLESHOOTING

If you encounter issues with your replacement battery, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Battery does not hold a charge or discharges quickly.	Improper charging, old charger, parasitic drain in toy, or battery defect.	Ensure charger is functioning correctly. Verify charging duration as per toy's manual. Check toy for any components that might be drawing power when off. If issues persist, contact customer support.
Fuses blow repeatedly after battery installation.	Incorrect wiring, short circuit in toy, or incompatible battery.	Double-check all wiring connections for correct polarity and secure fit. Inspect toy's wiring for any damage or short circuits. Ensure the battery is compatible with your specific toy model. If problem continues, seek professional assistance or contact customer support.
Toy does not power on after battery installation.	Loose connections, uncharged battery, or toy malfunction.	Verify all battery connections are secure. Although shipped charged, ensure the battery has sufficient charge. Test the toy with a known working battery if possible. Consult the toy's original manual for troubleshooting.

6. TECHNICAL SPECIFICATIONS

Specification	Detail
Model Number	TLV12120T
Voltage	12V
Amperage	12 Amps (12Ah)
Battery Type	Sealed Lead Acid (SLA)
Manufacturer	UPS Battery Center
Expected Life Span	3-5 years (under optimal conditions)
UPC	780478206356, 780478206332

7. WARRANTY AND CUSTOMER SUPPORT

Warranty Information:

This UPSBatteryCenter replacement battery is covered by a **1-year replacement warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the battery performs as specified under normal use. Please retain your proof of purchase for warranty claims.

Customer Support:

For technical assistance, warranty claims, or any questions regarding your UPSBatteryCenter product, please contact our customer support team:

- **Manufacturer:** UPS Battery Center Ltd.
- **Toll Free:** (1) 888-755-7718
- **Email:** sales@upsbatterycenter.com
- **Website:** www.upsbatterycenter.com