

Altec Lansing IMQ610-WHT

Altec Lansing Octave Wireless Bluetooth Speaker with Smartphone Dock

Model: IMQ610-WHT

INTRODUCTION

Thank you for choosing the Altec Lansing Octave Wireless Bluetooth Speaker with Smartphone Dock. This device combines a high-quality Bluetooth stereo speaker system with a convenient wireless charging station and an alarm clock. Designed for versatility and ease of use, it's an ideal companion for various settings, from your home to travel.

Key features include:

- **Modern Design:** A sleek and versatile design that fits seamlessly into any indoor environment, providing quality sound and charging capabilities.
- **Dual Charging Options:** Equipped with Qi Wireless Charging and USB Charging for rapid power delivery to your devices.
- **Extended Battery Life:** Enjoy up to 8 hours of continuous audio playback.
- **Multi-Purpose Functionality:** Features touchless access to Siri or Google Voice Assistant via Bluetooth, and is IPX4 rated for splash resistance.



Figure 1: Altec Lansing Octave Wireless Bluetooth Speaker with Smartphone Dock.

SETUP

Charging the Speaker

To charge the speaker, connect the AC adapter's plug into a suitable wall outlet. Insert the other end of the adapter into the charging port located on the back of the speaker. The LED indicator will illuminate red while charging and will turn off once charging is complete. A full charge typically takes 4 to 5 hours.



Figure 2: Rear view of the speaker with charging port (DC IN 5V) and USB port.

Power On/Off

To turn the speaker on or off, press and hold the power button (usually marked with a power symbol) for 1 to 2 seconds.

CONNECTIVITY

Bluetooth Pairing

To pair your device via Bluetooth:

1. Ensure the speaker is powered on.
2. On your smartphone or Bluetooth-compatible device, navigate to the Bluetooth settings page.
3. Make sure Bluetooth is enabled on your device.
4. Select "Octave" from the list of available devices to connect.

NFC Pairing (Near Field Communication)

For devices supporting NFC, you can connect by:

1. Turning on NFC on your smartphone.
2. Gently touching the back of your smartphone to the side of the speaker where the NFC sensor is located. The speaker and your device should automatically pair.

Qi Wireless Charging

Once the speaker is fully charged, you can place a Qi-compatible smartphone onto the designated Qi wireless charging pad on the speaker's dock. Your device will begin charging automatically.



Figure 3: Top view of the speaker highlighting the Qi wireless charging pad.

OPERATING CONTROLS

The top panel of the speaker features several buttons for controlling playback and volume:

- **Play/Pause Button:** Press to play or pause the current audio track.

- **Volume Up (+) Button:** Press to increase the music volume. Press and hold to skip to the next track.
- **Volume Down (-) Button:** Press to decrease the music volume. Press and hold to go to the previous track.



Figure 4: Top control panel with power, volume, microphone, and play/pause buttons.

CLOCK SETTINGS

On the back of the speaker, you will find three buttons dedicated to setting the clock:

- **Time Set Button:** Used to initiate time setting mode.
- **Down Button:** Used to decrease the time value.
- **Up Button:** Used to increase the time value.

Use these three buttons in conjunction to set the correct time for the integrated clock display.

RESET OPTIONS

Disconnect Bluetooth

To disconnect the current Bluetooth connection, press and hold the microphone button for approximately 5 seconds. You will hear a beep indicating the disconnection.

Reset All Connections

To clear all previously paired Bluetooth connections and reset the speaker's connection memory, press and hold the microphone button for approximately 10 seconds. You will hear a beep confirming the reset.

Factory Reset

To restore the speaker to its original factory settings, press and hold the power button for approximately 10 seconds.

SPECIFICATIONS

Feature	Detail
Model Name	IMQ610-WHT
Speaker Type	Wireless Bluetooth
Special Feature	Waterproof (IPX4 splashproof)
Compatible Devices	Desktop, Laptop, Smartphone, Tablet, Television
Controller Type	homekit, vera
Surround Sound Channel Configuration	2.0
Color	Off-White
Battery Life	8 Hours
Included Components	Speaker
Is Waterproof	True
Warranty Type	Limited
Number of Items	1
Control Method	Voice
Wireless Communication Technology	Bluetooth
Speaker Size	5 Inches
Power Source	Battery Powered
Tweeter Diameter	1 Inches
Water Resistance Level	Water Resistant
Number of Batteries	1 Lithium Ion batteries required. (included)
Audio Driver Type	Dynamic Driver
Bluetooth Range	30.48 Meters
Subwoofer Connectivity Technology	Wireless
Connectivity Protocol	Bluetooth
Includes MP3 player?	No
Number of Power Levels	1
UPC	021331940841
Global Trade Identification Number	00021331940841
Manufacturer	Altec Lansing
Package Dimensions	12.69 x 9.77 x 6.86 inches
Item Weight	3 pounds
ASIN	B07PX3ZKLF
Item model number	IMQ610-WHT

Batteries	1 Lithium Ion batteries required. (included)
Date First Available	March 26, 2019
Brand	Altec Lansing
Speaker Maximum Output Power	3 Watts
Connectivity Technology	Bluetooth, USB
Audio Output Mode	Stereo
Mounting Type	Tabletop Mount

MAINTENANCE

To ensure the longevity and optimal performance of your Altec Lansing Octave speaker, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the exterior surfaces of the speaker. Avoid using abrasive cleaners, solvents, or strong chemicals, as they may damage the finish.
- **Storage:** When not in use for extended periods, store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Water Resistance:** The speaker is IPX4 splashproof, meaning it can withstand splashes of water. Do not submerge the speaker in water or expose it to heavy rain. Ensure all port covers are securely closed when near water.
- **Battery Care:** For optimal battery life, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in constant use.

TROUBLESHOOTING

If you encounter issues with your Altec Lansing Octave speaker, refer to the following common troubleshooting steps:

- **No Power:** Ensure the AC adapter is securely connected to both the speaker and a working wall outlet. Check if the power button is pressed and held for 1-2 seconds to turn on.
- **No Sound:** Verify that the speaker is powered on and successfully paired via Bluetooth. Check the volume levels on both the speaker and your connected device. Ensure the audio source is playing.
- **Bluetooth Disconnection/Pairing Issues:** Make sure the speaker is within the Bluetooth range (up to 30.48 meters). Try disconnecting and re-pairing the device. If issues persist, perform a Bluetooth reset or a full connection reset as described in the 'Reset Options' section.
- **Wireless Charging Not Working:** Ensure your smartphone is Qi-compatible. Reposition the phone on the charging pad to ensure proper alignment. Remove any thick phone cases that might interfere with wireless charging.
- **Clock Not Displaying Correct Time:** Use the 'Time Set', 'Down', and 'Up' buttons on the back of the speaker to manually adjust the time.

If these steps do not resolve the issue, please contact customer support.

WARRANTY AND SUPPORT

The Altec Lansing Octave Wireless Bluetooth Speaker comes with a Limited Warranty. For detailed warranty information and terms, please refer to the documentation included with your product.

For additional support, frequently asked questions, or to explore other Altec Lansing products, please visit the official Altec Lansing website or their Amazon store:

- Official Website: www.alteclansing.com
- Altec Lansing Amazon Store: [Visit the Altec Lansing Store](#)

