

[manuals.plus](#) /

› [Braun](#) /

› [Braun Silk-épil 5 SE5-895 Epilator Instruction Manual](#)

Braun SE5-895

Braun Silk-épil 5 SE5-895 Epilator Instruction Manual

Model: SE5-895 | Brand: Braun

1. PRODUCT OVERVIEW

The Braun Silk-épil 5 SE5-895 is a versatile 5-in-1 hair removal and beauty set designed for face and body. This device allows you to epilate, shave, trim, cleanse, and exfoliate, providing long-lasting smooth skin. It is 100% waterproof, cordless, and rechargeable, making it suitable for use in the bath or shower to enhance comfort during epilation.

Key Features:

- **Long-Lasting Results:** Epilates hair 4x shorter than wax, providing smooth skin for up to 4 weeks.
- **All-in-One Solution:** Includes interchangeable heads for epilation, shaving, trimming, and facial cleansing/exfoliation.
- **Wet & Dry Use:** Designed for use in the shower or bath to reduce discomfort, featuring an anti-slip grip.
- **Cordless & Rechargeable:** Offers convenience and portability for use anywhere.
- **Painless Epilation:** With regular use in water, epilation becomes virtually painless.

Weeks of smooth skin, not days



4 weeks of salon-like smooth skin

BRAUN



28 micro-grip tweezers



3-in-1 epilate, shave, or trim



Removes hair 4x shorter than waxing



Massage roller cap reduces pain



World's #1
Epilation Brand

Image: Braun Silk-épil 5 Epilator highlighting features such as 4 weeks of smooth skin, 28 micro-grip tweezers, 3-in-1 functionality (epilate, shave, trim), massage roller cap to reduce pain, and its ability to remove hair 4x shorter than waxing.

Understanding Epilation

Epilation removes hair from the root, similar to waxing, but with key differences that can make it more convenient and effective for shorter hairs. Unlike waxing, epilators use tiny tweezers to pull out hair without lifting the skin, allowing for hair removal at shorter lengths.

Your browser does not support the video tag.

Video: This video explains the differences between epilation and waxing, detailing how each method removes hair and their respective benefits.

Your browser does not support the video tag.

Video: This video highlights the various benefits of epilating, such as long-lasting smoothness and efficiency.

How does epilation work?

Unlike stubbly wet shaving, tiny tweezers pull out the hair at the root without impacting the skin's surface



Image: A diagram showing how epilation works, with tiny tweezers pulling hair from the root, contrasting with stubbly wet shaving. It also notes that hair grows back thinner and finer with every use.

2. WHAT'S INCLUDED

Your Braun Silk-épil 5 SE5-895 set comes with the following components:

What's included?



Included but not pictured: Power Cord

Image: This image displays all the items included in the Braun Silk-épil 5 set: the Silk-épil 5 Device, Normal Brush, Exfoliation Brush, Skin Contact Cap, FaceSpa device, Beauty Sponge, Trimmer Cap, Pouch, and Cleaning Brush. The Power Cord is also included but not pictured.

- **Silk-épil 5 Device:** The main epilator unit.
- **Normal Brush:** For general body cleansing.
- **Exfoliation Brush:** Helps remove dead skin cells to prevent ingrown hairs.
- **Skin Contact Cap:** Guides the epilator for optimal skin contact.
- **FaceSpa Device:** A separate handheld unit for facial care.
- **Beauty Sponge:** For applying creams or makeup.
- **Trimmer Cap:** For precise trimming in sensitive areas.
- **Pouch:** For convenient storage and travel.
- **Cleaning Brush:** To clean the epilator head.
- **Power Cord:** For charging the device.

3. SETUP

Charging the Device

1. Ensure the device is switched off.
2. Connect the power cord to the epilator and plug it into an electrical outlet.
3. Allow the device to charge fully before first use. A full charge typically provides up to 30 minutes of cordless operation.

Attaching/Detaching Heads

1. To attach a head (epilator head, shaver head, exfoliation brush, facial brush), align it with the main body of the device and press firmly until it clicks into place.
2. To detach a head, press the release button (if applicable) and pull the head away from the device.

4. OPERATING INSTRUCTIONS

Epilation (Legs & Body)

For optimal results and reduced discomfort, especially for first-time users, consider epilating in warm water (wet use).



Image: A step-by-step guide titled 'Epilation 101'. It advises to exfoliate before epilating, epilate in water for comfort (especially

for beginners), hold the device at a 90-degree angle against hair growth, move slowly and steadily (approx. 15 seconds from ankle to knee), and moisturize after epilating for smooth skin.

- 1. Prepare Skin:** Exfoliate your skin 1-2 days before epilation to prevent ingrown hairs.
- 2. Wet or Dry:** Use the epilator on dry skin or in the bath/shower with warm water. Warm water helps to relax the skin and reduce discomfort.
- 3. Hold Correctly:** Hold the epilator at a 90-degree angle to your skin, moving it against the direction of hair growth.
- 4. Movement:** Glide the epilator slowly and steadily over your skin. Do not press too hard. The SensoSmart™ light will turn red if you are applying too much pressure.
- 5. Speed Settings:** The device typically has two speed settings. Start with a lower speed if you are new to epilation or have sensitive skin.
- 6. Moisturize:** After epilation, apply a soothing lotion or moisturizer to your skin.

Your browser does not support the video tag.

Video: This video provides 5 top tips for individuals epilating for the first time, offering guidance for a smoother experience.

Shaving & Trimming

Attach the shaver head for a close shave or the trimmer cap for precise hair trimming in sensitive areas like the bikini line or underarms. Use on dry or wet skin as preferred.

Facial Cleansing

Use the dedicated facial cleansing brush with your favorite facial cleanser. This brush is designed to gently exfoliate and cleanse your face, removing makeup and impurities more effectively than manual cleansing.



Facial Cleansing Brush

Use the brush to prep your face for epilation. It is up to **6x better at removing makeup***

*than manual cleansing alone

Image: A woman using the facial cleansing brush on her face, demonstrating how to use it to prepare the face for epilation and noting its ability to remove makeup up to 6x better than manual cleansing.

Body Exfoliation

Attach the body exfoliation brush to gently remove dead skin cells from your body. This helps to prevent ingrown hairs and leaves your skin feeling smoother.

5. MAINTENANCE AND CLEANING

- Cleaning the Epilator Head:** After each use, switch off the device and remove the epilator head. Use the provided cleaning brush to remove any trapped hairs. For thorough cleaning, you can rinse the epilator head under running water.
- Cleaning Brushes:** Rinse the facial and exfoliation brushes under running water after each use. Allow them to air dry completely before storing.
- Shaver Head:** Clean the shaver head with the cleaning brush. The foil and cutter block can also be rinsed under water.
- Storage:** Store the device and its attachments in the provided pouch in a dry place.

6. TROUBLESHOOTING

Pain or Discomfort During Epilation

It is normal to experience some discomfort during your first few epilation sessions, especially in sensitive areas. However, this sensation typically decreases with regular use.

- **Use Wet:** Epilating in warm water (bath or shower) can significantly reduce discomfort.
- **Exfoliate:** Regular exfoliation helps prevent ingrown hairs, which can contribute to discomfort.
- **Stretch Skin:** Gently stretch your skin taut with your free hand to help the epilator glide more smoothly.
- **Massage Rollers:** Utilize the massage roller cap to stimulate the skin and minimize pulling sensation.

Your browser does not support the video tag.

Video: This video offers advice on managing pain during epilation, providing tips to make the experience more comfortable.

Missed Hairs

- **SensoSmart™ Technology:** The device features a SensoSmart™ light that guides you to apply the right amount of pressure. If the light turns red, you are pressing too hard.
- **Proper Angle:** Ensure you are holding the epilator at a 90-degree angle to your skin.
- **Slow Movement:** Glide the epilator slowly to allow the tweezers to catch all hairs.

Your browser does not support the video tag.

Video: This video provides a general overview of the Braun Silk-épil 5 Epilator, showcasing its features and how it operates.

7. SPECIFICATIONS

Feature	Detail
Product Dimensions	2.76 x 10.24 x 7.76 inches
Item Weight	1.22 Pounds
Item Model Number	ipl1
Batteries	1 Lithium Ion batteries required (included)
UPC	069055885314
Manufacturer	Procter & Gamble
Water Resistance Level	Waterproof
Color	White
Power Source	Battery Powered

8. WARRANTY AND SUPPORT

For warranty information, product registration, or further support, please refer to the documentation included in your product packaging or visit the official Braun website.

