



[Manuals.plus](#) /

› [Simply3](#) /

› Simply3 Young Explorers Adventure Climber and Slide Instruction Manual

## Simply3 21813R-01

# Simply3 Young Explorers Adventure Climber and Slide Instruction Manual

Model: 21813R-01

## INTRODUCTION

---

Thank you for choosing the Simply3 Young Explorers Adventure Climber and Slide. This playset is designed to provide a safe and engaging environment for toddlers and young children, encouraging active play both indoors and outdoors. Please read this manual thoroughly before assembly and use to ensure proper setup and safe operation.

# young explorers ADVENTURE CLIMBER



Image: The Simplay3 Young Explorers Adventure Climber and Slide, showcasing its multi-level design and slide, with two children playing.

## SAFETY INFORMATION

---

**WARNING:** Adult supervision is required at all times. Failure to follow these instructions may result in serious injury.

- Ensure the playset is assembled correctly and all fasteners are secure before use.
- Place the playset on a level, soft surface, such as grass or a play mat, away from hard surfaces, fences, or other obstacles.
- Do not allow children to climb on the playset when wet, as surfaces may be slippery.
- Maximum weight recommendation: 180 pounds.
- Recommended age range: 1.5 to 6 years old.
- Inspect the playset regularly for loose parts, damage, or wear. Replace or repair components as needed.
- Keep children away from the playset during assembly.

## PACKAGE CONTENTS

---

Verify that all components are present before beginning assembly. The package includes all necessary plastic molded parts, fasteners, and a steering wheel for the fort area. Refer to the included assembly diagram for a complete list of parts.

## SETUP AND ASSEMBLY

Assembly is designed to be straightforward. A handheld drill/screwdriver is recommended for faster and easier installation of fasteners.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, flat surface.
2. **Assemble Base Sections:** Connect the main base panels according to the provided diagram, ensuring all interlocking tabs and screw points align.
3. **Attach Platforms:** Secure the two-tiered platforms to the base structure using the designated fasteners.
4. **Install Slide:** Attach the wide slide to the designated opening on the playset. Ensure it is firmly secured.
5. **Add Handrails and Steering Wheel:** Install the easy-grip handrails on the climbing areas and attach the steering wheel inside the ground-level fort.
6. **Final Check:** Once assembled, ensure all connections are tight and stable. The playset should be sturdy and free of wobbles.



Image: An exploded view diagram highlighting key features like the wide slide, easy-grip holds, large crawl-through area, and fort with steering wheel.

## OPERATING INSTRUCTIONS

---

The Simplay3 Young Explorers Adventure Climber and Slide offers multiple play activities:

- **Climbing:** Children can use the integrated ladder and handholds to climb to the two-tiered platforms.
- **Sliding:** The wide slide provides a secure and fun descent from the lower platform.
- **Crawling:** A ground-level entry leads to a secret fort area, perfect for imaginative play.
- **Pretend Play:** The steering wheel inside the fort encourages role-playing and creative scenarios.

This playset is suitable for both indoor and outdoor use. Its design allows it to fit through standard doorframes for easy relocation.



Image: Children enjoying the playset in both an indoor setting on a play mat and an outdoor backyard environment.

## MAINTENANCE

---

To ensure the longevity and safety of your Simplay3 playset:

- **Cleaning:** The double-wall plastic construction is easy to clean. Use mild soap and water with a soft

cloth. Avoid abrasive cleaners that may damage the plastic.

- **Inspection:** Regularly check all parts for cracks, breaks, or loose fasteners. Tighten any loose screws.
- **Weather Resistance:** The playset is weather and UV resistant, designed to withstand outdoor conditions. However, prolonged exposure to extreme weather may accelerate wear.
- **Storage:** If storing indoors for extended periods, ensure the playset is clean and dry.



Image: The Simplay3 Adventure Climber with visual indicators highlighting its durable construction, including UV resistance, rounded edges, ease of cleaning, recyclability, and long-lasting design.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Playset feels wobbly after assembly.	Fasteners are not fully tightened or playset is on an uneven surface.	Ensure all screws and connections are securely tightened. Move the playset to a level surface.
Parts do not fit together during assembly.	Incorrect orientation of parts or misalignment.	Refer to the assembly diagram to ensure parts are oriented correctly. Apply gentle pressure to align.
Plastic surface appears dirty or stained.	Accumulation of dirt, dust, or environmental residue.	Clean with mild soap and water using a soft cloth or sponge. For stubborn stains, a non-abrasive household cleaner can be used.

## SPECIFICATIONS

- **Material:** Durable, double-wall plastic construction
- **Product Dimensions (L x W x H):** 70" x 28.5" x 49.5"
- **Item Weight:** 52.43 Pounds
- **Maximum Weight Recommendation:** 180 Pounds

- **Age Range:** 1.5 - 6 years old (18 to 72 months)
- **Color:** Multi-color
- **Model Number:** 21813R-01
- **UPC:** 852806007864
- **Assembly:** Required
- **Origin:** Made in the USA

# DIMENSIONS



**Simplay3**

Image: A diagram illustrating the length (70"), width (28.5"), and height (49.5") of the Simplay3 Young Explorers Adventure Climber.

## WARRANTY AND SUPPORT

Simplay3 products are built to last and designed with quality in mind. For specific warranty details, please refer to the official Simplay3 website or the documentation included with your purchase. For customer support, inquiries, or to report missing/damaged parts, please contact Simplay3 directly through their official channels. A user guide in PDF format is available for download from the product page on Amazon.com.

**Return Policy:** This product is eligible for a 30-day easy return policy from the date of purchase.

**Contact Information:** For assistance, please visit the [Simplay3 Store on Amazon](#) or their official website.

