

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [HP](#) /
- › [HP 15 Laptop \(Model 6SB28UA\) User Manual](#)

HP 6SB28UA

HP 15 Laptop User Manual

Model: 6SB28UA

1. INTRODUCTION

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your HP 15 Laptop. Designed for everyday use, this laptop combines performance with portability, featuring an 8th Gen Intel Core i7 processor, 12GB of RAM, and a 256GB Solid State Drive.

The 15.6-inch HD display offers clear visuals, while integrated Wi-Fi and Bluetooth connectivity ensure you stay connected. This laptop runs on Windows 10 Home, providing a familiar and efficient operating environment.



Figure 1: HP 15 Laptop (Model 6SB28UA)

2. COMPONENT IDENTIFICATION

2.1 Front and Top View

- **Display:** 15.6-inch HD WLED-backlit screen.
- **Webcam:** Front-facing HP TrueVision HD Webcam with integrated digital microphone.
- **Keyboard:** Full-size, island-style keyboard with numeric keypad.
- **Touchpad:** Multi-touch gesture support.
- **Power Button:** Located above the keyboard.

2.2 Side Views (Ports and Connectors)



Figure 2: Left Side Ports

- **Power Connector:** For connecting the AC adapter.
- **Multi-format Digital Media Card Reader:** Supports various memory card types (e.g., SD cards).
- **USB 2.0 Port:** For connecting USB devices.
- **Optical Drive:** For reading and writing CDs/DVDs.



Figure 3: Right Side Ports

- **Security Lock Slot:** For attaching a security cable (sold separately).
- **Ethernet Port (RJ-45):** For wired network connection.
- **HDMI Port:** For connecting to an external display or HDTV.
- **USB 3.0 Ports (x2):** For connecting high-speed USB devices.
- **Headphone/Microphone Combo Jack:** For audio input/output.

3. SETUP

3.1 Unboxing and Initial Charge

1. Carefully remove the laptop and all accessories from the packaging. The box should contain the HP 15 Laptop and an AC Adapter.
2. Connect the AC adapter to the power connector on the side of the laptop and then plug it into a power outlet.
3. Allow the laptop to charge for at least 30 minutes before initial use, or until the battery indicator shows a sufficient charge.

3.2 First Power On and Windows Setup

1. Press the power button to turn on the laptop.
2. Follow the on-screen instructions to complete the Windows 10 Home setup process. This includes selecting your region, language, accepting terms, and creating a user account.
3. Connect to a Wi-Fi network when prompted to ensure your system can download necessary updates.

3.3 Connecting to a Network

- **Wireless (Wi-Fi):** Click the network icon in the taskbar, select your desired Wi-Fi network, enter the password, and click Connect.
- **Wired (Ethernet):** Connect an Ethernet cable from your router or modem to the Ethernet port on the laptop.

4. OPERATING YOUR LAPTOP

4.1 Power Management

- **Power On:** Press the power button.
- **Sleep Mode:** Close the lid or select 'Sleep' from the Start menu.
- **Shut Down:** Go to Start > Power > Shut down.
- **Restart:** Go to Start > Power > Restart.

4.2 Using the Keyboard and Touchpad

- **Keyboard:** Type as you would on a standard keyboard. Use the function keys (F1-F12) for special features, often requiring the 'Fn' key.
- **Touchpad:** Move your finger across the surface to control the cursor. Tap to click, use two fingers to scroll, and pinch to zoom.

4.3 Connecting External Devices

- **USB Devices:** Plug USB drives, mice, or other peripherals into the available USB 2.0 or USB 3.0 ports.
- **External Display (HDMI):** Connect an HDMI cable from the laptop's HDMI port to an external monitor or TV. Press **Windows key + P** to select display mode.
- **Bluetooth Devices:** Enable Bluetooth in Windows settings, then pair with devices like headphones or speakers.

4.4 Battery Management

- To maximize battery life, adjust power settings in Windows, reduce screen brightness, and close unused applications.
- The battery is designed to last up to 10.25 hours under optimal conditions.

5. MAINTENANCE

5.1 Cleaning Your Laptop

- Use a soft, lint-free cloth slightly dampened with water or a screen cleaner for the display.
- For the keyboard and chassis, use a soft cloth. Avoid harsh chemicals or abrasive materials.
- Periodically clean dust from vents using compressed air to ensure proper airflow and prevent overheating.

5.2 Software Updates

- Regularly check for and install Windows updates to ensure system security and performance. Go to Start > Settings > Update & Security > Windows Update.
- Keep your drivers updated. HP provides driver updates on its official support website.

5.3 Data Backup

- Regularly back up your important files to an external hard drive, USB drive, or cloud storage service to prevent data loss.

6. TROUBLESHOOTING

6.1 Common Issues and Solutions

- **Laptop does not power on:** Ensure the AC adapter is securely connected and the power outlet is functional. Try a different outlet.
- **No display on screen:** Connect an external monitor to check if the issue is with the laptop's display. Ensure brightness is not set to minimum.
- **Wi-Fi connection issues:** Check if Wi-Fi is enabled in Windows settings. Restart your router and modem. Ensure drivers are up to date.
- **Slow performance:** Close unnecessary applications. Check for malware. Ensure sufficient free space on the SSD.
- **Keyboard or touchpad not responding:** Restart the laptop. Check for driver updates.

For more detailed troubleshooting, refer to the HP support website or contact customer service.

7. SPECIFICATIONS

Feature	Specification
Model Number	6SB28UA
Display Size	15.6 Inches
Screen Resolution	1366 x 768 pixels (HD)
Processor	8th Gen Intel Core i7-8565U (1.8 GHz base, up to 4.6 GHz)
RAM	12 GB DDR4
Storage	256 GB SSD

Feature	Specification
Graphics	Intel UHD Graphics 620 (Integrated)
Wireless Connectivity	802.11ac Wi-Fi, Bluetooth
Ports	1x USB 2.0, 2x USB 3.0, 1x HDMI, 1x RJ-45 Ethernet, 1x Headphone/Mic Combo, 1x Multi-format SD Card Reader
Optical Drive	Yes
Operating System	Windows 10 Home (64-bit)
Battery Life	Up to 10.25 Hours
Weight	4.2 pounds
Dimensions (LxWxH)	14.8 x 0.9 x 9.7 inches

8. WARRANTY AND SUPPORT

For detailed warranty information, product registration, and technical support, please visit the official HP support website. You can find drivers, manuals, and troubleshooting guides specific to your model (6SB28UA) there.

HP Support Website: <https://support.hp.com>

Please have your product model number (6SB28UA) and serial number ready when contacting support.