Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- > INSMY /
- > INSMY C12 IPX7 Waterproof Shower Bluetooth Speaker User Manual

INSMY C12

INSMY C12 IPX7 Waterproof Shower Bluetooth Speaker User Manual

Model: C12 | Brand: INSMY

1. Introduction

Thank you for choosing the INSMY C12 IPX7 Waterproof Shower Bluetooth Speaker. This portable speaker is designed to provide high-quality audio in various environments, including showers, outdoor activities, and travel. Its robust waterproof and shock-absorbent design ensures durability, while its versatile connectivity options offer a seamless listening experience.



Figure 1: The INSMY C12 speaker in cashmere pink, shown with water splashing around it, highlighting its waterproof design.

2. PRODUCT OVERVIEW

2.1. Package Contents


- INSMY C12 Bluetooth Speaker
- USB Charging Cable
- Instruction Book
- Detachable Suction Cup
- Lanyard

2.2. Controls and Ports

The INSMY C12 speaker features intuitive controls located on its back panel and a sealed port for charging and TF card access.

• Power Button: Press and hold to power on/off.

- Play/Pause Button: Press to play or pause music.
- Volume Up (+): Increase volume.
- Volume Down (-): Decrease volume.
- Next Track (>>|): Skip to the next song.
- Previous Track (|<<): Go to the previous song.
- Microphone: For hands-free calling.
- USB Charging Port: For charging the device.
- TF Card Slot: For playing music directly from a Micro SD card.





3. SETUP

3.1. Initial Charging

Before first use, fully charge your INSMY C12 speaker. Connect the provided USB charging cable to the speaker's charging port and plug the other end into a USB power adapter (not included) or a computer's USB port. The charging time is approximately 3 hours for a full charge, providing up to 12 hours of playtime.



Figure 3: The INSMY C12 speaker, highlighting its long-lasting 12-hour battery life, suitable for extended use.

3.2. Bluetooth Pairing

- 1. Ensure the speaker is fully charged.
- 2. Press and hold the Power button on the back of the speaker until you hear a power-on tone and the LED indicator starts flashing, indicating it's in pairing mode.
- 3. On your smartphone, tablet, or other Bluetooth-enabled device, go to the Bluetooth settings.

- 4. Search for "INSMY-C12" in the list of available devices and select it.
- 5. Once connected, you will hear a confirmation tone, and the LED indicator will stop flashing and remain solid.

3.3. TF Card Insertion

To play music directly from a TF (Micro SD) card, gently open the waterproof cover on the side of the speaker. Insert your TF card into the designated slot until it clicks into place. The speaker will automatically switch to TF card playback mode if a card with music files is detected.

4. OPERATING INSTRUCTIONS

4.1. Music Playback

- Play/Pause: Press the Play/Pause button.
- Volume Control: Press the '+' button to increase volume, and the '-' button to decrease volume.
- **Next/Previous Track:** Press the '>>|' button for the next track or '|<<' button for the previous track.

4.2. Hands-Free Calling

With its built-in microphone, the INSMY C12 allows for hands-free calls when connected via Bluetooth to your smartphone.

- Answer Call: Press the Play/Pause button once when a call comes in.
- End Call: Press the Play/Pause button once during a call.
- Reject Call: Press and hold the Play/Pause button for 2 seconds.



Figure 4: The INSMY C12 speaker conveniently mounted on a shower wall using its suction cup, illustrating its ideal placement for inshower use.

5. MAINTENANCE

5.1. Cleaning

To maintain the speaker's performance and appearance, wipe it with a soft, damp cloth. Do not use abrasive cleaners or solvents. Ensure the charging port cover is securely closed after charging to maintain its waterproof integrity.

5.2. Storage

Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, charge the battery periodically to prolong its lifespan.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery.	Charge the speaker fully.
Cannot pair with Bluetooth device.	Speaker not in pairing mode; device too far; Bluetooth off on device.	Ensure speaker is in pairing mode (flashing LED). Move device closer. Turn on Bluetooth on your device.
Poor sound quality or distortion.	Low battery; device too far; interference.	Charge the speaker. Move device closer. Avoid obstacles or other wireless devices.
TF card not recognized.	Card inserted incorrectly; unsupported file format.	Reinsert TF card correctly. Ensure music files are in a supported format (e.g., MP3).

7. SPECIFICATIONS

Model Name: INSMY-C12

Water Resistance: IP67 (Fully submersible up to 1 meter for 30 minutes)

Connectivity: Bluetooth 5.0, TF Card, USB

Battery Capacity: 1200mAh **Playtime:** Up to 12 hours

Charging Time: Approximately 3 hours

Output Power: 5 Watts

Frequency Response: 20 KHz

Audio Output Mode: Mono

Dimensions (D x W x H): 3.46" x 3.46" x 1.2"

Item Weight: 7.4 Ounces

Special Features: Portable, Waterproof, Stereo Pairing, Built-in Microphone, Shockproof, Suction cup




Figure 5: The INSMY C12 speaker demonstrating its IPX7 waterproof rating by being submerged in water, capable of immersion up to 1 meter for 30 minutes.

8. WARRANTY AND SUPPORT


The INSMY C12 speaker comes with a limited warranty. For detailed warranty information, product support, or to register your product, please visit the official INSMY brand store or contact customer service through the retailer where you purchased the product.

For further assistance, please refer to the contact information provided in your product packaging or visit the NSMY Brand Store.

Related Documents - C12

	C12 Wireless Earbuds User Manual and Specifications Comprehensive guide for C12 wireless earbuds, covering features, operation, specifications, troubleshooting, and FCC compliance. Learn how to pair, control, and maintain your earbuds.
	Viessmann Vitocrossal 200 C12 Installation and Start-up Guide A comprehensive guide for licensed professional heating contractors on the installation and start-up of the Viessmann Vitocrossal 200 C12 gas condensing boiler. Covers unpacking, positioning, access, connections, electrical wiring, venting, and initial setup procedures.
10 5.7 2 5 10 5 0 5 0 5 0 5 0 5 0 5 0 5 0 5 0 5	INSMY C17Max Mini Speaker User Manual and Specifications This user manual provides comprehensive instructions for the INSMY C17Max Mini Bluetooth Speaker. It covers setup, true wireless stereo pairing, troubleshooting common issues, warranty service, customer support, and detailed specifications. Learn how to connect, play music, answer calls, and charge your device safely. Includes important safety prompts and regulatory compliance information.
0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	IDE11 C12 Wireless Earbuds User Manual User manual for IDE11 C12 wireless earbuds. Learn how to auto-pair, connect via Bluetooth, control music and calls, activate voice assistant, manage power, and troubleshoot. Features include 30-hour playtime, IPX7 water resistance, and CVC 8.0 noise cancellation.
4 110 0 1 0 1 0 1 0 1 0 1 0 1 0 1 0 1 0	INSMY-C17Max Mini Speaker: User Manual, Features, and Specifications Comprehensive user manual for the INSMY-C17Max Mini Speaker, covering setup, Bluetooth pairing, controls, troubleshooting, warranty, and technical specifications.
	Zhangzhou Aiwei IoT Technology C12-H Surveillance Camera User Manual User manual for the Zhangzhou Aiwei IoT Technology C12-H Surveillance Camera, providing instructions and specifications.

Documents - INSMY - C12



The Radio Manual: A Comprehensive Guide to Radio Technology

Explore the foundational principles of radio technology with 'The Radio Manual' by George E. Sterling. This comprehensive guide, edited by Robert S. Kruse and published by D. Van Nostrand Company, covers electricity, magnetism, motors, generators, batteries, vacuum tubes, and radio apparatus, essential for engineers, students, and enthusiasts.

lang:en score:11 filesize: 14.58 M page_count: 806 document date: 2021-04-17



VT82C686A "Super South" South Bridge

PSIPC
PCI Super-I/O Integrated Peripheral Controller

PC99 COMPLIANT TCI.TO-ISA BRIDGE
WITH INTEGRATED SUPER-I/O (FDC, LPT, COM1/2, AND IR),
NTEGRATED SUMBLASTER/IDBRECTSOUND ACT AUDIO,
ULTRADMA-33/66 MASTER MODE PCI-EIDE CONTROLLER,
USB CONTROLLER, KEYBOARD CONTROLLER, RTC,
DISTRIBUTED DIMA, SERIAL IRQ, PLUG AND PLAY,
ACPI, ENHANGED POWER MANAGEMENT, SIMBUS, AND
TEMPERATURE, VOLTAGE, AND FAN-SPEED MONITORING

Revision 1.82 March 2, 2001 VIA TECHNOLOGIES, INC.

VT82C686A "Super South" South Bridge Datasheet

Technical datasheet for the VIA VT82C686A "Super South" South Bridge, a PSIPC PCI Super-I/O Integrated Peripheral Controller. Details features, registers, pinouts, and specifications.

lang:i-klingon score:8 filesize: 1.15 M page_count: 130 document date: 2001-06-01