Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Passion-Electro RAK-EHA28WH

Replacement Remote Control User Manual

Model: RAK-EHA28WH for TECHNICS

Brand: Passion-Electro

1. Product Overview

This specialized replacement remote control is designed to provide full functionality for your TECHNICS RAK-EHA28WH device. It is not a universal remote and requires no programming. Simply install the batteries to begin operation, replicating the functions of your original remote control.

2. Setup Instructions

2.1 Battery Installation

The remote control requires two 1.5V AAA (LR03) batteries. Batteries are not included.

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery compartment cover.
3. Insert two AAA batteries, ensuring correct polarity (+ and -) as indicated inside the compartment.
4. Close the battery compartment cover securely.



Image showing the underside of the remote control with the battery compartment cover. To open, slide the cover downwards to access the battery slots.

3. Operating Instructions

Once batteries are installed, the remote control is ready for immediate use. No additional programming or setup is required. Point the remote control directly at your TECHNICS RAK-EHA28WH device's infrared sensor.

3.1 Key Functions

The remote control provides access to all functions of the original remote. The button layout is designed to be intuitive. Refer to your device's original manual for specific function details if needed.



This image displays the full top surface of the remote control, highlighting the arrangement of all functional buttons, including power, volume, channel, navigation, and special function keys.

4. Maintenance

4.1 Battery Replacement

Replace batteries when the remote control's response becomes sluggish or stops working. Always replace both batteries simultaneously with new 1.5V AAA (LR03) batteries. Do not mix old and new batteries or different battery types.

4.2 Cleaning

To clean the remote control, use a soft, dry cloth. Do not use liquid cleaners, solvents, or abrasive materials, as these may damage the surface or internal components.

5. Troubleshooting

- **Remote not responding:**
  Ensure batteries are installed correctly with the correct polarity. Replace old batteries with new ones. Check

for any obstructions between the remote and the device's infrared sensor. Ensure the remote is pointed directly at the device.

- **Specific functions not working:**
  Verify that your device supports the function you are trying to use. This remote replicates the original remote's functions; if a function was not present on the original, it will not be available here.

6. Specifications

- **Model Number:** RAK-EHA28WH
- **Brand:** Passion-Electro
- **Battery Type:** 2 x 1.5V AAA (LR03) batteries (not included)
- **Color:** Black
- **Maximum Range:** 10 Meters
- **Compatibility:** Designed for TECHNICS RAK-EHA28WH
- **Country of Origin:** China

7. Warranty and Support

This product is covered by a standard warranty. For warranty claims or technical support, please contact Passion-Electro directly. Refer to your purchase documentation for specific warranty terms and contact information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07PYX4WPQ

More documents and user manuals: **https://manuals.plus/**