Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Passion-Electro BDP103D

Passion-Electro Replacement Remote Control User Manual for OPPO BDP103D

Model: BDP103D

1. Introduction

This manual provides comprehensive instructions for the Passion-Electro Replacement Remote Control, specifically designed for the OPPO BDP103D Blu-ray player. This remote is a direct replacement, offering full functionality without requiring any programming. Simply insert the batteries, and it is ready for immediate use.
Please note that this is not a generic universal remote. The button layout is designed to replicate the original OPPO BDP103D remote control experience.

2. Product Overview

The Passion-Electro Replacement Remote Control for OPPO BDP103D is designed for ease of use and durability. It features a standard button layout for controlling your OPPO BDP103D Blu-ray player.



Figure 2.1: Front view of the remote control, showing all buttons including power, mute, number pad, navigation, and media controls.



Figure 2.2: Side profile of the remote control, illustrating its ergonomic design and slim form factor.



Figure 2.3: Angled view of the remote control, highlighting the button layout and overall shape.



Figure 2.4: Another angled view, providing a clear perspective of the remote's surface and button arrangement.



Figure 2.5: Rear view of the remote control, displaying the battery compartment cover.



Figure 2.6: Bottom view of the remote control, showing the battery compartment and its latch mechanism.

3. Setup: Battery Installation

The remote control requires two (2) AAA 1.5V batteries (LR03-AAA). Batteries are not included with the remote control.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch and lift to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.

Note: *Always use new batteries and replace both batteries at the same time. Do not mix old and new batteries or different types of batteries.*

4. Operating Instructions

This replacement remote control is pre-programmed for the OPPO BDP103D Blu-ray player and requires no additional setup. To operate your device:

1. Ensure the batteries are correctly installed in the remote control.
2. Point the remote control directly at the infrared receiver on your OPPO BDP103D Blu-ray player.
3. Press the desired function button. The remote has a maximum range of 10 meters (approximately 33 feet).

Key Functions:

- **Power Button:** Turns the device on or off.
- **Mute Button:** Mutes or unmutes the audio.
- **Number Pad (0-9):** For direct input of track numbers, channels, or other numerical selections.
- **Navigation Buttons (Up, Down, Left, Right, OK):** Used to navigate menus and confirm selections.
- **Volume Up/Down (V+/V-):** Adjusts the audio volume.
- **Channel Up/Down (P+/P-):** Changes channels or navigates through lists.
- **Back Button:** Returns to the previous menu or screen.
- **Menu/Exit:** Accesses or exits the main menu.
- **Media Control Buttons (Play, Pause, Stop, Fast Forward, Rewind):** Controls media playback.
- **Colored Buttons (Red, Green, Yellow, Blue):** Often used for specific functions within menus or applications.
- **Dedicated App Buttons (e.g., NET TV, SMART):** Provides quick access to streaming services or smart features.
- **Info/EPG/Fav:** Accesses information, Electronic Program Guide, or Favorite channels.

5. Maintenance

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Refer to Section 3 for battery installation.
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage. Store in a cool, dry place.

6. Troubleshooting

If you experience issues with your remote control, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Remote is not working.	Dead or incorrectly inserted batteries.	Replace batteries with new AAA batteries, ensuring correct polarity.
Remote works intermittently.	Low battery power or obstruction.	Replace batteries. Ensure there is a clear line of sight between the remote and the OPPO BDP103D.
Remote does not control the device.	Not pointed correctly or device is off.	Ensure the remote is pointed directly at the OPPO BDP103D. Verify the OPPO BDP103D is powered on.

7. Specifications

- **Brand:** Passion-Electro
- **Model:** BDP103D

- **Compatible Devices:** OPPO BDP103D
- **Connectivity Technology:** Infrared
- **Battery Type:** 2 x AAA (Alkaline, 1.5V)
- **Batteries Included:** No
- **Item Weight:** Approximately 100 grams
- **Maximum Range:** 10 meters
- **Special Feature:** Universal (in terms of broad compatibility with the specified model, not a generic universal remote)

8. Warranty and Support

This Passion-Electro replacement remote control is a new product designed to offer functionality similar to an original remote. Specific warranty details are not provided in the product information.
For any support inquiries or further assistance, please contact the seller directly through your purchase platform. Ensure you have your order details available when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07PZTMKPM

More documents and user manuals: **https://manuals.plus/**