

[Manuals.plus](#) /

› [VOUNOT](#) /

› VOUNOT Folding Shopping Trolley with 6 Stair Climbing Wheels User Manual

VOUNOT Folding Shopping Trolley with 6 Stair Climbing Wheels

VOUNOT Folding Shopping Trolley with 6 Stair Climbing Wheels User Manual

Model: Folding Shopping Trolley with 6 Stair Climbing Wheels | Brand: VOUNOT

1. INTRODUCTION

Thank you for choosing the VOUNOT Folding Shopping Trolley. This manual provides essential information for the safe and efficient use of your new trolley. Please read these instructions carefully before assembly and operation, and retain them for future reference. This trolley is designed to assist with transporting groceries and other items, featuring a unique 6-wheel system for easier stair climbing.

2. PRODUCT FEATURES

- **Innovative 6-Wheel Design:** Equipped with three rubber wheels on each side, specifically engineered for smooth stair climbing and even weight distribution.
- **Foldable Frame:** The metal frame folds compactly for convenient storage, saving space when not in use.
- **Removable Storage Bag:** A 30L capacity bag made from durable, waterproof 600D polyester, ideal for daily shopping. It includes a small zippered compartment for valuables.
- **2-in-1 Functionality:** The bag is removable, allowing the trolley frame to be used independently for transporting boxes, cartons, or other bulky items.
- **Lightweight and Durable:** Weighing approximately 2 kg, constructed from sturdy steel, capable of carrying up to 30 kg.
- **All-Terrain Adaptability:** The robust wheel system is designed to navigate various surfaces, including uneven ground, pavement, and stairs.

DÉTAILS PRODUIT PRODUCT DETAILS



Figure 1: Detailed view of the VOUNOT Shopping Trolley's components, highlighting the metal frame, comfortable handle, waterproof bag, internal pocket, plastic base, and the unique 3-pivot wheel system.

3. SETUP INSTRUCTIONS

The VOUNOT Shopping Trolley requires minimal assembly. Follow these steps to prepare your trolley for use:

1. **Unfold the Frame:** Carefully pull the handle upwards and extend the base frame until it locks into place. Ensure all joints are securely engaged.
2. **Attach the Wheels:** The 6-wheel assembly is typically pre-attached. If not, align the wheel axles with the designated slots on the frame and push firmly until they click into place. Ensure all wheels rotate freely.
3. **Install the Shopping Bag:** Place the removable shopping bag onto the trolley frame. Secure it using the Velcro straps or hooks provided, ensuring it sits firmly on the plastic base.

CHARIOT PLIABLE POUR RANGEMENT GAIN DE PLACE FOLDING CART FOR STORAGE OPTIMIZATION



Figure 2: Visual guide to folding and unfolding the trolley frame for storage optimization, and demonstrating its dual function as a cart for transporting various items.

4. OPERATING INSTRUCTIONS

4.1 General Use

- **Loading:** Place items evenly inside the shopping bag. Do not exceed the maximum weight capacity of 30 kg (66 lbs). For heavy items, distribute weight to maintain balance.
- **Transporting:** Hold the comfortable handle firmly and pull the trolley behind you. The 6-wheel system is designed to roll smoothly on flat surfaces.

SAC GRANDE CAPACITÉ DE 30L 30L CAPACITY BAG

*IDÉAL POUR VOS COURSES QUOTIDIENNES !
PERFECT FOR YOUR DAILY SHOPPING !*



Figure 3: Illustrates the ample 30L capacity of the shopping bag, perfect for accommodating a variety of daily groceries.

4.2 Stair Climbing

The unique 6-wheel design simplifies navigating stairs:

1. **Ascending Stairs:** Approach the stairs with the trolley. Gently pull the trolley upwards, allowing the rotating wheel clusters to roll over each step. Maintain a steady pace and firm grip on the handle.
2. **Descending Stairs:** Carefully guide the trolley down the stairs, allowing the wheels to rotate and descend step by step. Exercise caution and control the speed.



Figure 4: The VOUNOT trolley in action, showcasing its ease of use on stairs due to the innovative 6-wheel design. Also shown are the trolley's folded state and its use as a utility cart.




Figure 5: A visual representation of the 3-pivot climbing wheel system, demonstrating its rotational movement for effortless stair navigation.

4.3 2-in-1 Function (Utility Cart)

To use the trolley as a utility cart:

1. **Remove the Bag:** Detach the shopping bag from the frame by unfastening any securing straps or Velcro.
2. **Load Items:** Place cartons, boxes, or other items directly onto the plastic base of the trolley. For stability, it is recommended to secure items with bungee cords (not included).

S'ADAPTE À TOUS TYPES DE SURFACE ADAPT TO ALL KIND OF SURFACE



Figure 6: Demonstrates the trolley's versatility and robust wheel design, allowing it to adapt to various terrains such as concrete, muddy paths, wet surfaces, and gravel.

5. MAINTENANCE

- **Cleaning the Bag:** The polyester bag can be wiped clean with a damp cloth and mild detergent. Allow it to air dry completely before folding or storing. Do not machine wash or tumble dry.
- **Cleaning the Frame and Wheels:** Wipe the metal frame and plastic wheels with a damp cloth. For stubborn dirt, use a mild soap solution. Ensure no water enters the wheel mechanisms.
- **Storage:** When not in use, fold the trolley as instructed in the setup section and store it in a dry place away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically check all screws, bolts, and moving parts to ensure they are secure and functioning correctly. Tighten any loose fasteners.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Wheels do not rotate smoothly.	Dirt or debris in the wheel mechanism; loose attachment.	Clean wheels and axles. Ensure wheels are securely attached to the frame.
Trolley feels unstable.	Overloaded or unevenly distributed weight; frame not fully extended.	Reduce load and distribute weight evenly. Ensure the frame is fully extended and locked.
Shopping bag detaches easily.	Bag not properly secured to the frame.	Ensure all Velcro straps or hooks are firmly attached to the frame.

7. SPECIFICATIONS

Feature	Detail
Brand	VOUNOT
Model	Folding Shopping Trolley with 6 Stair Climbing Wheels
Material (Bag)	100% Polyester 600D (Waterproof)
Material (Frame)	Alloy Steel
Material (Handle)	Rubber
Number of Wheels	6 (3-pivot climbing wheel system)
Bag Capacity	30 Liters
Weight Limit	30 kg (66 lbs)
Item Weight	Approximately 2 kg (4.4 lbs)
Frame Dimensions (Unfolded)	37 cm (W) x 36 cm (D) x 94 cm (H) / 14.6 in (W) x 14.2 in (D) x 37 in (H)
Bag Dimensions	30 cm (W) x 20 cm (D) x 50 cm (H) / 11.8 in (W) x 7.9 in (D) x 19.7 in (H)
Folded Dimensions (Approx.)	37 cm (W) x 61 cm (H) / 14.6 in (W) x 24 in (H)
Wheel Diameter	Ø 11 cm (4.3 in)

TAILLE PRODUIT PRODUCT SIZE



Figure 7: Comprehensive product dimensions for both the trolley frame and the removable shopping bag.

8. WARRANTY AND SUPPORT

VOUNOT products are manufactured to high-quality standards. For any questions, concerns, or support needs regarding your Folding Shopping Trolley, please refer to your purchase documentation or contact the retailer where the product was purchased. Please retain your proof of purchase for warranty claims.

