Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Coolife YD000075

COOLIFE Luggage 3-Piece Set Instruction Manual

1. Introduction

Thank you for choosing the COOLIFE Luggage 3-Piece Set. This manual provides essential information for the proper setup, operation, maintenance, and care of your new luggage. Please read these instructions carefully to ensure optimal performance and longevity of your product.

2. Product Overview

The COOLIFE Luggage 3-Piece Set is designed for durability and ease of travel. Each suitcase features a robust PC+ABS hard shell, smooth spinner wheels, and a secure TSA-approved combination lock. The 28-inch model offers an expandable capacity for additional packing space.



Image: The COOLIFE 3-piece luggage set, showcasing the different sizes and design.

Key Features:

- **Durable Construction:** Made from ABS+PC material for a lighter yet strong hard shell, featuring a textured finish to resist scratches.
- **Smooth Mobility:** Equipped with quiet airplane spinner wheels for 360-degree maneuverability.
- **Adjustable Handle:** A sturdy, adjustable 3-level 100% pure aluminum telescoping handle.
- **Secure Locking:** Built-in TSA-approved combination lock for enhanced security.
- **Expandable Capacity:** The 28-inch suitcase offers an additional 15% scalable space.
- **Organized Interior:** Fully-lined interior with convenient mesh pockets and elastic cross straps.

3. Setup: Setting Your TSA Combination Lock

Your COOLIFE luggage comes with a built-in TSA-approved combination lock. The initial combination is set to **0-0-0**. Follow these steps to set your personal combination:

1. Ensure the lock is set to the default combination **0-0-0**.
2. Locate the small reset button (often a small hole) on the side or top of the lock. Use a pen or a pointed object to press this button until you hear a 'click' sound.
3. While the reset button is pressed, set your desired 3-digit combination by turning the dials to your chosen numbers.
4. Release the reset button by pushing the shackle or the side release tab. You should hear another 'click' sound.
5. Your new combination is now set. Scramble the dials to lock, and use your new combination to unlock.

Important: Remember your combination. There is no master key for personal combinations, and the manufacturer cannot assist in resetting it if forgotten.



Image: Detailed view of the TSA combination lock.

4. Operation

4.1. Telescopic Handle

The luggage features an adjustable 3-level 100% pure aluminum telescoping handle. To extend, press the button on the handle grip and pull upwards. To retract, press the button and push downwards until fully collapsed. Ensure the handle is fully extended or retracted before moving the luggage.



Image: A person demonstrating the extended telescopic handle.

4.2. Spinner Wheels

Equipped with quiet airplane spinner wheels, your luggage can be effortlessly maneuvered in any direction. These wheels provide smooth 360-degree rotation, enhancing stability and ease of transport. For best performance, push the luggage upright rather than tilting and pulling.

4.3. Expandable Capacity (28-inch model only)

The 28-inch suitcase includes an expandable zipper section, increasing its capacity by approximately 15%. To expand, locate the secondary zipper around the perimeter of the suitcase and open it. To return to standard size, close this zipper.



Image: Close-up showing the expandable zipper and other features.

4.4. Interior Organization

The fully-lined interior features a zippered divider, mesh pockets, and elastic cross straps. Use the zippered divider to separate contents, mesh pockets for smaller items, and cross straps to secure clothing and prevent shifting during transit.



Image: The interior of a COOLIFE suitcase, highlighting organizational features.

5. Maintenance and Care

- **Cleaning the Exterior:** Wipe the hard shell exterior with a soft, damp cloth and mild soap. Avoid using abrasive cleaners or harsh chemicals, as these can damage the finish.
- **Cleaning the Interior:** The interior lining can be spot cleaned with a damp cloth and mild detergent. Allow to air dry completely before closing.
- **Wheel Maintenance:** Periodically check the spinner wheels for any accumulated dirt, hair, or debris. Remove any obstructions to ensure smooth rolling.
- **Handle Care:** Keep the telescopic handle free from dirt and debris. If it becomes stiff, a small amount of silicone-based lubricant can be applied to the extending rods.
- **Storage:** When not in use, store your luggage in a cool, dry place away from direct sunlight. The smaller suitcases can be nested inside the larger ones for compact storage.

6. Troubleshooting

Common Issues and Solutions:

- **TSA Lock Not Opening:** Double-check that the correct 3-digit combination is entered. Ensure each dial clicks into place. If the combination was forgotten, the lock cannot be reset without the correct code.
- **Telescopic Handle Sticking:** Check for any visible obstructions or debris in the handle mechanism. Gently pull and push the handle several times. If needed, apply a small amount of silicone spray lubricant to the extending parts.
- **Wheels Not Spinning Smoothly:** Inspect the wheels for hair, lint, or other debris caught in the axles. Carefully remove any obstructions. Ensure the luggage is not overloaded beyond its capacity.
- **Zipper Issues:** If a zipper is stuck, avoid forcing it. Gently pull the fabric away from the zipper teeth and try to move the slider. Ensure the zipper teeth are properly aligned.

If you encounter issues not covered here or require further assistance, please refer to the Warranty and Support section.

7. Specifications

Feature	Description
Brand	Coolife
Model Number	YD000075
Material	PC + ABS Hard Shell
Lock Type	TSA-Approved Combination Lock
Wheels	Quiet Airplane Spinner Wheels (360-degree)
Handle	Adjustable 3-Level 100% Pure Aluminum Telescoping Handle
20-inch Carry-on Dimensions	22 x 8.9 x 15.2 inches (Exterior)
20-inch Carry-on Weight	6.3 lbs
20-inch Carry-on Capacity	38 Liters
24-inch Suitcase Dimensions	17.8 x 9.9 x 26.1 inches (Exterior)
24-inch Suitcase Weight	7.7 lbs
24-inch Suitcase Capacity	60 Liters
28-inch Suitcase Dimensions	20.1 x 11.8 (13in when expandable) x 29.9 inches (Exterior)
28-inch Suitcase Weight	10.6 lbs
28-inch Suitcase Capacity	93 Liters (expandable to 110 Liters)
Total Capacity (Set)	191 Liters



Image: Visual size reference and detailed dimensions for each suitcase.

8. Warranty and Support

COOLIFE offers a worldwide **2-year warranty** that covers manufacturing defects. This warranty ensures that your luggage is free from defects in material and workmanship under normal use.

For warranty claims, technical support, or any product-related inquiries, please contact COOLIFE customer service through the retailer where the product was purchased. You may also visit the official COOLIFE brand store online for additional support resources and contact information.

Please retain your proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07Q27F6MS

More documents and user manuals: **https://manuals.plus/**