Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

YING RAY 19032608-R

User Manual

YING RAY Replacement Remote Control for Panasonic & Quasar Air Conditioners

1. Product Overview

This manual provides instructions for the YING RAY replacement remote control, designed to operate specific Panasonic and Quasar window air conditioner units. This remote offers essential functions for controlling your air conditioner.



Figure 1: Front view of the YING RAY replacement remote control, showing its buttons and display area.

2. Setup and Battery Installation

The remote control requires two AAA 1.5V normal batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.

2. Slide the cover downwards or in the direction indicated by an arrow to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

Important: Ensure correct battery polarity. Do not mix old and new batteries, or different types of batteries.

3. Operating Instructions

This remote control provides basic functions for your compatible air conditioner unit. The available functions include:

- **Operation:** Power on/off the air conditioner.
- **Temp:** Adjust the temperature setting. Use the up/down arrows (often labeled TEMP/TIMER) to increase or decrease the temperature.
- **Mode:** Cycle through different operating modes (e.g., Cool, Fan, Dry).
- **Timer:** Set the on/off timer for the unit. Use the TIMER button and SET/CANCEL button in conjunction with temperature arrows to configure.
- **Fan Speed:** Adjust the fan speed (e.g., Low, Medium, High, Auto).

Functions such as "Air Swing" and "Economy" are available only if your original remote control and air conditioner unit supported these features. The replacement remote will transmit these commands if present on the remote's layout.

4. Compatibility

This YING RAY replacement remote control is specifically designed to be compatible with the following Panasonic and Quasar window air conditioner models and original remote control model numbers. This is not a universal remote control.



Figure 2: Visual representation of the YING RAY remote control and its compatibility with various Panasonic and Quasar remote models.

Compatible Original Remote Control Models:

- A75C2062
- A75C2063
- A75C2064
- A75C2065
- 671190018A
- 671190018B
- 671190018C
- 671190018E

Compatible Air Conditioner Unit Models:

Panasonic:

- CW-C60YU, CW-C80YU
- CW-XC60YU, CW-XC80YU, CW-XC82YU, CW-XC83YU
- CW-XC100AU, CW-XC103VU, CW-XC120AU, CW-XC122VU, CW-XC123VU
- CW-XC143EU, CW-XC183EU, CW-XC203EU
- CW-XC103HU, CW-XC104HK, CW-XC104HU, CW-XC105HU
- CW-XC123HU, CW-XC124HU, CW-XC125HU
- CW-XC143HU, CW-XC144HU, CW-XC145HK, CW-XC145HU
- CW-XC183HU, CW-XC184HU, CW-XC185HK, CW-XC85HU
- CW-XC100HU, CW-XC118HU, CW-XC120HU, CW-XC78HU, CW-XC80HU, CW-XC64HU
- CW-XC65HU, CW-XC83GU, CW-XC83HK, CW-XC83HU, CW-XC84GU, CW-XC84HK, CW-XC84HU, CW-XC85HK, CW-XC85HU

Quasar:

- HQ-2102UH, HQ-2122UH, HQ2052UH, HQ2082UH

This list may not be exhaustive. If your model is not listed, please verify compatibility before purchase.

5. Maintenance

To ensure the longevity and proper functioning of your remote control, follow these maintenance guidelines:

- Keep the remote control clean by wiping it with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- Avoid exposing the remote to direct sunlight, high temperatures, or high humidity.
- Do not drop the remote control or subject it to strong impacts.
- If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage.

6. Troubleshooting

If you experience issues with your remote control, try the following troubleshooting steps:

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace the batteries with new AAA 1.5V normal batteries.
  - Ensure there are no obstructions between the remote control and the air conditioner unit's receiver.
  - Confirm that the air conditioner unit is powered on.
- **Limited functionality:**
  - Verify that your air conditioner model supports the specific function (e.g., "Air Swing", "Economy"). This remote only transmits commands for functions present on its layout.
- **Remote range issues:**
  - Ensure you are within the effective operating range of the air conditioner's infrared receiver.
  - Check for strong light sources (like direct sunlight) that might interfere with the infrared signal.

If the problem persists after trying these steps, the air conditioner unit itself may have an issue, or the remote control may be faulty. Please contact the seller for further assistance if necessary.

7. Specifications

Attribute	Detail
Brand	YING RAY
Model Number	19032608-R
Compatible Devices	Air Conditioner
Max Number of Supported Devices	1
Battery Type	AAA 1.5V Normal Battery (not included)
Special Feature	Replacement for specific Panasonic/Quasar models

8. Warranty and Support

Specific warranty information for this YING RAY replacement remote control is not provided in the product details. For any warranty claims, technical support, or further inquiries, please contact the seller directly through your purchase platform. For general product information, you may refer to theYING RAY brand page on Amazon.

© 2024 YING RAY. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07Q2B81ZC

More documents and user manuals: **https://manuals.plus/**