

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [NEBULA](#) /

› [NEBULA by Anker Capsule II Mini Projector, Wi-Fi & Bluetooth, 200 ANSI Lumen 720p, Android TV 9.0, Powerful 8W Speaker, 100" Display, 5000+ Apps, Home Theater, Portable for Movies, Indoor & Outdoor](#)

NEBULA D2421

NEBULA Capsule II Mini Projector User Manual

Model: D2421

PRODUCT OVERVIEW

The NEBULA Capsule II is a compact and portable mini projector designed to deliver a comprehensive entertainment experience. Featuring 720p HD resolution and 200 ANSI lumens, it projects a clear image up to 100 inches. Powered by Android TV 9.0, it offers access to over 5,000 apps. The integrated 8W speaker provides immersive audio. Its portable design, coupled with Wi-Fi and Bluetooth connectivity, makes it suitable for various indoor and outdoor viewing environments.



Figure 1: Front view of the NEBULA Capsule II Mini Projector.

WHAT'S IN THE BOX

- Nebula Capsule II Projector
- Remote Control
- Quick Start Guide
- PD Charger
- Type-C Cable

SETUP

1. Physical Placement & Power

Place the Capsule II on a stable, flat surface. For optimal image quality, ensure the projector lens is unobstructed and facing a flat, light-colored surface or screen. Connect the provided PD charger and Type-C cable to the projector's USB-C port for power.



Figure 2: The compact size and rear ports of the Capsule II.

2. Initial Power On & Auto-Focus

Press and hold the power button on the projector or remote control to turn it on. The Capsule II features automatic focus and vertical keystone correction. The projector will automatically adjust the image clarity and shape. For manual focus adjustment, navigate to Projector Settings in the Android TV menu.

3. Network Connection

Follow the on-screen prompts to connect the Capsule II to your Wi-Fi network. A stable internet connection is essential for accessing streaming apps and online content.

4. Remote Control Pairing

The remote control should automatically pair with the projector upon first use. If not, follow the instructions in the Quick Start Guide to pair it via Bluetooth. The remote features voice control for Google Assistant.

5. Android TV Setup

Complete the initial Android TV setup, including signing in with your Google account to access the Google Play Store and personalize your app selection.




Figure 3: The Android TV interface projected by the Capsule II.

OPERATING

1. App Usage & Content Streaming

Navigate the Android TV interface using the remote control. You can download and install over 5,000 apps from the Google Play Store, including popular streaming services like YouTube, Hulu, and Twitch.

Netflix Compatibility Note: To use Netflix, download the "Nebula Manager" app from Google Play on the projector. Then, use the "Nebula Connect" app on your smartphone to control Netflix playback. Direct Chromecast mirroring of Netflix content is not supported due to licensing restrictions.

2. Screen Mirroring & Casting

The Capsule II has Chromecast built-in, allowing you to cast content directly from compatible apps on your smartphone, tablet, or computer. For iOS devices, you can use screen mirroring features to display your device's screen on the projector.

Video: Demonstrates how to screen mirror and cast content from an iPhone to the Nebula Capsule II.

3. HDMI Input

Connect external devices such as game consoles, Blu-ray players, or laptops to the projector using an HDMI cable. Switch the input source on the projector to HDMI to display content from the connected device.

4. Bluetooth Speaker Mode

The Capsule II can also function as a standalone Bluetooth speaker. Press the dedicated button on the projector to switch to Bluetooth speaker mode, allowing you to play audio from your paired devices without projecting an image.

MAINTENANCE

To ensure optimal performance and longevity of your Capsule II, keep the lens clean using a soft, lint-free cloth. Avoid using abrasive cleaners or solvents. Ensure proper ventilation by keeping the air vents clear of obstructions. Store the projector in a cool, dry place when not in use.

TROUBLESHOOTING

- **No Netflix/Prime Video:** Download

Related Documents - D2421

	<p><u>Nebula Capsule II Smart Mini Projector FAQ - Anker</u></p> <p>Frequently Asked Questions (FAQ) for the Anker Nebula Capsule II Smart Mini Projector. Find answers on display settings, operation, software, connectivity, and more for this portable 720p HD projector with Android TV.</p>
 Ръководство за потребител Небула Капсула 3	<p><u>Nebula Capsule 3: Ръководство за потребител</u></p> <p>Пълно ръководство за потребител за проектора Nebula Capsule 3 от Anker, включващо инструкции за безопасност, настройка, употреба, функции и отстраняване на неизправности.</p>
	<p><u>Nebula Mars 3 Projector: User Guide and Tips for Optimal Performance</u></p> <p>Comprehensive guide to getting the most out of your Nebula Mars 3 projector, covering charging, power, modes, features like autofocus and keystone correction, app integration, firmware updates, and optimal positioning for a superior viewing experience.</p>
	<p><u>Nebula Capsule II User Manual: Setup, Features, and Operation Guide</u></p> <p>Explore the Nebula Capsule II portable smart projector with this comprehensive user manual. Learn about setup, key features like Android TV, operation, settings, troubleshooting, and specifications for an optimal viewing experience.</p>
	<p><u>Nebula Capsule II User Manual</u></p> <p>Comprehensive user manual for the Nebula Capsule II projector, covering setup, features, specifications, and troubleshooting.</p>
 Посібник користувача Nebula Capsule 3	<p><u>Nebula Capsule 3 User Manual</u></p> <p>Comprehensive user manual for the Nebula Capsule 3 portable projector by Anker. Covers setup, features, settings, troubleshooting, and technical specifications for optimal viewing experience.</p>