Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Hatteker RFC-588

Hatteker Professional 5-in-1 Hair, Beard, and Body Trimmer User Manual

Introduction

Thank you for choosing the Hatteker Professional 5-in-1 Hair, Beard, and Body Trimmer. This versatile grooming kit is designed to meet all your personal care needs with precision and convenience. Featuring self-sharpening steel blades, a waterproof design, and a durable lithium battery, this trimmer offers a comprehensive solution for hair, beard, and body grooming.

Please read this manual carefully before using the product to ensure safe and optimal performance. Keep this manual for future reference.



The Hatteker 5-in-1 trimmer offers maximum precision for face, hair, and body grooming.

Safety Information

General Warnings

- Risk of cuts from blades. Handle with care.
- Skin irritation may occur due to improper use. Always follow instructions.
- Do not use near water or while charging, unless explicitly stated for specific waterproof models.
- Follow the IPX7 waterproof rating guidelines to prevent damage.
- Product packaging may contain different information than shown online. Always read the label, warnings, and instructions provided with the physical product before use.

Package Contents

Your Hatteker Professional 5-in-1 Trimmer package includes the following items:

- Hatteker Trimmer Unit
- Precision Trimmer Head (for beard/hair/ears)
- Body Shaver Head
- Adjustable Hair Clipper Head with sliding regulator (1-10mm)
- Variable Thickness Beard Comb (3/4/5/6mm)
- 4 Guide Combs (6/9/12/15mm)
- USB Charging Cable
- Charging Stand
- Cleaning Brush
- Lubricating Oil
- Travel Pouch



The complete Hatteker grooming kit, including the trimmer, charging stand, and all attachments, organized for convenience.



The Hatteker professional trimmer comes with various interchangeable heads and guide combs for versatile grooming.

Setup

Charging the Trimmer

1. Before first use, fully charge the trimmer.
2. Connect the USB charging cable to the trimmer and a suitable USB power adapter (not included) or a computer USB port.
3. The digital display will show charging progress. A full charge takes approximately 90 minutes and provides up to 60 minutes of cordless runtime.
4. You can charge the trimmer directly via the cable or by placing it on the charging stand.



The trimmer can be conveniently charged using a standard USB cable, connecting to various power sources.

Attaching and Detaching Heads/Combs

- To attach a head: Align the desired head with the trimmer body and press firmly until it clicks into place.
- To detach a head: Gently push the head upwards from the front of the trimmer until it releases.
- To attach a guide comb: Slide the comb onto the desired trimmer head until it locks securely.
- To detach a guide comb: Gently pull the comb away from the trimmer head.

Operating Instructions

Powering On/Off

Press the power button once to turn the trimmer on. Press it again to turn it off. The digital display will show the remaining battery life when powered on.



The integrated digital display clearly shows the remaining battery life in minutes.

Adjusting Cutting Length

For the adjustable hair clipper head, use the sliding regulator to select your desired cutting length from 1mm to 10mm. For other heads, attach the appropriate guide comb (3/4/5/6mm for beard, 6/9/12/15mm for hair) to achieve the desired length.



The precision dial allows for fine-tuning of cutting lengths from 1mm to 10mm for accurate styling.

Using Different Attachments

Select the appropriate attachment for your grooming task:

- **Precision Trimmer:** Ideal for beard shaping, detailing, and precise hair lines.
- **Hair Clipper:** Use with the adjustable comb or fixed guide combs for various hair lengths on your head.
- **Nose/Ear Trimmer:** Gently insert into nostrils or ears to remove unwanted hair.
- **Body Shaver:** For efficient and comfortable removal of body hair.

Always move the shaver gently over the skin in the direction of hair growth for best results and to prevent irritation.

Kit multi-grooming



Tagliapeli per naso



Tagliapeli per il corpo



Tagliacapelli per incisioni



Tagliacapelli a grandezza naturale



Tagliacapelli a lama larga

This multi-grooming kit is designed for various applications including nose and ear hair trimming, body hair removal, intricate hair designs, and precise beard and hair cutting.

Maintenance

Cleaning

Regular cleaning ensures optimal performance and hygiene:

1. After each use, turn off the trimmer and detach the head.
2. Brush away any loose hairs from the blades and inside the trimmer head using the provided cleaning brush.
3. Since the trimmer is fully washable (IPX7 rated), you can rinse the blades and trimmer head under running water for thorough cleaning. Ensure the trimmer body is not submerged for extended periods.
4. Dry all parts completely before reattaching or storing.



The waterproof design allows for easy cleaning of the trimmer heads under running water.

Lubrication

To maintain blade sharpness and smooth operation, apply a few drops of the provided lubricating oil to the blades after every few uses, especially after rinsing with water. Turn the trimmer on for a few seconds to distribute the oil.

Storage

Store the trimmer and its accessories in a dry, cool place, away from direct sunlight and out of reach of children. Use the provided travel pouch for convenient and protected storage.

Troubleshooting

Problem	Possible Cause	Solution
Trimmer does not turn on.	Battery is depleted.	Charge the trimmer fully.
Trimmer pulls hair or cuts poorly.	Blades are dirty or not lubricated. / Blades are dull.	Clean and lubricate the blades. / Consider replacing the blade head if dullness persists.
Trimmer makes unusual noise.	Blade head not properly attached. / Foreign object in blades.	Reattach the blade head securely. / Clean the blades thoroughly.
Battery life is shorter than expected.	Battery degradation over time. / Not fully charged.	Ensure full charge before use. Battery life naturally decreases over years of use.

Specifications

Feature	Detail
Brand	Hatteker
Model Name	Hatteker RFC (RFC-588)
Item Model Number	RFC-588
Color	Black
Power Source	Battery Powered
Battery Type	1 Lithium Ion battery (included)

Feature	Detail
Battery Charging Time	90 minutes (for 60 minutes runtime)
Connector Type	USB
Blade Material	Alloy Steel
Special Feature	Waterproof (IPX7)
Minimum Cutting Length	0.8 mm (with precision regulator) / 3 mm (with comb)
Maximum Cutting Length	10 mm (with adjustable comb) / 15 mm (with guide comb)
Recommended Uses	Beard, Hair, Ears, Body, Edging, Light Trimming
Target Audience	Men (Unisex)
Package Dimensions	20.2 x 13.8 x 8.4 cm; 540 grams
Country of Origin	China
GTIN / UPC	710670432543

Warranty and Support

Hatteker products are manufactured to high-quality standards. For information regarding warranty coverage, please refer to the warranty card included in your product packaging or contact Hatteker customer support.

For technical support, troubleshooting assistance, or any questions about your product, please visit the official Hatteker website or contact their customer service department. Contact details are typically provided in the product packaging or on the brand's official website.

Product Videos

No official product videos from the seller were available for embedding in this manual. Please refer to the product page or manufacturer's website for any available video demonstrations or guides.

© 2023 Hatteker. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07Q2S1M6H

More documents and user manuals: **https://manuals.plus/**