

Manuals.plus /

- › PremiumCord /
- › PremiumCord 230V Power Cable (IEC 320 C15) Instruction Manual

PremiumCord IEC 320 C15 Unique 2 m

PremiumCord 230V Power Cable (IEC 320 C15)

INSTRUCTION MANUAL

Product Overview

This manual provides essential information for the safe and effective use of your PremiumCord 230V Power Cable. This cable is designed for connecting laptops and other compatible devices to a power source. It features a CEE 7/7 Knieowa 230V UNISCHUKO plug on one end and an IEC 320 C15 socket on the other.



Image: The PremiumCord 230V Power Cable, showing the angled CEE 7/7 (Schuko) plug on the left and the IEC 320 C15 socket on the right, both black in color. The cable itself is also black.

Setup

- 1. Identify Compatible Devices:** Ensure your device requires a 230V power supply and has an IEC 320 C16 inlet (which mates with a C15 socket). This cable is commonly used for certain laptops, network switches, and other IT equipment.
- 2. Connect to Device:** Insert the IEC 320 C15 socket end of the power cable firmly into the corresponding power inlet on your device.
- 3. Connect to Power Outlet:** Insert the CEE 7/7 Knieowa 230V UNISCHUKO plug end of the power cable into a standard 230V wall outlet. Ensure the outlet is properly grounded.
- 4. Verify Connection:** Confirm both ends of the cable are securely connected.

Operating Instructions

Once the cable is properly connected to both your device and a power outlet, the device should receive power. No further operational steps are required for the cable itself, as it functions as a passive power conduit.

- Always ensure the power outlet is easily accessible for quick disconnection if needed.
- Do not overload the power outlet or extension cords.

Maintenance

- **Cleaning:** Disconnect the cable from all power sources and devices before cleaning. Wipe the cable and connectors with a dry, soft cloth. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use, store the cable in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly coiling or bending the cable sharply, as this can damage the internal wires.
- **Inspection:** Periodically inspect the cable for any signs of damage, such as cuts, fraying, or bent pins on the connectors. If damage is observed, discontinue use immediately and replace the cable.

Troubleshooting

Problem	Possible Cause	Solution
Device not receiving power.	Cable not fully inserted.	Ensure both ends of the cable are firmly seated in their respective ports.
Device not receiving power.	Power outlet is not active.	Test the power outlet with another known working device. Check circuit breaker.
Device not receiving power.	Cable is damaged.	Inspect the cable for visible damage (cuts, fraying, bent pins). If damaged, replace the cable.
Device not receiving power.	Incompatible device or power requirements.	Verify that your device's power input matches the cable's specifications (IEC 320 C16 inlet, 230V, 10A).

Specifications

Product Type: Power Cable

Model: IEC 320 C15 Unique
Length: 2 meters (200 Centimeters)
Color: Black
First Plug (Source): CEE 7/7 Knieowa 230V UNISCHUKO (Angled Ground Contact)
Second Plug (Device): IEC 320 C15 Socket
Maximum Voltage: 250 Volts
Maximum Current: 10 Amperes
Cable Cross-section: 2 x 0.75 mm²
Number of Conductors: 2
UL Listed: Yes

Warranty Information

PremiumCord products are manufactured to high-quality standards. This product comes with a standard manufacturer's warranty against defects in materials and workmanship. Please refer to the product packaging or the PremiumCord official website for specific warranty terms and conditions, as these may vary by region and product type. Keep your proof of purchase for warranty claims.

Support

For technical assistance, troubleshooting, or general inquiries regarding your PremiumCord product, please visit the official PremiumCord website or contact their customer support. Contact details can typically be found on the product packaging or the brand's official online presence.

You can visit the PremiumCord store on Amazon: [PremiumCord Store](#)

