

[Manuals.plus](#) /

› [oviitech](#) /

› oviitech Plug in Outlet Extender (Model LA-31) User Manual

oviitech LA-31

oviitech Plug in Outlet Extender (Model LA-31) User Manual

Model: LA-31

INTRODUCTION

This manual provides instructions for the safe and efficient use of your oviitech Plug in Outlet Extender, Model LA-31. This device expands a standard wall outlet into six grounded outlets, featuring a side-entry design for convenience in tight spaces.



Image: Two oviitech Plug in Outlet Extenders, white, with six side-facing outlets visible on each unit.

IMPORTANT SAFETY INFORMATION

Please read and understand all safety instructions before using this product. Failure to follow these instructions may result in electric shock, fire, or personal injury.

- **Indoor Use Only:** This device is designed for indoor use in dry locations. Do not use outdoors or in wet environments.
- **Grounded Outlets:** Ensure the wall outlet you are plugging into is properly grounded.
- **Do Not Overload:** Do not exceed the electrical ratings of 15A, 125V, 60Hz, 1875W. Overloading can cause overheating and fire.
- **Avoid Damage:** Do not use if the device or its outlets appear damaged.
- **Children and Pets:** Keep out of reach of children and pets.
- **ETL Listed:** This product is ETL Listed, indicating compliance with safety standards.



Image: Rear view of the oviitech outlet extender, displaying the two prongs for insertion into a wall outlet and printed safety warnings.

SETUP AND INSTALLATION

The oviitech Plug in Outlet Extender is designed for simple, tool-free installation.

1. **Identify a Wall Outlet:** Locate a standard, grounded 3-prong wall outlet where you need additional power access.
2. **Plug In the Extender:** Align the two prongs of the oviitech outlet extender with the corresponding slots in the wall outlet. Push firmly until the extender is securely seated against the wall. No screws are required for installation.
3. **Verify Stability:** Ensure the extender is stable and does not wobble.








Image: A close-up view of the oviitech outlet extender's prongs, illustrating its design for direct plug-in installation.

OPERATION

Once installed, the oviitech Plug in Outlet Extender provides six grounded AC outlets for your devices.

- **Connecting Devices:** Plug your electrical devices directly into any of the six side-facing outlets.
- **Side-Entry Design:** The side-entry design is particularly useful for furniture placement, allowing furniture to sit closer to the wall without obstructing plugs.
- **Power Capacity:** The extender supports a maximum load of 1875W (15A at 125V). Do not exceed this rating.




Image: The oviitech outlet extender installed behind a yellow shelf, demonstrating how its side-entry design allows for flush furniture placement while providing accessible power.



Image: An oviitech outlet extender in use on a desk, providing power to a laptop and an alarm clock, showcasing its utility in a workspace.



Image: The oviitech outlet extender in a kitchen setting, supplying power to a microwave and an electric kettle, highlighting its application in various indoor environments.

MAINTENANCE

The oviitech Plug in Outlet Extender requires minimal maintenance.

- **Cleaning:** Disconnect the extender from the wall outlet before cleaning. Wipe the exterior with a dry, soft cloth. Do not use liquid cleaners or immerse in water.
- **Inspection:** Periodically inspect the extender for any signs of damage, such as cracks, frayed wires, or loose connections. If damage is found, discontinue use and replace the unit.

TROUBLESHOOTING

If you encounter issues with your oviitech Plug in Outlet Extender, refer to the following common solutions:

- **No Power to Devices:**
 - Ensure the extender is fully and securely plugged into a live wall outlet.
 - Check the circuit breaker for the wall outlet. It may have tripped.
 - Verify that the total wattage of connected devices does not exceed 1875W.
 - Test the wall outlet with another device to confirm it is functional.
- **Loose Fit in Wall Outlet:**
 - Ensure the extender is pushed firmly into the wall outlet.
 - If the wall outlet itself is worn or loose, it may need to be replaced by a qualified electrician.
- **Overheating:**
 - Immediately unplug all devices and the extender from the wall.
 - Reduce the number of high-power devices connected to the extender.
 - Ensure the total wattage does not exceed 1875W.

SPECIFICATIONS

Model Number	LA-31
Total Power Outlets	6 Grounded AC Outlets
Electrical Rating	15A, 125V, 60Hz, 1875W
Product Dimensions	6.38 x 2.68 x 4.92 inches
Item Weight	12.3 ounces
Certifications	ETL Listed
Usage Environment	Indoor Use Only




Image: Dimensional diagram of the oviitech outlet extender, indicating its height, width, and depth for precise fitment.

WARRANTY AND SUPPORT

For warranty information or technical support, please contact oviitech customer service. Refer to your purchase documentation for specific warranty terms and contact details.

You can also visit the official oviitech store for more information: [oviitech Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question