Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

EverNice PF46970+40474-4

EverNice Double Toe Walking Foot Instruction Manual

Model: PF46970+40474-4

1. Introduction

This manual provides instructions for the installation, operation, and maintenance of the EverNice Double Toe Walking Foot. This presser foot is designed to assist in sewing various materials, including leather, upholstery, canvas, and tents, by providing even feeding of multiple layers.

Compatible Sewing Machine Models:

- Pfaff: 145, 146, 195, 245, 335, 540, 545, 1240, 1245 (Note: Not compatible with PFAFF 9063)
- Highlead: GS2698-1B
- Zoje: 335, 335A
- Wimsew: 0602

2. Package Contents

The package includes the following components:

- Outer Foot (Two Toe)
- Inside Foot (4mm)

Part Number: 91-014522293 (46970+40474-4)

3. Setup and Installation

Follow these steps to properly install the Double Toe Walking Foot on your compatible sewing machine:

1. **Prepare the Machine:** Turn off your sewing machine and raise the presser foot lever. Loosen the screw that holds the current presser foot in place.
2. **Remove Existing Foot:** Carefully remove the existing presser foot from the machine.
3. **Attach the Outer Foot:** Position the outer foot component of the walking foot onto the presser bar. Align the screw hole on the outer foot with the screw hole on the presser bar. Secure it with the screw, ensuring it is firm but not overtightened.

4. **Insert the Inner Foot:** Slide the inner foot component into the outer foot, ensuring it sits correctly within the mechanism. The inner foot should move freely within the outer foot.
5. **Verify Installation:** Gently lower the presser foot lever to ensure the walking foot is properly seated and moves smoothly. The feed dogs of the walking foot should align with the machine's feed dogs.



Figure 1: Assembled EverNice Double Toe Walking Foot, ready for installation.



Figure 2: Side view of the outer foot, highlighting its structure.

4. Operation

The Double Toe Walking Foot is designed to provide consistent feeding for challenging materials and multiple fabric layers. Its independent upper and lower feed dogs work in conjunction with your machine's feed dogs to prevent shifting, puckering, and uneven stitching.

- **Material Handling:** This foot is particularly effective when sewing thick materials like leather, vinyl, canvas, or when quilting multiple layers of fabric.
- **Even Stitching:** The walking foot mechanism ensures that all layers of fabric are fed through the machine at the same rate, resulting in more even and professional-looking stitches.
- **Adjustments:** Ensure your machine's tension and stitch length are appropriate for the material thickness you are sewing. Test on a scrap piece of fabric before beginning your project.

5. Maintenance

Proper maintenance will extend the life and performance of your walking foot:

- **Cleaning:** Periodically remove lint and dust from the foot, especially around the feed dogs and moving parts, using a small brush or compressed air.
- **Storage:** Store the walking foot in a clean, dry place when not in use to prevent rust or damage.
- **Inspection:** Regularly inspect the foot for any signs of wear, bending, or damage. Replace if necessary to ensure optimal sewing performance.

6. Troubleshooting

If you encounter issues while using the Double Toe Walking Foot, consider the following:

- **Foot Does Not Fit / Is Too Tight:**
  Ensure your sewing machine model is listed as compatible. Some machines may have slight variations. If the fit is excessively tight, verify that the presser bar screw is not obstructing the foot's attachment. Do not force the foot onto the machine, as this can cause damage.
- **Foot Is Too Loose:**
  Confirm that the presser foot screw is securely tightened. If the foot still feels loose, it may indicate a compatibility issue or a manufacturing tolerance variation.
- **Uneven Feeding / Skipped Stitches:**
  Check that the walking foot is correctly installed and that its feed dogs are engaging properly with the fabric and the machine's feed dogs. Adjust thread tension and needle size according to the material being sewn.
- **Noise During Operation:**
  Ensure all parts are securely fastened and that there is no interference with other machine components. A small amount of sewing machine oil on the moving parts of the walking foot (if recommended by your machine's manual) might reduce friction, but avoid over-oiling.

7. Specifications

Brand	EverNice
Model Number	PF46970+40474-4
Part Number	91-014522293 (46970+40474-4)
Material	Metal (designed for use with materials like leather)
UPC	741025420397

8. Warranty and Support

For warranty information or technical support, please refer to the documentation provided with your purchase or contact EverNice customer service directly. Keep your purchase receipt as proof of purchase.

© 2024 EverNice. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07Q3V1BBJ

More documents and user manuals: **https://manuals.plus/**