Hitachi CV950

Hitachi CV950 Cylinder Vacuum Cleaner User Manual

Model: CV950 | Brand: Hitachi

1. Introduction

This manual provides essential information for the safe and efficient use of your Hitachi CV950 Cylinder Vacuum Cleaner. Please read these instructions thoroughly before operating the appliance and retain them for future reference. The Hitachi CV950 is designed for effective cleaning of various surfaces, featuring a powerful 2000W motor and an 18-liter dust capacity.



Figure 1: Main unit of the Hitachi CV950 Cylinder Vacuum Cleaner.

2. Safety Information

Always observe basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and personal injury.

- Ensure the power supply voltage matches the rating label on the vacuum cleaner.
- Do not use the vacuum cleaner on wet surfaces or to pick up liquids.
- Do not pick up flammable or combustible materials, hot ashes, or sharp objects.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Unplug from the outlet when not in use and before servicing.
- Do not operate with a damaged cord or plug.
- This appliance is for indoor use only.

3. Package Contents

Verify that all components are present in the package:

- Hitachi CV950 Cylinder Vacuum Cleaner Main Unit

- Flexible Hose
- Extension Pipe
- Floor Nozzle
- Crevice Tool
- Dusting Brush
- Cloth Filter (pre-installed)
- User Manual

4. Setup

Follow these steps to assemble your vacuum cleaner before first use:

1. **Attach the Flexible Hose:** Insert the hose end into the suction inlet on the main unit until it clicks securely into place.
2. **Connect Extension Pipe and Nozzle:** Attach the extension pipe to the handle end of the flexible hose. Then, connect the desired cleaning nozzle (e.g., floor nozzle) to the end of the extension pipe.
3. **Power Connection:** Extend the power cord and plug it into a suitable electrical outlet (220V).



Figure 2: Detail of the hose connection to the main unit.

5. Operating Instructions

To operate your Hitachi CV950 vacuum cleaner:

1. **Power On:** Press the ON/OFF button located on the main unit to start the vacuum cleaner.
2. **Adjust Suction Power:** If available, adjust the suction power using the control dial or slider on the unit or hose handle.
3. **Cleaning Surfaces:** Use the appropriate nozzle for the surface you are cleaning. The floor nozzle is suitable for carpets and hard floors. The crevice tool is for narrow spaces, and the dusting brush for delicate surfaces.

4. **Blower Function:** To use the blower function, detach the hose from the suction inlet and attach it to the blower outlet (refer to the diagram on the unit if unsure). This function is useful for blowing away dust from hard-to-reach areas.
5. **Power Off:** After cleaning, press the ON/OFF button to turn off the vacuum cleaner and unplug it from the power outlet.



Figure 3: Extension pipe with a brush attachment for versatile cleaning.

6. Maintenance

Regular maintenance ensures optimal performance and extends the life of your vacuum cleaner.

6.1. Emptying the Dust Container

- The dust indicator will show when the dust container is full and needs emptying.
- Unplug the vacuum cleaner.
- Open the lid of the main unit and carefully remove the dust container.
- Empty the collected dust into a waste bin.
- Reinsert the dust container and close the lid securely.

6.2. Cleaning the Cloth Filter

- The cloth filter should be cleaned regularly, especially when suction power decreases.
- Unplug the vacuum cleaner and remove the dust container.
- Carefully remove the cloth filter.
- Shake off loose dust or gently brush it clean. If heavily soiled, hand wash the filter in lukewarm water without detergent.
- Allow the filter to air dry completely before reinserting. Do not use the vacuum cleaner without a dry filter.

6.3. General Cleaning

- Wipe the exterior of the vacuum cleaner with a soft, damp cloth. Do not use abrasive cleaners.

- Check nozzles and hoses for blockages and remove any debris.

7. Troubleshooting

Refer to the table below for common issues and their solutions.

Problem	Possible Cause	Solution
Vacuum cleaner does not start	No power supply; Power switch off	Check power cord connection; Press ON/OFF switch
Low suction power	Dust container full; Filter clogged; Hose/nozzle blocked	Empty dust container; Clean/replace filter; Remove blockage
Unusual noise	Foreign object in hose/nozzle; Motor issue	Check and remove foreign objects; Contact service center

If the problem persists after attempting these solutions, please contact Hitachi customer support.

8. Specifications

Feature	Specification
Brand	Hitachi
Model Name	CV-950
Power Source	Corded Electric
Voltage	220 Volts
Motor Power	2000 Watts
Dust Capacity	18 Liters
Filter Type	Cloth Filter
Special Feature	Blower Function, Spotless Cleaning
Recommended Surface	Carpet, Hardwood Floors
Noise Level	80 dB
Item Weight	8.42 Kilograms
Product Dimensions (LxWxH)	42 x 33.5 x 54.5 cm
Color	Grey



Figure 4: Internal motor components, highlighting the 2000W power unit.

9. Warranty and Support

This product is covered by a manufacturer's warranty. For specific warranty terms and conditions, please refer to the warranty card included with your purchase or visit the official Hitachi website. Extended warranty plans may also be available for purchase.

9.1. Protection Plans

Additional protection plans are available to cover accidental damages or extend the warranty period. These plans typically offer:

- 2-year accidental damage protection plan for floor care.
- 1-year extended warranty plan for floor care.
- 2-year extended warranty plan for floor care.

Details regarding coverage and pricing for these plans can be found at the point of purchase or by contacting your retailer.

9.2. Customer Support

For technical assistance, spare parts, or service inquiries, please contact Hitachi customer support through their official channels. You can find contact information on the Hitachi website or in your product documentation.

© 2024 Hitachi. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question