

BakkerElkhuizen UltraBoard 950

UltraBoard 950 Compact Bluetooth Keyboard User Manual

Brand: BakkerElkhuizen

INTRODUCTION

This manual provides comprehensive instructions for the UltraBoard 950 Compact Bluetooth Keyboard. It covers essential information regarding product setup, daily operation, routine maintenance, and troubleshooting common issues. Please read this manual thoroughly to ensure optimal performance and longevity of your keyboard.



Image: The UltraBoard 950 Compact Bluetooth Keyboard, showcasing its sleek design and full key layout.

SETUP

Package Contents

- UltraBoard 950 Compact Bluetooth Keyboard
- USB Charging Cable

Charging the Keyboard

Before first use, ensure the keyboard is fully charged. Connect the supplied USB cable to the keyboard's charging port (typically located on the side or back) and to a standard USB power source, such as a computer's USB port or a USB wall adapter. The charging indicator light will illuminate during charging and typically turn off or change color when fully charged.

## Bluetooth Pairing

1. Ensure the keyboard is sufficiently charged.
2. Locate the power switch on the keyboard and slide it to the 'On' position.
3. Activate Bluetooth on your host device (e.g., laptop, tablet, smartphone).
4. On the keyboard, press and hold the dedicated Bluetooth pairing button (or a function key combination, if specified on the keyboard, such as **Fn + C** or a key with a Bluetooth icon) to enter pairing mode. The Bluetooth indicator light will typically flash rapidly.
5. On your device, search for available Bluetooth devices. Select "UltraBoard 950" or a similar name from the list.
6. If prompted, enter any pairing code displayed on your device using the keyboard, then press **Enter**.
7. Once successfully paired, the Bluetooth indicator light on the keyboard will become solid or turn off, indicating a stable connection.




Image: The UltraBoard 950 keyboard from an elevated angle, showing its compact form factor.

## OPERATING THE KEYBOARD

### Hotkeys and Function Keys

The UltraBoard 950 is equipped with various hotkeys and function keys (F1-F12) that provide quick access to common commands. These functions are often indicated by blue icons on the keys. To activate these functions, press the **Fn** key simultaneously with the desired function key.

- **Media Controls:** Play/Pause, Previous Track, Next Track.
- **Volume Controls:** Mute, Volume Down, Volume Up.
- **Other Hotkeys:** Home, Mail, Print Screen, Num Lock, Insert, Delete.

*Note: The specific functionality of some hotkeys may depend on the operating system (Windows, macOS, iOS, Android) and the application in use.*



Image: An annotated diagram illustrating the keyboard's features, including its four hotkeys, light key touch due to scissor mechanism, easy access arrow keys, light keys with black letters for contrast, and compatibility with Windows and macOS.

## Switching Between Devices

The UltraBoard 950 supports multi-device connectivity, allowing you to seamlessly switch between up to five paired devices. To switch, press the designated device selection key (e.g., **Fn + 1**, **Fn + 2**, etc., if applicable, or specific keys labeled for device switching). The keyboard will connect to the selected device.



Image: A user actively typing on the UltraBoard 950 keyboard, illustrating its compact size and comfortable typing position.

## MAINTENANCE

### Care and Cleaning

- To clean the keyboard, gently wipe the surface and keys with a soft, lint-free cloth.
- For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaning solution. Ensure no liquid enters the keyboard.
- Avoid using harsh chemicals, abrasive materials, or aerosol sprays directly on the keyboard.
- Do not immerse the keyboard in water or any other liquid.
- Store the keyboard in a dry environment, away from extreme temperatures, direct sunlight, and excessive dust.



Image: A detailed close-up of the keyboard's side profile, emphasizing its slim design and keycap structure.

## TROUBLESHOOTING

### Keyboard Not Connecting via Bluetooth

- **Check Battery:** Ensure the keyboard is fully charged. Low battery can prevent connection.
- **Re-pair:** On your device, remove or

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

#### Name

#### Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

#### Question

Example: How do I reset this device or fix this error?

#### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

Open the live page

<https://manuals.plus/asin/B07Q77JMZ1>

More documents and user manuals: <https://manuals.plus/>