#### Manuals+

Q & A | Deep Search | Upload

#### manuals.plus /

- homeasy /
- > HOMEASY Electric Meat Grinder & Food Processor User Manual

#### homeasy ALW-FC38

# HOMEASY Electric Meat Grinder & Food Processor User Manual

Model: ALW-FC38

## 1. PRODUCT OVERVIEW

The HOMEASY Electric Meat Grinder & Food Processor is a versatile kitchen appliance designed for chopping and grinding various ingredients. It features a powerful 350W motor and four sharp stainless steel blades, enabling efficient processing of meat, vegetables, fruits, and nuts. The unit includes a durable 2-liter stainless steel bowl, offering ample capacity for family-sized portions. Its user-friendly design ensures easy assembly, operation, and cleaning.



Figure 1.1: Assembled HOMEASY Electric Meat Grinder & Food Processor

#### 2. PRODUCT COMPONENTS

The HOMEASY Electric Meat Grinder & Food Processor consists of several key components designed for optimal performance and ease of use:

- Motor Unit: Contains the 350W motor and control buttons.
- Lid: A transparent cover that fits over the bowl, ensuring safe operation.
- Chopping Blade: Features four sharp stainless steel blades for efficient processing.
- Stainless Steel Bowl: A 2-liter capacity bowl for holding ingredients. It is designed to be stronger and more durable than glass bowls.
- Rubber Mat: An anti-vibration mat for stable operation.



Figure 2.1: Exploded View of Product Components

# **Unbreakble Bowl** Large Capacity Stainless Steel Mixing Bowl Stainless Steel: Glass material: Portable / Anti Drop Heavy / Fragile HOMEASY

Figure 2.2: Stainless Steel Bowl Durability



Figure 2.3: Adamantine Connector for Blade



Figure 2.4: Packing List

#### 3. SETUP

Before first use, ensure all components are clean. Follow these steps to assemble the food processor:

- 1. Place the stainless steel bowl on a stable, flat surface, preferably on the provided rubber mat.
- 2. Carefully place the chopping blade onto the central pin inside the bowl. Ensure it is securely seated.
- 3. Place the transparent lid onto the bowl, aligning it properly.
- 4. Position the motor unit on top of the lid, ensuring the motor shaft engages with the top of the blade assembly.
- 5. Plug the power cord into a suitable electrical outlet.



Figure 3.1: Assembly Steps

#### 4. OPERATING INSTRUCTIONS

The food processor is designed for simple operation with two speed modes:

- 1. Prepare your ingredients by cutting them into smaller, manageable pieces if necessary.
- 2. Place the ingredients into the stainless steel bowl. Do not overfill; ensure the lid can close properly.
- 3. Secure the lid and motor unit as described in the Setup section.
- 4. Select the desired speed by pressing one of the two buttons on top of the motor unit:
  - Button I (Slow Speed): Ideal for meat and harder ingredients.
  - Button II (Fast Speed): Recommended for vegetables and fruits.
- 5. Press and hold the button to operate. Release the button to stop. For best results, use short pulses rather than continuous operation, especially for tougher ingredients.
- 6. Do not operate continuously for more than 40 seconds. Allow the unit to rest for a while before resuming operation to prevent overheating.
- 7. Once processing is complete, unplug the unit, carefully remove the motor unit and lid, and then remove the processed food.



Figure 4.1: Speed Selection Buttons

#### 5. MAINTENANCE AND CLEANING

Proper maintenance ensures the longevity and hygiene of your food processor:

- Always unplug the appliance before cleaning.
- The unit can be disassembled for easy cleaning. The stainless steel bowl, lid, and chopping blade are dishwasher safe.
- Alternatively, these components can be hand washed with warm, soapy water. Rinse thoroughly and dry immediately to prevent water spots or corrosion.
- The motor unit should never be immersed in water. Wipe it clean with a damp cloth.
- Exercise extreme caution when handling the chopping blades as they are very sharp.
- Store the appliance in a dry place when not in use.

#### 6. TROUBLESHOOTING

If you encounter issues with your food processor, consider the following common solutions:

• **Appliance does not turn on:** Ensure the power cord is securely plugged into a working outlet. Verify that the motor unit is correctly seated on the lid and the lid is properly aligned with the bowl.

- **Ingredients are not chopping evenly:** Do not overfill the bowl. Cut larger ingredients into smaller, uniform pieces. Use the pulse function to achieve desired consistency.
- **Motor sounds strained or stops:** This may indicate overloading. Reduce the amount of ingredients in the bowl. Allow the motor to cool down if it has been running continuously for an extended period.
- Excessive vibration or noise: Ensure the appliance is placed on a stable, flat surface and the rubber mat is in place. Check that all components are correctly assembled and secured.

If problems persist, please contact customer support.

### 7. SPECIFICATIONS

Feature	Detail
Brand	homeasy
Model Name	Meat Grinder
Item Model Number	ALW-FC38
Power	350W
Bowl Capacity	2 Liters (8 Cups)
Blade Material	Stainless Steel
Product Dimensions	8.7"D x 8.7"W x 9.8"H
Item Weight	3.19 pounds
Special Feature	Shock Resistant
Color	Grey, Black



Figure 7.1: Product Size and Capacity

# 8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact HOMEASY customer service directly. Keep your purchase receipt for warranty claims.

© 2024 HOMEASY. All rights reserved.

# **Related Documents - ALW-FC38**



#### RovSun Multifunction Meat Grinder ALW-FC18SS Instruction Manual

Comprehensive instruction manual for the RovSun Multifunction Meat Grinder ALW-FC18SS, covering features, specifications, usage, maintenance, and troubleshooting.

CROWN®  Papara usama (Pamagara a respektora)  ANY HIT	Crown ALW 100T Washing Machine User Manual This user manual provides important safety information, operating instructions, and maintenance guidance for the Crown ALW 100T washing machine. Learn about installation, control panel overview, program selection, and troubleshooting.
CROWN®  Western West Trees News August 1	CROWN ALW 80T Washing Machine User Manual Get detailed instructions and safety guidelines for the CROWN ALW 80T washing machine. This user manual covers installation, operation, maintenance, and troubleshooting for optimal appliance performance.
CROWN®  Western Messes (Yest Messel  April 100	Crown ALW 100T Washing Machine User Manual This user manual provides comprehensive instructions for the Crown ALW 100T washing machine, covering safety guidelines, installation, operation, maintenance, technical specifications, programme details, troubleshooting, and fault warnings.
FENIX =	Fenix 2025 Product Catalog: High-Performance Lighting Solutions  Explore the comprehensive 2025 Product Catalog from Fenix, featuring a wide range of high- performance flashlights, headlamps, tactical lights, bicycle lights, camping lanterns, and accessories designed for extreme environments and everyday use.
COURT	Rezultate Financiare Trimestrul III 2025 - SC Visual Fan SA (Allview)  Raport financiar al SC Visual Fan SA (Allview) pentru trimestrul al treilea 2025, detaliind performanța financiară, inițiativele strategice și actualizările segmentelor de afaceri.