

ZIHNIC WH-816

ZIHNIC WH-816 Bluetooth Headphones Instruction Manual

Model: WH-816

1. INTRODUCTION

Thank you for choosing ZIHNIC WH-816 Bluetooth Headphones. These headphones are designed to provide high-definition stereo sound with noise reduction technology for an immersive audio experience. Built for comfort and durability, they feature a foldable and stretchable design, soft memory-protein foam leather earmuffs, and a lightweight construction suitable for prolonged wearing. Enjoy seamless Bluetooth connectivity, dual-mode operation (wireless and wired), and a long-lasting battery life.

2. WHAT'S IN THE BOX

- ZIHNIC WH-816 Bluetooth Headphones
- Protective Case
- USB Charging Cable
- 3.5mm Audio Cable



Image 2.1: ZIHNIC WH-816 Headphones, protective case, USB charging cable, and 3.5mm audio cable.

3. PRODUCT FEATURES AND CONTROLS

The ZIHNIC WH-816 headphones are designed with user-friendly controls and features for a superior audio experience.

- **High Definition Stereo Sound:** Enjoy clear and powerful audio.
- **Noise Reduction Technology:** Minimizes ambient noise for focused listening.
- **Soft Memory-Protein Foam Earmuffs:** Ensures lasting comfort during extended use.
- **Foldable and Stretchable Design:** Allows for a perfect fit and easy portability.
- **Seamless Bluetooth 5.0 Connectivity:** Provides a quick and stable wireless connection up to 10 meters.
- **Dual Mode (Wireless & Wired):** Use wirelessly or connect via the 3.5mm audio cable.
- **Long Battery Life:** Up to 20 hours of playtime on a single charge (450mAh battery, 2.5 hours charging time).
- **Built-in Microphone:** For hands-free calls with noise reduction.
- **Micro SD/TF Card Slot:** For direct music playback from a memory card.
- **FM Radio Function:** Enjoy your favorite radio stations.



Image 3.1: Diagram illustrating the location and function of controls on the ZIHNIC WH-816 headphones, including power, volume, track control, mode button, Micro SD/TF card slot, LED indicator, USB charging port, built-in microphone, and headphone jack.

4. SETUP

4.1 Charging the Headphones

1. Locate the USB Charging Port on the headphone ear cup.
2. Connect the provided USB Charging Cable to the port on the headphones.
3. Plug the other end of the USB cable into a compatible USB power source (e.g., computer USB port, wall adapter).
4. The LED indicator will illuminate during charging and turn off once fully charged. A full charge takes approximately 2.5 hours.

4.2 Bluetooth Pairing

1. Ensure the headphones are turned off.
2. Slide the ON/OFF button to the 'ON' position. The headphones will enter pairing mode, indicated by a flashing LED light (typically blue and red alternating).
3. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
4. Select "WH-816" from the list of found devices.
5. Once successfully paired, the LED indicator will typically show a solid blue light or flash slowly.

5. OPERATING INSTRUCTIONS

5.1 Bluetooth Mode

After successful pairing, your headphones will automatically connect to the last paired device when turned on. Use the volume and track control buttons on the ear cup to manage your audio.

5.2 Wired Mode

To use the headphones in wired mode, connect one end of the provided 3.5mm audio cable to the headphone jack on the ear cup and the other end to your audio device. This mode allows you to continue listening even if the battery is depleted.



Image 5.1: Illustration of the ZIHNIC WH-816 headphones in both wireless (Bluetooth) and wired modes, highlighting the flexibility of use.

5.3 Micro SD/TF Card Playback

Insert a Micro SD/TF card with your favorite music files into the designated slot on the ear cup. The headphones will automatically switch to Micro SD/TF card mode and begin playback.

5.4 FM Radio Mode

Press the 'M' (Mode) button to switch to FM Radio mode. Use the track control buttons to scan for and select radio stations.

5.5 Call Handling

When connected via Bluetooth, you can answer or end calls using the phone button on the ear cup. The built-in microphone with noise reduction ensures clear hands-free communication.

6. MAINTENANCE

- Clean the headphones regularly with a soft, dry cloth.
- Avoid exposing the headphones to extreme temperatures, humidity, or direct sunlight.
- Store the headphones in the provided protective case when not in use to prevent damage.
- Do not attempt to disassemble or repair the headphones yourself. Contact customer support for assistance.

7. TROUBLESHOOTING

7.1 No Sound

- Ensure the headphones are powered on and charged.
- Check the volume level on both the headphones and your connected device.
- If using Bluetooth, ensure the headphones are properly paired and within range.
- If using wired mode, ensure the 3.5mm audio cable is securely connected to both devices.

7.2 Pairing Issues

- Make sure the headphones are in pairing mode (flashing LED).
- Disable and re-enable Bluetooth on your device.
- Move the headphones closer to your device and away from other wireless interference.
- Forget/delete the headphones from your device's Bluetooth list and attempt to re-pair.

7.3 Charging Issues

- Ensure the USB charging cable is not damaged and is securely connected.
- Try a different USB power source or charging cable.
- Confirm the charging port on the headphones is clean and free of debris.

8. SPECIFICATIONS

Feature	Specification
Model Name	WH-816
Connectivity Technology	Wired, Wireless (Bluetooth 5.0)
Bluetooth Range	10 Meters
Battery Capacity	450mAh (1 Lithium Polymer battery)
Battery Life	Up to 20 Hours
Charging Time	2.5 Hours

Headphones Jack	3.5 mm Jack
Noise Control	Sound Isolation
Control Type	Volume Control, Touch
Special Features	Foldable, Microphone Included, Universal Phone Control
Item Weight	10.6 ounces (0.3 Kilograms)
Product Dimensions	6.7 x 6.7 x 3.35 inches
Material	Faux Leather (Earmuffs), Hard-shell synthetic material (Case)
Water Resistance Level	Water Resistant
Compatible Devices	Smartphones, Tablets, Computers, Smart Speakers

9. WARRANTY AND SUPPORT

Your ZIHNIC WH-816 Bluetooth Headphones come with a **12-month warranty**. We are committed to 100% customer satisfaction and offer 24/7 customer support service. For any inquiries, troubleshooting assistance, or warranty claims, please contact our customer support team.

10. PRODUCT VIDEOS

Your browser does not support the video tag.

Video 10.1: A user demonstrates the foldable design of the ZIHNIC headphones and how they fit into the included protective case, highlighting their portability and ease of storage.

Your browser does not support the video tag.

Video 10.2: A user showcases the Rose Gold variant of the ZIHNIC Wireless Headset, demonstrating its design and features. Note: This manual is for the Black WH-816 model.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question