HABA 304688

HABA Rainbow Activity Spiral Toy Instruction Manual

Model: 304688

Introduction

The HABA Rainbow Activity Spiral Toy is designed to engage and stimulate infants aged 0-18 months. This multi-sensory toy features a vibrant spiral design with various textures, a rattle, and a teething element, promoting developmental play. It is easily attachable to car seats, strollers, and cribs, providing entertainment on the go or at home.

Key Features:

- Multi-sensory developmental toy suitable for babies 0-18 months.
- Features 9 fabric sections with different patterns and textures.
- Includes a teething ring, rattle, tags, and leaves for sensory exploration.
- Spiral design allows for easy attachment to car seat handles, strollers, and cribs.
- Machine washable for convenient cleaning.
- Tested to meet US and European safety standards.

Safety Information

Please read and retain these instructions for future reference. Ensure the toy is securely attached before allowing the child to play. Regularly inspect the toy for any signs of wear or damage. Discontinue use if any part becomes loose or broken. This toy is designed for supervised play.

Setup and Attachment

The HABA Rainbow Activity Spiral Toy is designed for easy attachment to various baby equipment.

1. Identify a suitable bar or handle on your car seat, stroller, or crib. The diameter of the bar should allow the spiral to wrap around securely without being too loose or too tight.
2. Begin by wrapping one end of the spiral around the chosen bar.
3. Continue to coil the spiral around the bar until the entire toy is securely attached.
4. Ensure the toy is firmly in place and cannot easily be pulled off by the child. The hanging elements should be within reach of the child for interaction.



Image: A baby reaching for the HABA Rainbow Activity Spiral Toy, which is securely wrapped around the handle of a car seat. The toy features colorful fabric sections and dangling elements.

Operating and Interaction

The HABA Rainbow Activity Spiral Toy offers various elements for your baby's exploration and development.

- **Textured Fabrics:** Encourage your baby to touch and feel the different fabric sections, each with unique patterns and textures, to stimulate tactile senses.
- **Rattle Element:** The clear ring with colorful beads creates a gentle rattling sound when shaken, attracting your baby's attention and developing auditory skills.
- **Teething Ring:** A soft, chewable teething element is included to provide relief during teething phases. Ensure it is clean before use.
- **Tags and Leaves:** Small tags and fabric leaves dangle from the spiral, offering additional elements for grasping, pulling, and sensory discovery.



Image: A detailed view of the HABA Rainbow Activity Spiral Toy, highlighting its vibrant colors, varied fabric textures, the clear rattle ring with beads, and a yellow star-shaped teether.

Maintenance and Cleaning

To ensure hygiene and longevity of your HABA Rainbow Activity Spiral Toy, follow these cleaning instructions:

- The toy is machine washable.
- Use a cold water setting and a delicate cycle.
- Place the toy in a mesh laundry bag to protect it during washing.
- Do not bleach.
- Air dry thoroughly. Do not tumble dry.
- Inspect the toy after washing to ensure all components are intact and secure.

Troubleshooting

If you encounter any issues with your HABA Rainbow Activity Spiral Toy, consider the following:

- **Toy does not stay securely attached:** Ensure the spiral is wrapped tightly around the bar. If the bar is too thin, the toy may not fit securely. Consider attaching it to a thicker bar or adding padding to the bar for a snugger fit.
- **Child shows limited interest:** Introduce the toy during different times of day or in various environments (car, stroller, crib). Demonstrate how to interact with the different elements (rattle, textures).

- **Signs of wear or damage:** Regularly inspect the toy for loose threads, tears, or broken parts. If any damage is found, discontinue use immediately to prevent choking hazards or injury.

Specifications

Model Number	304688
Product Dimensions	11.02 x 3.54 x 5.51 inches
Item Weight	4.6 ounces
Recommended Age	0 - 1 years
Manufacturer	HABA
Release Date	April 1, 2019





Image: The retail packaging for the HABA Rainbow Activity Spiral Toy, displaying the product, brand logo, and model number 304688.

Warranty and Support

HABA toys are manufactured to high-quality standards. For specific warranty information or support inquiries, please refer to the official HABA website or contact HABA customer service directly.
You can visit the official HABA store for more information: HABA Store on Amazon.

© 2026 HABA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question