

[Manuals.plus](#) /

› [TARGUS](#) /

› Targus AMW600AP-50 W600 Wireless Optical Mouse User Manual

TARGUS AMW600AP

Targus W600 Wireless Optical Mouse User Manual

Model: AMW600AP

INTRODUCTION

The Targus W600 Wireless Optical Mouse is designed for precise and comfortable navigation. Featuring a 1,600 DPI optical sensor and 2.4 GHz wireless technology, it provides reliable and responsive control for your computer. The compact USB receiver can be conveniently stored within the mouse, making it ideal for both desktop use and travel.



Figure 1: Targus W600 Wireless Optical Mouse with its USB receiver.

SETUP GUIDE

1. Battery Installation

1. Locate the battery compartment on the underside of the mouse.
2. Slide the battery compartment cover open.
3. Insert one AA alkaline battery, ensuring the positive (+) and negative (-) terminals align correctly with the indicators inside the compartment.
4. Close the battery compartment cover securely.



Figure 2: Underside of the mouse with the battery compartment and power switch.

2. Connecting the USB Receiver

1. Locate the small USB receiver, often stored within the mouse's battery compartment or packaged separately.
2. Plug the USB receiver into an available USB port on your computer.

3. Your operating system (Windows, macOS, or Linux) should automatically detect and install the necessary drivers. This process may take a few moments.



Figure 3: USB receiver connected to a laptop.

OPERATING THE MOUSE

Powering On/Off

On the underside of the mouse, locate the ON/OFF switch (refer to Figure 2). Slide the switch to the "ON" position to activate the mouse. Slide it to "OFF" when not in use to conserve battery life.

Basic Functions

- **Left Button:** Primary click function, used for selecting items, opening files, and confirming actions.
- **Right Button:** Secondary click function, typically used to open context menus.
- **Scroll Wheel:** Used for scrolling through documents and web pages vertically. It can also function as a middle click button.



Figure 4: Top view of the mouse highlighting button layout.

Optical Sensor and Wireless Technology

The Targus W600 mouse utilizes a 1,600 DPI (Dots Per Inch) optical sensor, providing high precision and smooth tracking on various surfaces. The 2.4 GHz wireless technology ensures a stable connection with minimal interference, delays, or

signal drops, offering reliable performance up to 10 meters from the receiver.

MAINTENANCE

Cleaning

To maintain optimal performance, periodically clean the mouse. Use a soft, dry cloth to wipe the exterior. For the optical sensor, use a cotton swab lightly dampened with rubbing alcohol to gently clean the sensor opening on the underside of the mouse. Ensure the mouse is powered off before cleaning.

Battery Replacement

When the mouse performance degrades or it stops responding, it is likely time to replace the battery. Follow the battery installation steps outlined in the "Setup Guide" section.

Receiver Storage

For convenience and to prevent loss, the USB receiver can be stored inside the mouse's battery compartment when not in use or during travel.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Mouse not responding	Battery is low or dead.	Replace the battery.
	Mouse is powered off.	Slide the ON/OFF switch to "ON".
	USB receiver not properly connected.	Ensure the USB receiver is firmly plugged into a working USB port. Try a different USB port.
Erratic cursor movement	Dirty optical sensor.	Clean the optical sensor on the underside of the mouse.
	Using the mouse on an unsuitable surface.	Use the mouse on a flat, non-reflective, opaque surface or a mouse pad.
Connection drops frequently	Interference from other wireless devices or distance from receiver.	Move the mouse closer to the USB receiver. Remove any large metal objects or other 2.4 GHz wireless devices that may be causing interference.

SPECIFICATIONS

Feature	Detail
Brand	TARGUS
Model	AMW600AP
Connectivity Technology	2.4 GHz Wireless (USB Receiver)
Movement Detection Technology	Optical

Feature	Detail
DPI	1,600 DPI
Number of Buttons	3 (Left, Right, Scroll Wheel)
Power Source	Battery Powered
Battery Type	1 x AA Alkaline Battery
Compatible Operating Systems	Windows, macOS, Linux
Dimensions (L x W x H)	97 x 58 x 37.5 mm (approx.)
Weight	56 g (without battery)
Color	Black

WARRANTY AND SUPPORT

Targus products are designed for reliability and performance. This product typically comes with a manufacturer's warranty. For specific warranty terms, duration, and to register your product, please refer to the warranty card included in the product packaging or visit the official Targus website. For technical support, troubleshooting assistance beyond this manual, or warranty claims, please contact Targus customer service through their official support channels.

© 2024 Targus. All rights reserved.
For more information, visit www.targus.com

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07Q912MH3>

More documents and user manuals: <https://manuals.plus/>