

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [TARGUS](#) /

› [Targus W600 Wireless Optical Mouse User Manual](#)

TARGUS AMW60003AP

Targus W600 Wireless Optical Mouse

Model: AMW60003AP

INTRODUCTION

Thank you for purchasing the Targus W600 Wireless Optical Mouse. This manual provides detailed instructions for setting up, operating, and maintaining your new mouse. The Targus W600 is designed for comfortable and precise navigation, featuring a 1,600 DPI optical sensor and reliable 2.4 GHz wireless technology.

Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

SAFETY INFORMATION

- Keep the device away from water and other liquids.
- Do not expose the device to extreme temperatures or direct sunlight.
- Avoid dropping or subjecting the device to strong impacts.
- Do not attempt to disassemble or repair the device yourself. Refer all servicing to qualified personnel.
- Dispose of batteries according to local regulations. Do not dispose of batteries in fire.

PACKAGE CONTENTS

Please check the package for the following items:

- 1 x Targus W600 Wireless Optical Mouse (Blue)
- 1 x USB Receiver
- 2 x AAA Batteries (included)

SETUP

1. Battery Installation

1. Locate the battery compartment on the underside of the mouse.

2. Slide the battery compartment cover open.
3. Insert the two AAA batteries, ensuring the correct polarity (+/-) as indicated inside the compartment.
4. Close the battery compartment cover securely.



Image: Side view of the Targus W600 Wireless Optical Mouse, highlighting its ergonomic design. The battery compartment is located on the underside.

2. Connecting the USB Receiver

1. Locate the USB receiver, which is typically stored in a small compartment on the underside of the mouse or within the packaging.
2. Plug the USB receiver into an available USB port on your computer (PC or Mac).
3. Your computer should automatically detect and install the necessary drivers. This may take a few moments.
4. Once the drivers are installed, the mouse is ready for use.



Image: The Targus W600 Wireless Optical Mouse shown with its compact USB receiver, which plugs into your computer's USB port.

OPERATING THE MOUSE

The Targus W600 Wireless Optical Mouse features standard mouse controls for intuitive navigation.

- **Left Click:** Press the left button to select items, open links, or activate functions.
- **Right Click:** Press the right button to open context menus or access additional options.
- **Scroll Wheel:** Roll the scroll wheel up or down to navigate through documents and web pages. The scroll wheel can also be pressed down for a middle-click function, depending on software configuration.

The 1,600 DPI optical sensor provides precise and responsive cursor control on various surfaces. The 2.4 GHz wireless technology ensures a stable connection with minimal interference.



Image: Top view of the Targus W600 Wireless Optical Mouse, illustrating the primary buttons and scroll wheel for user interaction.

MAINTENANCE

Cleaning

To clean your mouse, gently wipe the surface with a soft, damp cloth. Do not use harsh chemicals, abrasive cleaners, or excessive moisture, as this may damage the device.

Battery Replacement

When the mouse performance degrades or the cursor becomes erratic, it may be time to replace the batteries. Follow the battery installation steps outlined in the "Setup" section.

Storage

When not in use for extended periods, it is recommended to remove the batteries to prevent leakage. The USB receiver can be stored in its dedicated compartment on the underside of the mouse.

TROUBLESHOOTING

Problem	Solution
Mouse not responding.	<ul style="list-style-type: none">Ensure batteries are correctly installed and not depleted. Replace if necessary.Check if the USB receiver is securely plugged into a working USB port. Try a different USB port.Ensure the mouse is within range of the USB receiver (typically up to 10 meters).Restart your computer.
Erratic cursor movement.	<ul style="list-style-type: none">Clean the optical sensor on the underside of the mouse.Ensure you are using the mouse on a suitable surface (non-reflective, non-transparent).Replace the batteries.
Connection drops frequently.	<ul style="list-style-type: none">Move the USB receiver closer to the mouse.Avoid placing the receiver near other wireless devices or large metal objects that might cause interference.Try plugging the receiver into a different USB port, preferably on the front of your computer if available.

SPECIFICATIONS

Brand	TARGUS
-------	--------

Model	AMW60003AP
Connectivity Technology	2.4 GHz Wireless (USB Receiver)
Movement Detection	Optical
DPI	1,600 DPI
Number of Buttons	3
Hand Orientation	Ambidextrous
Power Source	Battery Powered
Batteries Required	2 x AAA (included)
Compatible Operating Systems	Windows XP, Windows 7, Linux, Mac
Product Dimensions	97 x 37.5 x 58 mm; 56 g
Special Features	Wireless, Ergonomic Design

WARRANTY AND SUPPORT

Warranty Information

The Targus W600 Wireless Optical Mouse typically comes with a manufacturer's warranty. Please refer to the warranty card included in your product packaging or visit the official Targus website for detailed warranty terms and conditions specific to your region. Keep your purchase receipt as proof of purchase for warranty claims.

Customer Support

For technical assistance, troubleshooting, or product inquiries, please contact Targus customer support. Contact information can usually be found on the official Targus website or on the product packaging. When contacting support, please have your product model number (AMW60003AP) and purchase details ready. You can visit the official Targus website for more information:www.targus.com